


EU

2026
SWITCH
SOCKET



资质证书

Qualification certificate



ABOUT FIKO 企业简介 Company Profiles

本公司是一家从事电器开关、移动排插及建筑信息智能化产品的设计、开发、生产、销售、服务为一体的外贸出口型企业，公司注重新产品的开发和研制，积极引进国内外先进技术和设备，运用先进的生产工艺和优质的美国进口原材料，生产出了多种规格的家用电器，家庭信息接入箱及电器附件系列产品。

公司始终坚持以“用户至上，质量第一”的质量方针，质量就是生命。公司员工一直坚持把质量作为生命工程来建设，严格按照ISO9001质量体系标准进行内部管理，使质量文化渗透到生产、营销服务到每一个领域，并成为了公司员工的一种自觉行为。

公司不断吸纳和培养适用现代企业管理的高级管理人才，全面导入CIS企业形象策划的战略工程，提升品牌文化。公司的系列产品通过了中国质量认证中心的ISO9001质量体系认证，电工类产品通过了中国国家强制性认证，公司走上了一条可持续发展的道路，公司始终坚持以市场为导向；以科技进步为支柱，以科学管理为动力，追求经济效益与社会效益的完美统一为目标。


公司竭诚为新老客户提供优质可靠的产品和满意的服务，不断促进公司的全面发展，与您共创辉煌，迈进知识经济的新时代。

Our company is engaged in the design, development, production and sales of electrical switch, mobile plug-in and intelligent building information products As an export-oriented foreign trade enterprise, the company pays attention to the development and research of new products, and actively introduces advanced technology and equipment at home and abroad,using advanced production technology and high-quality imported raw materials from the United States, we have produced a variety of household appliances and home information access boxes and electrical accessories series products.

The company always adhere to the quality policy of "customer first, quality first", quality is life. The company's employees have been adhering to quality as a life project to build, in strict accordance with ISO9001 quality system standards for internal management, so that the quality culture into production, marketing services to every field, and become a conscious behavior of the company's employees.

The company continues to absorb and cultivate senior management talents suitable for modern enterprise management, and fully introduces CIS corporate image planning strategy project, enhance brand culture. The company's series of products have passed the ISO9001 quality system certification of China Quality Certification Center class products have passed China's compulsory certification, the company embarked on a road of sustainable development, the company has always been firmly guided by the market taking scientific and technological progress as the pillar, scientific management as the driving force, and pursuing the perfect unification of economic and social benefits as the goal.

The company wholeheartedly provides high quality and reliable products and satisfactory service for new and old customers, and continuously promotes the overall development of the company, and shares with you create brilliance and stride into a new era of knowledge economy.



PARTNER 合作伙伴



EU

CATALOG
目录



P/001-006	LL-K 1	PC白色系列 PC white Series
P/007-012	LL-K2	金色烤漆面板系列 Lacquered panel gold series
P/013-018	LL-K3	黑色烤漆面板系列 Lacquered panel black series
P/019-024	LL-K4	灰色烤漆面板系列 Lacquered panel grey series

P/025-030	LL-L 1	铝镁拉丝金系列 Aluminum magnesium brushed gold Series
P/031-036	LL-L2	铝镁拉丝银系列 Aluminum magnesium brushed silver Series
P/037-042	LL-L3	铝镁拉丝黑系列 Aluminum magnesium brushed black Series
P/043-048	LL-L4	铝镁拉丝灰系列 Aluminum magnesium brushed grey Series



P/049-058	SF-G 1	钢化玻璃白色系列 Tempered glass white Series
P/059-066	SF-G2	钢化玻璃金色系列 Tempered glass gold series
P/067-074	SF-G3	钢化玻璃黑色系列 Tempered glass black series
P/075-082	SF-G4	钢化玻璃灰色系列 Tempered glass grey series



P/083-088	SF-K 1	PC白色系列 PC white Series	P/089-094	SF-K2	金色烤漆面板系列 Lacquered panel gold series
P/095-100	SF-K3	黑色烤漆面板系列 Lacquered panel black series	P/101-106	SF-K4	灰色烤漆面板系列 Lacquered panel grey series



P/107-112	OB-Z 1	PC白色系列 PC white Series	P/113-118	OB-Z2	肤感金色系列 Skin feels gold series
P/119-124	OB-Z3	肤感黑色系列 Skin feels black series	P/125-130	OB-Z4	肤感灰色系列 Skin feels grey series

P/131-136	OB-D 1	Pc大按键白色系列 PC Large Key white Series	P/137-142	OB-D2	喷漆大按键金色系列 Gold-colored large paint-button series
P/143-148	OB-D3	喷漆大按键黑色系列 Black-colored large paint-button series	P/149-154	OB-D4	喷漆大按键灰色系列 Grey-colored large paint-button series

P/155-160	OB-L 1	铝镁银拉丝系列 Aluminum magnesium silver drawing Series	P/161-166	OB-L2	铝镁拉丝金系列 Aluminum magnesium gold drawing series
P/167-172	OB-L3	铝镁黑拉丝系列 Aluminum magnesium black drawing Series	P/173-178	OB-L4	铝镁拉丝灰系列 Aluminum magnesium grey drawing series

P/179-184	OB-G 1	超薄钢化玻璃白色系列 Ultra-thin Tempered glass white series	P/185-190	OB-G2	超薄钢化玻璃金色系列 Ultra-thin Tempered glass gold series
P/191-196	OB-G3	超薄钢化玻璃黑色系列 Ultra-thin Tempered glass black series	P/197-202	OB-G4	超薄钢化玻璃灰色系列 Ultra-thin Tempered glass grey series



P/203-210	功能键	烤漆系列 Lacquered panel series	P/211-212	定制电卡	Bottom box
P/213-216	底盒	Bottom box			


匠心制造
与用户共享生活乐趣
Craftsmanship:
Share the Delight of Life with Users

EUROPEAN CONNECTED SWITCH SOCKET

欧式连体开关插座

一触倾心 · 优雅入微
Fall in love with a touch
Elegant and subtle

欧式肤感连体开关，触摸间的艺术。
European skin sense connected switch,
touch between the art.



LL-K1


SERIES



简约面板设计
彰显非凡格调

Simple panel design,
It shows extraordinary style.


LL-K1 PC白色/PC white

	LL-K1-0071 20A红绿开关 20A Red and green switch ¥:107.00		LL-K1-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:137.00		LL-K1-0087 1/2 USB/TYPE-C+HDMI ¥:297.00
	LL-K1-0072 空白出线孔 Blank outlet hole ¥:26.00		LL-K1-0080 1/2 白板+白板 blank panel+blank panel ¥:31.00		LL-K1-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:252.00
	LL-K1-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:60.00		LL-K1-0081 1/2 双HDMI 1/2 Dual HDMI ¥:342.00		LL-K1-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:175.00
	LL-K1-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:60.00		LL-K1-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:220.00		LL-K1-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:175.00
	LL-K1-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:70.00		LL-K1-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:220.00		LL-K1-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:184.00
	LL-K1-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:100.00		LL-K1-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:229.00		LL-K1-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:215.00
	LL-K1-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:75.00		LL-K1-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:260.00		LL-K1-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:190.00
	LL-K1-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:182.00		LL-K1-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:235.00		

LL-K1 PC白色/PC white

	LL-K1-0001 一开单控开关 ¥:45.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:48.00 1 gang 2 way switch 一开多控开关 ¥:66.00 1 gang 3 way switch		LL-K1-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:55.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:61.00		LL-K1-0017 13A方角插座 13A square corner socket ¥:45.00
	LL-K1-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:50.00 一开双控复位开关 1 gang 2 way Reset switch ¥:53.00		LL-K1-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:65.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:71.00		LL-K1-0018 德式插座 German socket ¥:45.00
	LL-K1-0003 二开单控开关 ¥:55.00 2 gang 1 way switch 二开双控开关 ¥:61.00 2 gang 2 way switch		LL-K1-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:65.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:74.00		LL-K1-0019 法式插座 French socket ¥:45.00
	LL-K1-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:65.00 二开双控复位开关 2 gang 2 way Reset switch ¥:71.00		LL-K1-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:80.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:89.00		LL-K1-0020 俄式插座 Russian socket ¥:45.00
	LL-K1-0005 三开单控开关 ¥:65.00 3 gang 1 way switch 三开双控开关 ¥:74.00 3 gang 2 way switch		LL-K1-0013 门铃开关(荧光) Doorbell switch(Fluorescent lamp) ¥:50.00		LL-K1-0021 德意式插座 German+Italian socket ¥:65.00
	LL-K1-0006 三开单复位开关 ¥:80.00 3 gang 1 way Reset switch 三开双复位开关 ¥:89.00 3 gang 2 way Reset switch		LL-K1-0014 门禁开关(荧光) Gating switch(Fluorescent lamp) ¥:50.00		LL-K1-0022 德式USB+Type-c German USB+Type-C ¥:205.00
	LL-K1-0007 一开单控开关(荧光) ¥:45.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:48.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:66.00 1 gang 3 way switch(Fluorescent lamp)		LL-K1-0015 百叶窗升降开关(荧光) louwer window lifter switch (Fluorescent lamp) ¥:65.00		LL-K1-0023 法式USB+Type-c French USB+Type-C ¥:205.00
	LL-K1-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:50.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:53.00		LL-K1-0016 多功能插座 Universal socket ¥:45.00		LL-K1-0024 德式插座+二位USB 2 USB with German socket ¥:195.00

LL-K1 PC白色/PC white

	LL-K1-0025 法式插座+二位USB 2 USB with French socket ¥:195.00		LL-K1-0033 法式透明防溅插座 French transparent splash-proof socket ¥:68.00		LL-K1-0041 卫星插座 Satellite socket ¥:70.00
	LL-K1-0026 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal)(10W) ¥:192.00		LL-K1-0034 德式插座+防水 German socket + Waterproof belt ¥:55.00		LL-K1-0042 二位卫星插座 Double Satellite socket ¥:90.00
	LL-K1-0027 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal) ¥:262.00		LL-K1-0035 法式插座+防水 French socket + Waterproof belt ¥:55.00		LL-K1-0043 电视卫星插座 Satellite and TV socket ¥:75.00
	LL-K1-0028 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(10W) ¥:192.00		LL-K1-0036 电视插座 TV socket ¥:55.00		LL-K1-0044 电话卫星插座 ¥:75.00 Satellite and telephone socket 电脑卫星插座 ¥:80.00 Satellite and computer socket
	LL-K1-0029 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(20W) ¥:262.00		LL-K1-0037 电话插座 ¥:55.00 telephone socket 电脑插座 ¥:65.00 computer socket		LL-K1-0045 二位USB插座 Double USB socket ¥:175.00
	LL-K1-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:192.00		LL-K1-0038 二位电视插座 Double TV socket ¥:65.00		LL-K1-0046 二位音响插座 Single audio socket ¥:75.00
	LL-K1-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:192.00		LL-K1-0039 二位电话插座 ¥:65.00 Double telephone socket 二位电脑插座 ¥:75.00 Double computer socket 电话电脑插座 ¥:70.00 telephone+computer socket		LL-K1-0047 四位音响插座 Double audio socket ¥:95.00
	LL-K1-0032 德式透明防溅插座 German type transparent splash-proof socket ¥:68.00		LL-K1-0040 电视电话插座 ¥:65.00 TV + telephone socket 电视电脑插座 ¥:70.00 TV + computer socket		LL-K1-0048 紧急呼叫开关 Emergency call switch ¥:145.00

LL-K1 PC白色/PC white

	LL-K1-0049 调光开关300W ¥:118.00 Dimming 300W 调光开关500W ¥:158.00 Dimming 500W 调光开关1000W ¥:188.00 Dimming 1000W 调光LED开关200W ¥:158.00 Dimming LED 200W		LL-K1-0057 凹型人体感应地脚灯 The human body induction footlights ¥:230.00		LL-K1-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥:68.00
	LL-K1-0050 调速开关300W ¥:118.00 Speed 300W 调速开关500W ¥:158.00 Speed 500W		LL-K1-0058 剃须插座 Shaving socket ¥:420.00		LL-K1-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥:68.00
	LL-K1-0051 调音开关 Tuning switch (fire) ¥:168.00		LL-K1-0059 空白面板 Blank plate ¥:26.00		LL-K1-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:68.00
	LL-K1-0052 触摸延时开关 ¥:118.00 Touch delay switch 声光控延时开关 ¥:118.00 Sound-light controlled delay switch		LL-K1-0060 二位德式插座(单体) Double German socket(single) ¥:72.00		LL-K1-0066 一位连体边框 one face frame ¥:12.00
	LL-K1-0053 人体感应开关 Human body induction ¥:228.00		LL-K1-0061 二位法式插座(单体) Double French socket (single) ¥:72.00		LL-K1-0067 二位连体边框 Double face frame ¥:25.00
	LL-K1-0054 叮咚门铃 Ding dong doorbell ¥:158.00		LL-K1-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:342.00		LL-K1-0068 三位连体边框 Three face frame ¥:40.00
	LL-K1-0055 插卡取电(机械式) ¥:220.00 Mechanical card for electricity 插卡取电(低频) ¥:350.00 Low frequency induction card for electricity 插卡取电(高频) ¥:480.00 High frequency induction card for electricity		LL-K1-0069 四位连体边框 four face frame ¥:55.00		LL-K1-0070 五位连体边框 five face frame ¥:70.00

LL-K2

SERIES








简约面板设计
彰显非凡格调

Simple panel design,
It shows extraordinary style.


LL-K2 烤漆金色/Paint gold

	LL-K2-0071 20A红绿开关 20A Red and green switch ¥:123.00		LL-K2-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:148.00		LL-K2-0087 1/2 USB/TYPE-C+HDMI ¥:313.00
	LL-K2-0072 空白出线孔 Blank outlet hole ¥:36.00		LL-K2-0080 1/2 白板+白板 blank panel+blank panel ¥:41.00		LL-K2-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:268.00
	LL-K2-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:70.00		LL-K2-0081 1/2 双HDMI 1/2 Dual HDMI ¥:358.00		LL-K2-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:190.00
	LL-K2-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:70.00		LL-K2-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:235.00		LL-K2-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:190.00
	LL-K2-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:80.00		LL-K2-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:235.00		LL-K2-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:200.00
	LL-K2-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:110.00		LL-K2-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:245.00		LL-K2-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:230.00
	LL-K2-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:85.00		LL-K2-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:275.00		LL-K2-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:205.00
	LL-K2-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:193.00		LL-K2-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:250.00		


LL-K2 烤漆金色/Paint gold

	LL-K2-0001 一开单控开关 ¥:55.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:58.00 1 gang 2 way switch 一开多控开关 ¥:76.00 1 gang 3 way switch		LL-K2-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:65.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:71.00		LL-K2-0017 13A方角插座 13A square corner socket ¥:55.00
	LL-K2-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:60.00 一开双控复位开关 1 gang 2 way Reset switch ¥:63.00		LL-K2-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:75.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:81.00		LL-K2-0018 法式插座 German socket ¥:55.00
	LL-K2-0003 二开单控开关 ¥:65.00 2 gang 1 way switch 二开双控开关 ¥:71.00 2 gang 2 way switch		LL-K2-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:75.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:84.00		LL-K2-0019 法式插座 French socket ¥:55.00
	LL-K2-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:75.00 二开双控复位开关 2 gang 2 way Reset switch ¥:81.00		LL-K2-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:90.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:104.00		LL-K2-0020 俄式插座 Russian socket ¥:55.00
	LL-K2-0005 三开单控开关 ¥:75.00 3 gang 1 way switch 三开双控开关 ¥:84.00 3 gang 2 way switch		LL-K2-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:60.00		LL-K2-0021 德意式插座 German+Italian socket ¥:75.00
	LL-K2-0006 三开单复位开关 ¥:90.00 3 gang 1 way Reset switch 三开双复位开关 ¥:104.00 3 gang 2 way Reset switch		LL-K2-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:60.00		LL-K2-0022 德式USB+Type-c German USB+Type-C ¥:215.00
	LL-K2-0007 一开单控开关(荧光) ¥:55.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:58.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:76.00 1 gang 3 way switch(Fluorescent lamp)		LL-K2-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:75.00		LL-K2-0023 法式USB+Type-c French USB+Type-C ¥:215.00
	LL-K2-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:60.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:63.00		LL-K2-0016 多功能插座 Universal socket ¥:55.00		LL-K2-0024 德式插座+二位USB 2 USB with German socket ¥:205.00

LL-K2 烤漆金色/Paint gold

	LL-K2-0025 法式插座+二位USB 2 USB with French socket ¥ :205.00		LL-K2-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :79.00		LL-K2-0041 卫星插座 Satellite socket ¥ :80.00
	LL-K2-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :203.00		LL-K2-0034 德式插座+防水 German socket + Waterproof belt ¥ :65.00		LL-K2-0042 二位卫星插座 Double Satellite socket ¥ :100.00
	LL-K2-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :273.00		LL-K2-0035 法式插座+防水 French socket + Waterproof belt ¥ :65.00		LL-K2-0043 电视卫星插座 Satellite and TV socket ¥ :85.00
	LL-K2-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :203.00		LL-K2-0036 电视插座 TV socket ¥ :65.00		LL-K2-0044 电话卫星插座 ¥ :85.00 Satellite and telephone socket 电脑卫星插座 ¥ :90.00 Satellite and computer socket
	LL-K2-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :273.00		LL-K2-0037 电话插座 ¥ :65.00 telephone socket 电脑插座 ¥ :75.00 computer socket		LL-K2-0045 二位USB插座 Double USB socket ¥ :185.00
	LL-K2-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :203.00		LL-K2-0038 二位电视插座 Double TV socket ¥ :75.00		LL-K2-0046 二位音响插座 Single audio socket ¥ :85.00
	LL-K2-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :203.00		LL-K2-0039 二位电话插座 ¥ :75.00 Double telephone socket 二位电脑插座 ¥ :85.00 Double computer socket 电话电脑插座 ¥ :80.00 telephone+computer socket		LL-K2-0047 四位音响插座 Double audio socket ¥ :105.00
	LL-K2-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :79.00		LL-K2-0040 电视电话插座 ¥ :75.00 TV + telephone socket 电视电脑插座 ¥ :80.00 TV + computer socket		LL-K2-0048 紧急呼叫开关 Emergency call switch ¥ :155.00

LL-K2 烤漆金色/Paint gold

	LL-K2-0049 调光开关300W Dimming 300W ¥ :128.00 调光开关500W Dimming 500W ¥ :168.00 调光开关1000W Dimming 1000W ¥ :198.00 调光LED开关200W ¥ :168.00 Dimming LED 200W		LL-K2-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :240.00		LL-K2-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :79.00
	LL-K2-0050 调速开关300W ¥ :128.00 Speed 300W 调速开关500W ¥ :168.00 Speed 500W		LL-K2-0058 剃须插座 Shaving socket ¥ :430.00		LL-K2-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :79.00
	LL-K2-0051 调音开关 Tuning switch(fire) ¥ :178.00		LL-K2-0059 空白面板 Blank plate ¥ :36.00		LL-K2-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :79.00
	LL-K2-0052 触摸延时开关 ¥ :128.00 Touch delay switch 声光控延时开关 ¥ :128.00 Sound-light controlled delay switch		LL-K2-0060 二位德式插座(单体) Double German socket(single) ¥ :83.00		LL-K2-0066 一位连体边框 one face frame ¥ :18.00
	LL-K2-0053 人体感应开关 Human body induction ¥ :238.00		LL-K2-0061 二位法式插座(单体) Double French socket (single) ¥ :83.00		LL-K2-0067 二位连体边框 Double face frame ¥ :50.00
	LL-K2-0054 叮咚门铃 Ding dong doorbell ¥ :168.00		LL-K2-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :348.00		LL-K2-0068 三位连体边框 Three face frame ¥ :80.00
	LL-K2-0055 插卡取电(机械式) ¥ :230.00 Mechanical card for electricity 插卡取电(低频) ¥ :360.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :490.00 High frequency induction card for electricity		LL-K2-0069 四位连体边框 four face frame ¥ :110.00		LL-K2-0070 五位连体边框 five face frame ¥ :140.00
	LL-K2-0056 凹型地脚灯 The footlights ¥ :140.00				

LL-K3

SERIES



弧角设计高度符合人体工学原理，触感细腻温润，仿佛触摸着丝滑的绸缎。
简约的面板，摒弃了繁杂的装饰，以纯粹之美展现出高雅格调。
它令人舒适倾心，为生活增添一抹独特的魅力。

The arc Angle design is highly ergonomic, and the touch is delicate and warm,
as if touching silky satin. The simple panel, abandoning the complicated decoration,
shows the elegant style with pure beauty.
It is comfortable and charming, adding a unique charm to life.

LL-K3 烤漆黑色/Paint black

	LL-K3-0071 20A红绿开关 20A Red and green switch ¥:123.00		LL-K3-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:148.00		LL-K3-0087 1/2 USB/TYPE-C+HDMI ¥:313.00
	LL-K3-0072 空白出线孔 Blank outlet hole ¥:36.00		LL-K3-0080 1/2 白板+白板 blank panel+blank panel ¥:41.00		LL-K3-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:268.00
	LL-K3-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:70.00		LL-K3-0081 1/2 双HDMI 1/2 Dual HDMI ¥:358.00		LL-K3-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:190.00
	LL-K3-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:70.00		LL-K3-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:235.00		LL-K3-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:190.00
	LL-K3-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:80.00		LL-K3-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:235.00		LL-K3-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:200.00
	LL-K3-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:110.00		LL-K3-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:245.00		LL-K3-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:230.00
	LL-K3-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:85.00		LL-K3-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:275.00		LL-K3-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:205.00
	LL-K3-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:193.00		LL-K3-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:250.00		

LL-K3 烤漆黑色/Paint black

	LL-K3-0001 一开单控开关 ¥:55.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:58.00 1 gang 2 way switch 一开多控开关 ¥:76.00 1 gang 3 way switch		LL-K3-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:65.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:71.00		LL-K3-0017 13A方角插座 13A square corner socket ¥:55.00
	LL-K3-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:60.00 一开双控复位开关 1 gang 2 way Reset switch ¥:63.00		LL-K3-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:75.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:81.00		LL-K3-0018 德式插座 German socket ¥:55.00
	LL-K3-0003 二开单控开关 ¥:65.00 2 gang 1 way switch 二开双控开关 ¥:71.00 2 gang 2 way switch		LL-K3-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:75.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:84.00		LL-K3-0019 法式插座 French socket ¥:55.00
	LL-K3-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:75.00 二开双控复位开关 2 gang 2 way Reset switch ¥:81.00		LL-K3-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:90.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:104.00		LL-K3-0020 俄式插座 Russian socket ¥:55.00
	LL-K3-0005 三开单控开关 ¥:75.00 3 gang 1 way switch 三开双控开关 ¥:84.00 3 gang 2 way switch		LL-K3-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:60.00		LL-K3-0021 德意式插座 German+Italian socket ¥:75.00
	LL-K3-0006 三开单复位开关 ¥:90.00 3 gang 1 way Reset switch 三开双复位开关 ¥:104.00 3 gang 2 way Reset switch		LL-K3-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:60.00		LL-K3-0022 德式USB+Type-c German USB+Type-C ¥:215.00
	LL-K3-0007 一开单控开关(荧光) ¥:55.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:58.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:76.00 1 gang 3 way switch(Fluorescent lamp)		LL-K3-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:75.00		LL-K3-0023 法式USB+Type-c French USB+Type-C ¥:215.00
	LL-K3-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:60.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:63.00		LL-K3-0016 多功能插座 Universal socket ¥:55.00		LL-K3-0024 德式插座+二位USB 2 USB with German socket ¥:205.00

LL-K3 烤漆黑色/Paint black

	LL-K3-0025 法式插座+二位USB 2 USB with French socket ¥ :205.00		LL-K3-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :79.00		LL-K3-0041 卫星插座 Satellite socket ¥ :80.00
	LL-K3-0026 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal)(10W) ¥ :203.00		LL-K3-0034 德式插座+防水 German socket + Waterproof belt ¥ :65.00		LL-K3-0042 二位卫星插座 Double Satellite socket ¥ :100.00
	LL-K3-0027 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal) ¥ :273.00		LL-K3-0035 法式插座+防水 French socket + Waterproof belt ¥ :65.00		LL-K3-0043 电视卫星插座 Satellite and TV socket ¥ :85.00
	LL-K3-0028 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(10W) ¥ :203.00		LL-K3-0036 电视插座 TV socket ¥ :65.00		LL-K3-0044 电话卫星插座 ¥ :85.00 Satellite and telephone socket 电脑卫星插座 ¥ :90.00 Satellite and computer socket
	LL-K3-0029 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(20W) ¥ :273.00		LL-K3-0037 电话插座 ¥ :65.00 telephone socket 电脑插座 ¥ :75.00 computer socket		LL-K3-0045 二位USB插座 Double USB socket ¥ :185.00
	LL-K3-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :203.00		LL-K3-0038 二位电视插座 Double TV socket ¥ :75.00		LL-K3-0046 二位音响插座 Single audio socket ¥ :85.00
	LL-K3-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :203.00		LL-K3-0039 二位电话插座 ¥ :75.00 Double telephone socket 二位电脑插座 ¥ :85.00 Double computer socket 电话电脑插座 ¥ :80.00 telephone+computer socket		LL-K3-0047 四位音响插座 Double audio socket ¥ :105.00
	LL-K3-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :79.00		LL-K3-0040 电视电话插座 ¥ :75.00 TV + telephone socket 电视电脑插座 ¥ :80.00 TV + computer socket		LL-K3-0048 紧急呼叫开关 Emergency call switch ¥ :155.00


LL-K3 烤漆黑色/Paint black

	LL-K3-0049 调光开关300W Dimming 300W ¥ :128.00 调光开关500W Dimming 500W ¥ :168.00 调光开关1000W Dimming 1000W ¥ :198.00 调光LED开关200W ¥ :168.00 Dimming LED 200W		LL-K3-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :240.00		LL-K3-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :79.00
	LL-K3-0050 调速开关300W ¥ :128.00 Speed 300W 调速开关500W ¥ :168.00 Speed 500W		LL-K3-0058 剃须插座 Shaving socket ¥ :430.00		LL-K3-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :79.00
	LL-K3-0051 调音开关 Tuning switch(fire) ¥ :178.00		LL-K3-0059 空白面板 Blank plate ¥ :36.00		LL-K3-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :79.00
	LL-K3-0052 触摸延时开关 ¥ :128.00 Touch delay switch 声光控延时开关 ¥ :128.00 Sound-light controlled delay switch		LL-K3-0060 二位德式插座(单体) Double German socket(single) ¥ :83.00		LL-K3-0066 一位连体边框 one face frame ¥ :18.00
	LL-K3-0053 人体感应开关 Human body induction ¥ :238.00		LL-K3-0061 二位法式插座(单体) Double French socket (single) ¥ :83.00		LL-K3-0067 二位连体边框 Double face frame ¥ :50.00
	LL-K3-0054 叮咚门铃 Ding dong doorbell ¥ :168.00		LL-K3-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :348.00		LL-K3-0068 三位连体边框 Three face frame ¥ :80.00
	LL-K3-0055 插卡取电(机械式) ¥ :230.00 Mechanical card for electricity 插卡取电(低频) ¥ :360.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :490.00 High frequency induction card for electricity		LL-K3-0069 四位连体边框 four face frame ¥ :110.00		LL-K3-0070 五位连体边框 five face frame ¥ :140.00
	LL-K3-0056 凹型地脚灯 The footlights ¥ :140.00				




LL-K4
SERIES

LL-K4 烤漆灰色/Paint grey

	LL-K4-0071 20A红绿开关 20A Red and green switch ¥:123.00		LL-K4-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:148.00		LL-K4-0087 1/2 USB/TYPE-C+HDMI ¥:313.00
	LL-K4-0072 空白出线孔 Blank outlet hole ¥:36.00		LL-K4-0080 1/2 白板+白板 blank panel+blank panel ¥:41.00		LL-K4-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:268.00
	LL-K4-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:70.00		LL-K4-0081 1/2 双HDMI 1/2 Dual HDMI ¥:358.00		LL-K4-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:190.00
	LL-K4-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:70.00		LL-K4-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:235.00		LL-K4-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:190.00
	LL-K4-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:80.00		LL-K4-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:235.00		LL-K4-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:200.00
	LL-K4-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:110.00		LL-K4-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:245.00		LL-K4-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:230.00
	LL-K4-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:85.00		LL-K4-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:275.00		LL-K4-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:205.00
	LL-K4-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:193.00		LL-K4-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:250.00		


LL-K4 烤漆灰色/Paint grey

	LL-K4-0001 一开单控开关 ¥:55.00 1 gang 1 way switch 一开双控开关 ¥:58.00 1 gang 2 way switch 一开多控开关 ¥:76.00 1 gang 3 way switch		LL-K4-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:65.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:71.00		LL-K4-0017 13A方角插座 13A square corner socket ¥:55.00
	LL-K4-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:60.00 一开双控复位开关 1 gang 2 way Reset switch ¥:63.00		LL-K4-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:75.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:81.00		LL-K4-0018 德式插座 German socket ¥:55.00
	LL-K4-0003 二开单控开关 ¥:65.00 2 gang 1 way switch 二开双控开关 ¥:71.00 2 gang 2 way switch		LL-K4-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:75.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:84.00		LL-K4-0019 法式插座 French socket ¥:55.00
	LL-K4-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:75.00 二开双控复位开关 2 gang 2 way Reset switch ¥:81.00		LL-K4-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:90.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:104.00		LL-K4-0020 俄式插座 Russian socket ¥:55.00
	LL-K4-0005 三开单控开关 ¥:75.00 3 gang 1 way switch 三开双控开关 ¥:84.00 3 gang 2 way switch		LL-K4-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:60.00		LL-K4-0021 德意式插座 German+Italian socket ¥:75.00
	LL-K4-0006 三开单复位开关 ¥:90.00 3 gang 1 way Reset switch 三开双复位开关 ¥:104.00 3 gang 2 way Reset switch		LL-K4-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:60.00		LL-K4-0022 德式USB+Type-c German USB+Type-C ¥:215.00
	LL-K4-0007 一开单控开关(荧光) ¥:55.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:58.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:76.00 1 gang 3 way switch(Fluorescent lamp)		LL-K4-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:75.00		LL-K4-0023 法式USB+Type-c French USB+Type-C ¥:215.00
	LL-K4-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:60.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:63.00		LL-K4-0016 多功能插座 Universal socket ¥:55.00		LL-K4-0024 德式插座+二位USB 2 USB with German socket ¥:205.00

LL-K4 烤漆灰色/Paint grey

	LL-K4-0025 法式插座+二位USB 2 USB with French socket ¥ :205.00		LL-K4-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :79.00		LL-K4-0041 卫星插座 Satellite socket ¥ :80.00
	LL-K4-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :203.00		LL-K4-0034 德式插座+防水 German socket + Waterproof belt ¥ :65.00		LL-K4-0042 二位卫星插座 Double Satellite socket ¥ :100.00
	LL-K4-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :273.00		LL-K4-0035 法式插座+防水 French socket + Waterproof belt ¥ :65.00		LL-K4-0043 电视卫星插座 Satellite and TV socket ¥ :85.00
	LL-K4-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :203.00		LL-K4-0036 电视插座 TV socket ¥ :65.00		LL-K4-0044 电话卫星插座 ¥ :85.00 Satellite and telephone socket 电脑卫星插座 ¥ :90.00 Satellite and computer socket
	LL-K4-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :273.00		LL-K4-0037 电话插座 ¥ :65.00 telephone socket 电脑插座 ¥ :75.00 computer socket		LL-K4-0045 二位USB插座 Double USB socket ¥ :185.00
	LL-K4-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :203.00		LL-K4-0038 二位电视插座 Double TV socket ¥ :75.00		LL-K4-0046 二位音响插座 Single audio socket ¥ :85.00
	LL-K4-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :203.00		LL-K4-0039 二位电话插座 ¥ :75.00 Double telephone socket 二位电脑插座 ¥ :85.00 Double computer socket 电话电脑插座 ¥ :80.00 telephone+computer socket		LL-K4-0047 四位音响插座 Double audio socket ¥ :105.00
	LL-K4-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :79.00		LL-K4-0040 电视电话插座 ¥ :75.00 TV + telephone socket 电视电脑插座 ¥ :80.00 TV + computer socket		LL-K4-0048 紧急呼叫开关 Emergency call switch ¥ :155.00

LL-K4 烤漆灰色/Paint grey


	LL-K4-0049 调光开关300W Dimming 300W ¥ :128.00 调光开关500W Dimming 500W ¥ :168.00 调光开关1000W Dimming 1000W ¥ :198.00 调光LED开关200W ¥ :168.00 Dimming LED 200W		LL-K4-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :240.00		LL-K4-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :79.00
	LL-K4-0050 调速开关300W ¥ :128.00 Speed 300W 调速开关500W ¥ :168.00 Speed 500W		LL-K4-0058 剃须插座 Shaving socket ¥ :430.00		LL-K4-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :79.00
	LL-K4-0051 调音开关 Tuning switch(fire) ¥ :178.00		LL-K4-0059 空白面板 Blank plate ¥ :36.00		LL-K4-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :79.00
	LL-K4-0052 触摸延时开关 ¥ :128.00 Touch delay switch 声光控延时开关 ¥ :128.00 Sound-light controlled delay switch		LL-K4-0060 二位德式插座(单体) Double German socket(single) ¥ :83.00		LL-K4-0066 一位连体边框 one face frame ¥ :18.00
	LL-K4-0053 人体感应开关 Human body induction ¥ :238.00		LL-K4-0061 二位法式插座(单体) Double French socket (single) ¥ :83.00		LL-K4-0067 二位连体边框 Double face frame ¥ :50.00
	LL-K4-0054 叮咚门铃 Ding dong doorbell ¥ :168.00		LL-K4-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :348.00		LL-K4-0068 三位连体边框 Three face frame ¥ :80.00
	LL-K4-0055 插卡取电(机械式) ¥ :230.00 Mechanical card for electricity 插卡取电(低频) ¥ :360.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :490.00 High frequency induction card for electricity		LL-K4-0069 四位连体边框 four face frame ¥ :110.00		
	LL-K4-0056 凹型地脚灯 The footlights ¥ :140.00		LL-K4-0070 五位连体边框 five face frame ¥ :140.00		

LL-L1


SERIES

铝镁金拉丝

Aluminum-magnesium-gold polishing



The refined texture of light luxury
seamlessly integrates into high-end environments
轻奢的精致质感，无缝融入高端环境



LL-L1 铝镁拉丝金/ Aluminum magnesium brushed gold



LL-L1-0071
20A红绿开关
20A Red and green switch
¥:165.00



LL-L1-0072
空白出线孔
Blank outlet hole
¥:78.00




LL-L1-0073
1/2 电视插座+白板
1/2 TV socket+blank panel
¥:112.00



LL-L1-0074
1/2 电话插座+白板
1/2 telephone socket+blank panel
¥:112.00



LL-L1-0075
1/2 电脑插座+白板
1/2 computer socket+blank panel
¥:122.00



LL-L1-0076
1/2 电脑插座六类+白板
1/2 Computer socket(Cat6)
+blank panel
¥:152.00



LL-L1-0077
1/2 卫星插座+白板
1/2 satellite socket+blank panel
¥:127.00



LL-L1-0078
1/2 HDMI+白板
1/2 HDMI+blank panel
¥:235.00



LL-L1-0079
1/2 USB+type-c10W+白板
1/2 USB+type-c10W+blank panel
¥:190.00



LL-L1-0080
1/2 白板+白板
blank panel+blank panel
¥:83.00



LL-L1-0081
1/2 双HDMI
1/2 Dual HDMI
¥:400.00



LL-L1-0082
1/2 电视+HDMI
1/2 TV socket+1/2 HDMI socket
¥:277.00



LL-L1-0083
1/2 电话+HDMI
1/2 telephone socket+1/2
HDMI socket
¥:277.00



LL-L1-0084
1/2 电脑插座+HDMI
1/2 computer socket+HDMI
¥:287.00



LL-L1-0085
1/2 电脑插座六类+HDMI
1/2 Computer socket(Cat6)+HDMI
¥:317.00



LL-L1-0086
1/2 卫星+HDMI
1/2 satellite socket+HDMI
¥:292.00



LL-L1-0087
1/2 USB/TYPE-C+HDMI
¥:355.00



LL-L1-0088
二位1/2 USB/TYPE-C
Double 1/2 USB/TYPE-C
¥:310.00



LL-L1-0089
1/2 电视+USB/TYPE-C
1/2 TV socket+1/2USB/TYPE-C
¥:232.00



LL-L1-0090
1/2 电话+USB/TYPE-C
1/2 telephone socket+
1/2 USB/TYPE-C
¥:232.00



LL-L1-0091
1/2 电脑+USB/TYPE-C
1/2 Computer socket+ USB/TYPE-C
¥:242.00



LL-L1-0092
1/2 电脑六类+USB/TYPE-C
1/2 Computer socket(Cat6)
+USB/TYPE-C
¥:272.00



LL-L1-0093
1/2 卫星+USB/TYPE-C
1/2 satellite socket+USB/TYPE-C
¥:247.00

LL-L1 铝镁拉丝金/ Aluminum magnesium brushed gold



LL-L1-0001
一开单控开关 ¥:97.00
1 gang 1 way switch
(Fluorescent lamp)
一开双控开关 ¥:100.00
1 gang 2 way switch
一开多控开关 ¥:118.00
1 gang 3 way switch



LL-L1-0002
一开单控复位开关
1 gang 1 way Reset switch
¥:102.00
一开双控复位开关
1 gang 2 way Reset switch
¥:105.00



LL-L1-0003
二开单控开关 ¥:107.00
2 gang 1 way switch
二开双控开关 ¥:113.00
2 gang 2 way switch



LL-L1-0004
二开单控复位开关
2 gang 1 way Reset switch
¥:117.00
二开双控复位开关
2 gang 2 way Reset switch
¥:123.00



LL-L1-0005
三开单控开关 ¥:117.00
3 gang 1 way switch
三开双控开关 ¥:126.00
3 gang 2 way switch



LL-L1-0006
三开单复位开关 ¥:132.00
3 gang 1 way Reset switch
三开双复位开关 ¥:141.00
3 gang 2 way Reset switch



LL-L1-0007
一开单控开关(荧光) ¥:97.00
1 gang 1 way switch(Fluorescent lamp)
一开双控开关(荧光) ¥:100.00
1 gang 2 way switch(Fluorescent lamp)
一开多控开关(荧光) ¥:118.00
1 gang 3 way switch(Fluorescent lamp)



LL-L1-0008
一开单控复位开关(荧光)
1 gang 1 way Reset switch
(Fluorescent lamp)
¥:102.00
一开双控复位开关(荧光)
1 gang 2 way Reset switch
(Fluorescent lamp)
¥:105.00



LL-L1-0009
二开单控开关(荧光)
2 gang 1 way switch
(Fluorescent lamp)
¥:107.00
二开双控开关(荧光)
2 gang 2 way switch
(Fluorescent lamp)
¥:113.00



LL-L1-0010
二开单控复位开关(荧光)
2 gang 1 way Reset switch
(Fluorescent lamp)
¥:117.00
二开双控复位开关(荧光)
2 gang 2 way Reset switch
(Fluorescent lamp)
¥:123.00



LL-L1-0011
三开单控开关(荧光)
3 gang 1 way switch
(Fluorescent lamp)
¥:117.00
三开双控开关(荧光)
3 gang 2 way switch
(Fluorescent lamp)
¥:126.00



LL-L1-0012
三开单复位开关(荧光)
3 gang 1 way Reset switch
(Fluorescent lamp)
¥:132.00
三开双复位开关(荧光)
3 gang 2 way Reset switch
(Fluorescent lamp)
¥:141.00



LL-L1-0013
门铃开关(荧光)
Doorbell switch
(Fluorescent lamp)
¥:102.00



LL-L1-0014
门禁开关(荧光)
Gating switch
(Fluorescent lamp)
¥:102.00



LL-L1-0015
百叶窗升降开关(荧光)
louver window lifter switch
(Fluorescent lamp)
¥:117.00



LL-L1-0016
多功能插座
Universal socket
¥:97.00



LL-L1-0017
13A方角插座
13A square corner socket
¥:97.00



LL-L1-0018
德式插座
German socket
¥:97.00



LL-L1-0019
法式插座
French socket
¥:97.00



LL-L1-0020
俄式插座
Russian socket
¥:97.00



LL-L1-0021
德意式插座
German+Italian socket
¥:117.00



LL-L1-0022
德式USB+Type-c
German USB+Type-C
¥:257.00





LL-L1-0023
法式USB+Type-c
French USB+Type-C
¥:257.00







LL-L1-0024
德式插座+二位USB
2 USB with German socket
¥:247.00

LL-L1 铝镁拉丝金/ Aluminum magnesium brushed gold

	LL-L1-0025 法式插座+二位USB 2 USB with French socket ¥ :247.00		LL-L1-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :121.00		LL-L1-0041 卫星插座 Satellite socket ¥ :122.00
	LL-L1-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :245.00		LL-L1-0034 德式插座+防水 German socket + Waterproof belt ¥ :107.00		LL-L1-0042 二位卫星插座 Double Satellite socket ¥ :142.00
	LL-L1-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C(20W) (horizontal) ¥ :315.00		LL-L1-0035 法式插座+防水 French socket + Waterproof belt ¥ :107.00		LL-L1-0043 电视卫星插座 Satellite and TV socket ¥ :127.00
	LL-L1-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :245.00		LL-L1-0036 电视插座 TV socket ¥ :107.00		LL-L1-0044 电话卫星插座 ¥ :127.00 Satellite and telephone socket 电脑卫星插座 ¥ :132.00 Satellite and computer socket
	LL-L1-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :315.00		LL-L1-0037 电话插座 ¥ :107.00 telephone socket 电脑插座 ¥ :117.00 computer socket		LL-L1-0045 二位USB插座 Double USB socket ¥ :227.00
	LL-L1-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :245.00		LL-L1-0038 二位电视插座 Double TV socket ¥ :117.00		LL-L1-0046 二位音响插座 Single audio socket ¥ :127.00
	LL-L1-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :245.00		LL-L1-0039 二位电话插座 ¥ :117.00 Double telephone socket 二位电脑插座 ¥ :127.00 Double computer socket 电话电脑插座 ¥ :122.00 telephone+computer socket		LL-L1-0047 四位音响插座 Double audio socket ¥ :147.00
	LL-L1-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :121.00		LL-L1-0040 电视电话插座 ¥ :117.00 TV + telephone socket 电视电脑插座 ¥ :122.00 TV + computer socket		LL-L1-0048 紧急呼叫开关 Emergency call switch ¥ :197.00

LL-L1 铝镁拉丝金/ Aluminum magnesium brushed gold



	LL-L1-0049 调光开关300W ¥ :170.00 Dimming 300W 调光开关500W ¥ :210.00 Dimming 500W 调光开关1000W ¥ :240.00 Dimming 1000W 调光LED开关200W ¥ :210.00 Dimming LED 200W		LL-L1-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :282.00		LL-L1-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :121.00
	LL-L1-0050 调速开关300W ¥ :170.00 Speed 300W 调速开关500W ¥ :210.00 Speed 500W		LL-L1-0058 剃须插座 Shaving socket ¥ :472.00		LL-L1-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :121.00
	LL-L1-0051 调音开关 Tuning switch(fire) ¥ :220.00		LL-L1-0059 空白面板 Blank plate ¥ :78.00		LL-L1-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :121.00
	LL-L1-0052 触摸延时开关 ¥ :170.00 Touch delay switch 声光控延时开关 ¥ :170.00 Sound-light controlled delay switch		LL-L1-0060 二位德式插座(单体) Double German socket(single) ¥ :125.00		LL-L1-0066 一位连体边框 one face frame ¥ :60.00
	LL-L1-0053 人体感应开关 Human body induction ¥ :280.00		LL-L1-0061 二位法式插座(单体) Double French socket (single) ¥ :125.00		LL-L1-0067 二位连体边框 Double face frame ¥ :160.00
	LL-L1-0054 叮咚门铃 Ding dong doorbell ¥ :210.00		LL-L1-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :390.00		LL-L1-0068 三位连体边框 Three face frame ¥ :240.00
	LL-L1-0055 插卡取电(机械式) ¥ :272.00 Mechanical card for electricity 插卡取电(低频) ¥ :402.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :532.00 High frequency induction card for electricity		LL-L1-0069 四位连体边框 four face frame ¥ :320.00		
	LL-L1-0056 凹型地脚灯 The footlights ¥ :182.00		LL-L1-0070 五位连体边框 five face frame ¥ :400.00		

LL-L2

SERIES








铝镁银拉丝

Aluminum-magnesium-silver polishing














The refined texture of light luxury
seamlessly integrates into high-end environments
轻奢的精致质感，无缝融入高端环境








LL-L2铝镁银拉丝/ Aluminum magnesium silver drawing

	LL-L2-0071 20A红绿开关 20A Red and green switch ¥:165.00		LL-L2-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:190.00		LL-L2-0087 1/2 USB/TYPE-C+HDMI ¥:355.00
	LL-L2-0072 空白出线孔 Blank outlet hole ¥:78.00		LL-L2-0080 1/2 白板+白板 blank panel+blank panel ¥:83.00		LL-L2-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:310.00
	LL-L2-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:112.00		LL-L2-0081 1/2 双HDMI 1/2 Dual HDMI ¥:400.00		LL-L2-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:232.00
	LL-L2-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:112.00		LL-L2-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:277.00		LL-L2-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:232.00
	LL-L2-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:122.00		LL-L2-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:277.00		LL-L2-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:242.00
	LL-L2-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:152.00		LL-L2-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:287.00		LL-L2-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:272.00
	LL-L2-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:127.00		LL-L2-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:317.00		LL-L2-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:247.00
	LL-L2-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:235.00		LL-L2-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:292.00		







LL-L2铝镁银拉丝/ Aluminum magnesium silver drawing

	LL-L2-0001 一开单控开关 ¥:97.00 1 gang 1 way switch 一开双控开关 ¥:100.00 1 gang 2 way switch 一开多控开关 ¥:118.00 1 gang 3 way switch		LL-L2-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:107.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:113.00		LL-L2-0017 13A方角插座 13A square corner socket ¥:97.00
	LL-L2-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:102.00 一开双控复位开关 1 gang 2 way Reset switch ¥:105.00		LL-L2-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:117.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:123.00		LL-L2-0018 德式插座 German socket ¥:97.00
	LL-L2-0003 二开单控开关 ¥:107.00 2 gang 1 way switch 二开双控开关 ¥:113.00 2 gang 2 way switch		LL-L2-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:117.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:126.00		LL-L2-0019 法式插座 French socket ¥:97.00
	LL-L2-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:117.00 二开双控复位开关 2 gang 2 way Reset switch ¥:123.00		LL-L2-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:132.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:141.00		LL-L2-0020 俄式插座 Russian socket ¥:97.00
	LL-L2-0005 三开单控开关 ¥:117.00 3 gang 1 way switch 三开双控开关 ¥:126.00 3 gang 2 way switch		LL-L2-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:102.00		LL-L2-0021 德意式插座 German+Italian socket ¥:117.00
	LL-L2-0006 三开单复位开关 ¥:132.00 3 gang 1 way Reset switch 三开双复位开关 ¥:141.00 3 gang 2 way Reset switch		LL-L2-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:102.00		LL-L2-0022 德式USB+Type-c German USB+Type-C ¥:257.00
	LL-L2-0007 一开单控开关(荧光) ¥:97.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:100.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:118.00 1 gang 3 way switch(Fluorescent lamp)		LL-L2-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:117.00		LL-L2-0023 法式USB+Type-c French USB+Type-C ¥:257.00
	LL-L2-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:102.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:105.00		LL-L2-0016 多功能插座 Universal socket ¥:97.00		LL-L2-0024 德式插座+二位USB 2 USB with German socket ¥:247.00

LL-L2铝镁银拉丝/ Aluminum magnesium silver drawing

	LL-L2-0025 法式插座+二位USB 2 USB with French socket ¥ :247.00		LL-L2-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :121.00		LL-L2-0041 卫星插座 Satellite socket ¥ :122.00
	LL-L2-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :245.00		LL-L2-0034 德式插座+防水 German socket + Waterproof belt ¥ :107.00		LL-L2-0042 二位卫星插座 Double Satellite socket ¥ :142.00
	LL-L2-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :315.00		LL-L2-0035 法式插座+防水 French socket + Waterproof belt ¥ :107.00		LL-L2-0043 电视卫星插座 Satellite and TV socket ¥ :127.00
	LL-L2-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :245.00		LL-L2-0036 电视插座 TV socket ¥ :107.00		LL-L2-0044 电话卫星插座 ¥ :127.00 Satellite and telephone socket 电脑卫星插座 ¥ :132.00 Satellite and computer socket
	LL-L2-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :315.00		LL-L2-0037 电话插座 ¥ :107.00 telephone socket 电脑插座 ¥ :117.00 computer socket		LL-L2-0045 二位USB插座 Double USB socket ¥ :227.00
	LL-L2-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :245.00		LL-L2-0038 二位电视插座 Double TV socket ¥ :117.00		LL-L2-0046 二位音响插座 Single audio socket ¥ :127.00
	LL-L2-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :245.00		LL-L2-0039 二位电话插座 ¥ :117.00 Double telephone socket 二位电脑插座 ¥ :127.00 Double computer socket 电话电脑插座 ¥ :122.00 telephone+computer socket		LL-L2-0047 四位音响插座 Double audio socket ¥ :147.00
	LL-L2-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :121.00		LL-L2-0040 电视电话插座 ¥ :117.00 TV + telephone socket 电视电脑插座 ¥ :122.00 TV + computer socket		LL-L2-0048 紧急呼叫开关 Emergency call switch ¥ :197.00

LL-L2铝镁银拉丝/ Aluminum magnesium silver drawing



	LL-L2-0049 调光开关300W ¥ :170.00 Dimming 300W 调光开关500W ¥ :210.00 Dimming 500W 调光开关1000W ¥ :240.00 Dimming 1000W 调光LED开关200W ¥ :210.00 Dimming LED 200W		LL-L2-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :282.00		LL-L2-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :121.00
	LL-L2-0050 调速开关300W ¥ :170.00 Speed 300W 调速开关500W ¥ :210.00 Speed 500W		LL-L2-0058 剃须插座 Shaving socket ¥ :472.00		LL-L2-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :121.00
	LL-L2-0051 调音开关 Tuning switch(fire) ¥ :220.00		LL-L2-0059 空白面板 Blank plate ¥ :78.00		LL-L2-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :121.00
	LL-L2-0052 触摸延时开关 ¥ :170.00 Touch delay switch 声光控延时开关 ¥ :170.00 Sound-light controlled delay switch		LL-L2-0060 二位德式插座(单体) Double German socket(single) ¥ :125.00		LL-L2-0066 一位连体边框 one face frame ¥ :60.00
	LL-L2-0053 人体感应开关 Human body induction ¥ :280.00		LL-L2-0061 二位法式插座(单体) Double French socket (single) ¥ :125.00		LL-L2-0067 二位连体边框 Double face frame ¥ :160.00
	LL-L2-0054 叮咚门铃 Ding dong doorbell ¥ :210.00		LL-L2-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :390.00		LL-L2-0068 三位连体边框 Three face frame ¥ :240.00
	LL-L2-0055 插卡取电(机械式) ¥ :272.00 Mechanical card for electricity 插卡取电(低频) ¥ :402.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :532.00 High frequency induction card for electricity		LL-L2-0069 四位连体边框 four face frame ¥ :320.00		
	LL-L2-0056 凹型地脚灯 The footlights ¥ :182.00		LL-L2-0070 五位连体边框 five face frame ¥ :400.00		

LL-L3

SERIES

铝镁黑拉丝

Aluminum-magnesium-black polishing




The refined texture of light luxury
seamlessly integrates into high-end environments
轻奢的精致质感，无缝融入高端环境

LL-L3铝镁黑拉丝/ Aluminum magnesium black brushed

	LL-L3-0071 20A红绿开关 20A Red and green switch ¥:165.00		LL-L3-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:190.00		LL-L3-0087 1/2 USB/TYPE-C+HDMI ¥:355.00
	LL-L3-0072 空白出线孔 Blank outlet hole ¥:78.00		LL-L3-0080 1/2 白板+白板 blank panel+blank panel ¥:83.00		LL-L3-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:310.00
	LL-L3-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:112.00		LL-L3-0081 1/2 双HDMI 1/2 Dual HDMI ¥:400.00		LL-L3-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:232.00
	LL-L3-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:112.00		LL-L3-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:277.00		LL-L3-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:232.00
	LL-L3-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:122.00		LL-L3-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:277.00		LL-L3-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:242.00
	LL-L3-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:152.00		LL-L3-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:287.00		LL-L3-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:272.00
	LL-L3-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:127.00		LL-L3-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:317.00		LL-L3-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:247.00
	LL-L3-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:235.00		LL-L3-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:292.00		






LL-L3铝镁黑拉丝/ Aluminum magnesium black brushed

	LL-L3-0001 一开单控开关 ¥:97.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:100.00 1 gang 2 way switch 一开多控开关 ¥:118.00 1 gang 3 way switch		LL-L3-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:107.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:113.00		LL-L3-0017 13A方角插座 13A square corner socket ¥:97.00
	LL-L3-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:102.00 一开双控复位开关 1 gang 2 way Reset switch ¥:105.00		LL-L3-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:117.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:123.00		LL-L3-0018 德式插座 German socket ¥:97.00
	LL-L3-0003 二开单控开关 ¥:107.00 2 gang 1 way switch 二开双控开关 ¥:113.00 2 gang 2 way switch		LL-L3-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:117.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:126.00		LL-L3-0019 法式插座 French socket ¥:97.00
	LL-L3-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:117.00 二开双控复位开关 2 gang 2 way Reset switch ¥:123.00		LL-L3-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:132.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:141.00		LL-L3-0020 俄式插座 Russian socket ¥:97.00
	LL-L3-0005 三开单控开关 ¥:117.00 3 gang 1 way switch 三开双控开关 ¥:126.00 3 gang 2 way switch		LL-L3-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:102.00		LL-L3-0021 德意式插座 German+Italian socket ¥:117.00
	LL-L3-0006 三开单复位开关 ¥:132.00 3 gang 1 way Reset switch 三开双复位开关 ¥:141.00 3 gang 2 way Reset switch		LL-L3-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:102.00		LL-L3-0022 德式USB+Type-c German USB+Type-C ¥:257.00
	LL-L3-0007 一开单控开关(荧光) ¥:97.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:100.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:118.00 1 gang 3 way switch(Fluorescent lamp)		LL-L3-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:117.00		LL-L3-0023 法式USB+Type-c French USB+Type-C ¥:257.00
	LL-L3-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:102.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:105.00		LL-L3-0016 多功能插座 Universal socket ¥:97.00		LL-L3-0024 德式插座+二位USB 2 USB with German socket ¥:247.00

LL-L3铝镁黑拉丝/ Aluminum magnesium black brushed

	LL-L3-0025 法式插座+二位USB 2 USB with French socket ¥ :247.00		LL-L3-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :121.00		LL-L3-0041 卫星插座 Satellite socket ¥ :122.00
	LL-L3-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :245.00		LL-L3-0034 德式插座+防水 German socket + Waterproof belt ¥ :107.00		LL-L3-0042 二位卫星插座 Double Satellite socket ¥ :142.00
	LL-L3-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C(20W) (horizontal) ¥ :315.00		LL-L3-0035 法式插座+防水 French socket + Waterproof belt ¥ :107.00		LL-L3-0043 电视卫星插座 Satellite and TV socket ¥ :127.00
	LL-L3-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :245.00		LL-L3-0036 电视插座 TV socket ¥ :107.00		LL-L3-0044 电话卫星插座 ¥ :127.00 Satellite and telephone socket 电脑卫星插座 ¥ :132.00 Satellite and computer socket
	LL-L3-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :315.00		LL-L3-0037 电话插座 ¥ :107.00 telephone socket 电脑插座 ¥ :117.00 computer socket		LL-L3-0045 二位USB插座 Double USB socket ¥ :227.00
	LL-L3-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :245.00		LL-L3-0038 二位电视插座 Double TV socket ¥ :117.00		LL-L3-0046 二位音响插座 Single audio socket ¥ :127.00
	LL-L3-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :245.00		LL-L3-0039 二位电话插座 ¥ :117.00 Double telephone socket 二位电脑插座 ¥ :127.00 Double computer socket 电话电脑插座 ¥ :122.00 telephone+computer socket		LL-L3-0047 四位音响插座 Double audio socket ¥ :147.00
	LL-L3-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :121.00		LL-L3-0040 电视电话插座 ¥ :117.00 TV + telephone socket 电视电脑插座 ¥ :122.00 TV + computer socket		LL-L3-0048 紧急呼叫开关 Emergency call switch ¥ :197.00

LL-L3铝镁黑拉丝/ Aluminum magnesium black brushed



	LL-L3-0049 调光开关300W Dimming 300W ¥ :170.00 调光开关500W Dimming 500W ¥ :210.00 调光开关1000W Dimming 1000W ¥ :240.00 调光LED开关200W ¥ :210.00 Dimming LED 200W		LL-L3-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :282.00		LL-L3-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :121.00
	LL-L3-0050 调速开关300W ¥ :170.00 Speed 300W 调速开关500W ¥ :210.00 Speed 500W		LL-L3-0058 剃须插座 Shaving socket ¥ :472.00		LL-L3-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :121.00
	LL-L3-0051 调音开关 Tuning switch(fire) ¥ :220.00		LL-L3-0059 空白面板 Blank plate ¥ :78.00		LL-L3-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :121.00
	LL-L3-0052 触摸延时开关 ¥ :170.00 Touch delay switch 声光控延时开关 ¥ :170.00 Sound-light controlled delay switch		LL-L3-0060 二位德式插座(单体) Double German socket(single) ¥ :125.00		LL-L3-0066 一位连体边框 one face frame ¥ :60.00
	LL-L3-0053 人体感应开关 Human body induction ¥ :280.00		LL-L3-0061 二位法式插座(单体) Double French socket (single) ¥ :125.00		LL-L3-0067 二位连体边框 Double face frame ¥ :160.00
	LL-L3-0054 叮咚门铃 Ding dong doorbell ¥ :210.00		LL-L3-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :390.00		LL-L3-0068 三位连体边框 Three face frame ¥ :240.00
	LL-L3-0055 插卡取电(机械式) ¥ :272.00 Mechanical card for electricity 插卡取电(低频) ¥ :402.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :532.00 High frequency induction card for electricity		LL-L3-0069 四位连体边框 four face frame ¥ :320.00		LL-L3-0070 五位连体边框 five face frame ¥ :400.00
	LL-L3-0056 凹型地脚灯 The footlights ¥ :182.00				

LL-L4

SERIES





铝镁拉丝灰

Aluminum-magnesium-grey polishing







The refined texture of light luxury
seamlessly integrates into high-end environments
轻奢的精致质感，无缝融入高端环境


LL-L4铝镁拉丝灰/ Aluminum magnesium brushed grey

	LL-L4-0071 20A红绿开关 20A Red and green switch ¥:165.00		LL-L4-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:190.00		LL-L4-0087 1/2 USB/TYPE-C+HDMI ¥:355.00
	LL-L4-0072 空白出线孔 Blank outlet hole ¥:78.00		LL-L4-0080 1/2 白板+白板 blank panel+blank panel ¥:83.00		LL-L4-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:310.00
	LL-L4-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:112.00		LL-L4-0081 1/2 双HDMI 1/2 Dual HDMI ¥:400.00		LL-L4-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:232.00
	LL-L4-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:112.00		LL-L4-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:277.00		LL-L4-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:232.00
	LL-L4-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:122.00		LL-L4-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:277.00		LL-L4-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:242.00
	LL-L4-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:152.00		LL-L4-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:287.00		LL-L4-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:272.00
	LL-L4-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:127.00		LL-L4-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:317.00		LL-L4-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:247.00
	LL-L4-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:235.00		LL-L4-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:292.00		







LL-L4铝镁拉丝灰/ Aluminum magnesium brushed grey

	LL-L4-0001 一开单控开关 ¥:97.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:100.00 1 gang 2 way switch 一开多控开关 ¥:118.00 1 gang 3 way switch		LL-L4-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:107.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:113.00		LL-L4-0017 13A方角插座 13A square corner socket ¥:97.00
	LL-L4-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:102.00 一开双控复位开关 1 gang 2 way Reset switch ¥:105.00		LL-L4-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:117.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:123.00		LL-L4-0018 德式插座 German socket ¥:97.00
	LL-L4-0003 二开单控开关 ¥:107.00 2 gang 1 way switch 二开双控开关 ¥:113.00 2 gang 2 way switch		LL-L4-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:117.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:126.00		LL-L4-0019 法式插座 French socket ¥:97.00
	LL-L4-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:117.00 二开双控复位开关 2 gang 2 way Reset switch ¥:123.00		LL-L4-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:132.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:141.00		LL-L4-0020 俄式插座 Russian socket ¥:97.00
	LL-L4-0005 三开单控开关 ¥:117.00 3 gang 1 way switch 三开双控开关 ¥:126.00 3 gang 2 way switch		LL-L4-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:102.00		LL-L4-0021 德意式插座 German+Italian socket ¥:117.00
	LL-L4-0006 三开单复位开关 ¥:132.00 3 gang 1 way Reset switch 三开双复位开关 ¥:141.00 3 gang 2 way Reset switch		LL-L4-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:102.00		LL-L4-0022 德式USB+Type-c German USB+Type-C ¥:257.00
	LL-L4-0007 一开单控开关(荧光) ¥:97.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:100.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:118.00 1 gang 3 way switch(Fluorescent lamp)		LL-L4-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:117.00		LL-L4-0023 法式USB+Type-c French USB+Type-C ¥:257.00
	LL-L4-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:102.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:105.00		LL-L4-0016 多功能插座 Universal socket ¥:97.00		LL-L4-0024 德式插座+二位USB 2 USB with German socket ¥:247.00

LL-L4铝镁拉丝灰/ Aluminum magnesium brushed grey

	LL-L4-0025 法式插座+二位USB 2 USB with French socket ¥ :247.00		LL-L4-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :121.00		LL-L4-0041 卫星插座 Satellite socket ¥ :122.00
	LL-L4-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :245.00		LL-L4-0034 德式插座+防水 German socket + Waterproof belt ¥ :107.00		LL-L4-0042 二位卫星插座 Double Satellite socket ¥ :142.00
	LL-L4-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :315.00		LL-L4-0035 法式插座+防水 French socket + Waterproof belt ¥ :107.00		LL-L4-0043 电视卫星插座 Satellite and TV socket ¥ :127.00
	LL-L4-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :245.00		LL-L4-0036 电视插座 TV socket ¥ :107.00		LL-L4-0044 电话卫星插座 ¥ :127.00 Satellite and telephone socket 电脑卫星插座 ¥ :132.00 Satellite and computer socket
	LL-L4-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :315.00		LL-L4-0037 电话插座 ¥ :107.00 telephone socket 电脑插座 ¥ :117.00 computer socket		LL-L4-0045 二位USB插座 Double USB socket ¥ :227.00
	LL-L4-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :245.00		LL-L4-0038 二位电视插座 Double TV socket ¥ :117.00		LL-L4-0046 二位音响插座 Single audio socket ¥ :127.00
	LL-L4-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :245.00		LL-L4-0039 二位电话插座 ¥ :117.00 Double telephone socket 二位电脑插座 ¥ :127.00 Double computer socket 电话电脑插座 ¥ :122.00 telephone+computer socket		LL-L4-0047 四位音响插座 Double audio socket ¥ :147.00
	LL-L4-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :121.00		LL-L4-0040 电视电话插座 ¥ :117.00 TV + telephone socket 电视电脑插座 ¥ :122.00 TV + computer socket		LL-L4-0048 紧急呼叫开关 Emergency call switch ¥ :197.00


LL-L4铝镁拉丝灰/ Aluminum magnesium brushed grey

	LL-L4-0049 调光开关300W ¥ :170.00 Dimming 300W 调光开关500W ¥ :210.00 Dimming 500W 调光开关1000W ¥ :240.00 Dimming 1000W 调光LED开关200W ¥ :210.00 Dimming LED 200W		LL-L4-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :282.00		LL-L4-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :121.00
	LL-L4-0050 调速开关300W ¥ :170.00 Speed 300W 调速开关500W ¥ :210.00 Speed 500W		LL-L4-0058 剃须插座 Shaving socket ¥ :472.00		LL-L4-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :121.00
	LL-L4-0051 调音开关 Tuning switch(fire) ¥ :220.00		LL-L4-0059 空白面板 Blank plate ¥ :78.00		LL-L4-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :121.00
	LL-L4-0052 触摸延时开关 ¥ :170.00 Touch delay switch 声光控延时开关 ¥ :170.00 Sound-light controlled delay switch		LL-L4-0060 二位德式插座(单体) Double German socket(single) ¥ :125.00		LL-L4-0066 一位连体边框 one face frame ¥ :60.00
	LL-L4-0053 人体感应开关 Human body induction ¥ :280.00		LL-L4-0061 二位法式插座(单体) Double French socket (single) ¥ :125.00		LL-L4-0067 二位连体边框 Double face frame ¥ :160.00
	LL-L4-0054 叮咚门铃 Ding dong doorbell ¥ :210.00		LL-L4-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :390.00		LL-L4-0068 三位连体边框 Three face frame ¥ :240.00
	LL-L4-0055 插卡取电(机械式) ¥ :272.00 Mechanical card for electricity 插卡取电(低频) ¥ :402.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :532.00 High frequency induction card for electricity		LL-L4-0069 四位连体边框 four face frame ¥ :320.00		
	LL-L4-0056 凹型地脚灯 The footlights ¥ :182.00		LL-L4-0070 五位连体边框 five face frame ¥ :400.00		

SF-G1

钢化玻璃 SERIES

Tempered glass



The high transparency and smooth texture of glass give switches and sockets a unique fashionable and modern feel.

Whether it is a minimalist home decor or a luxurious European style, the glass-faced switch and socket can perfectly match it, adding a touch of refinement and elegance to the space.

SF-G1

SERIES

钢化玻璃面板
Tempered glass panel











The high transparency and smooth texture of glass give switches and sockets a unique fashionable and modern feel. Whether it is a minimalist home decor or a luxurious European style, the glass-faced switch and socket can perfectly match it, adding a touch of refinement and elegance to the space.












SF-G1钢化玻璃白色/Tempered glass white

	SF-G1-0129 20A红绿开关 20A Red and green switch ¥:185.00		SF-G1-0137 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:210.00		SF-G1-0145 1/2 USB/TYPE-C+HDMI ¥:375.00
	SF-G1-0130 空白出线孔 Blank outlet hole ¥:98.00		SF-G1-0138 1/2 白板+白板 blank panel+blank panel ¥:103.00		SF-G1-0146 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:330.00
	SF-G1-0131 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:132.00		SF-G1-0139 1/2 双HDMI 1/2 Dual HDMI ¥:420.00		SF-G1-0147 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:252.00
	SF-G1-0132 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:132.00		SF-G1-0140 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:297.00		SF-G1-0148 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:252.00
	SF-G1-0133 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:142.00		SF-G1-0141 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:297.00		SF-G1-0149 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:262.00
	SF-G1-0134 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:172.00		SF-G1-0142 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:307.00		SF-G1-0150 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:292.00
	SF-G1-0135 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:147.00		SF-G1-0143 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:337.00		SF-G1-0151 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:267.00
	SF-G1-0136 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:255.00		SF-G1-0144 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:312.00		






SF-G1钢化玻璃白色/Tempered glass white

	SF-G1-0001 WIFI 触摸一位开关 WIFI Touch 1 gang switch ¥:360.00		SF-G1-0009 大板俄式插座 Russian socket ¥:135.00		SF-G1-0017 大板法式插座带2USB French socket with 2USB ¥:275.00
	SF-G1-0002 ZIGBEE 触摸一位开关 ZIGBEE Touch 1 gang switch ¥:430.00		SF-G1-0010 大板电视插座 TV socket ¥:145.00		SF-G1-0018 大板德式插座带USB/Type-C(10W) German socket with USB/Type-C(10W) ¥:285.00
	SF-G1-0003 WIFI触摸二位开关 WIFI Touch 2 gang switch ¥:410.00		SF-G1-0011 大板电话插座 ¥:145.00 telephone socket 大板电脑插座 ¥:155.00 computer socket		SF-G1-0019 大板德式插座带USB/Type-C(20W) German socket with USB/Type-C(20W) ¥:335.00
	SF-G1-0004 ZIGBEE触摸二位开关 ZIGBEE Touch 2 gang switch ¥:480.00		SF-G1-0012 大板电视电话插座 ¥:155.00 TV+ telephone socket 大板电视电脑插座 ¥:160.00 TV+computer socket		SF-G1-0020 大板法式插座带USB/Type-C(10W) French socket with USB/Type-C(10W) ¥:285.00
	SF-G1-0005 WIFI触摸三位开关 WIFI Touch 1 gang switch ¥:460.00		SF-G1-0013 大板电话电脑插座 telephone + computer socket ¥:160.00		SF-G1-0021 大板法式插座带USB/Type-C(20W) French socket with USB/Type-C(20W) ¥:335.00
	SF-G1-0006 ZIGBEE触摸三位开关 ZIGBEE Touch 3 gang switch ¥:530.00		SF-G1-0014 大板调光 300W Dimming 300W ¥:228.00		SF-G1-0022 121双联德式插座 Double German socket ¥:291.00
	SF-G1-0007 大板德式插座 German socket ¥:135.00		SF-G1-0015 大板调速 300W Speed 300W ¥:228.00		SF-G1-0023 121双联法式插座 Double French socket ¥:291.00
	SF-G1-0008 大板法式插座 French socket ¥:135.00		SF-G1-0016 大板德式插座带2USB German socket with 2USB ¥:275.00		SF-G1-0024 121双联俄式插座 Double Russian socket ¥:291.00











SF-G1钢化玻璃白色/Tempered glass white

	SF-G1-0025 大板德式+德式插座 German+German socket ¥:270.00		SF-G1-0033 大板二位连体wifi触摸三开+法式插座 Two-position WiFi touch 3 switch + French socket ¥:595.00
	SF-G1-0026 大板法式+法式插座 French+French socket ¥:270.00		SF-G1-0034 大板德式插座带2USB*2 German socket with 2USB*2 ¥:550.00
	SF-G1-0027 大板俄式+俄式插座 Russian+Russian socket ¥:270.00		SF-G1-0035 大板法式插座带2USB*2 French socket with 2USB*2 ¥:550.00
	SF-G1-0028 大板二位连体WiFi触摸一开+德式插座 Two-position WiFi touch 1 switch + German socket ¥:495.00		SF-G1-0036 大板德式插座带USB/Type-C*2(10W) German socket with USB/Type-C*2(10W) ¥:570.00
	SF-G1-0029 大板二位连体WiFi触摸二开+德式插座 Two-position WiFi touch 2 switch + German socket ¥:545.00		SF-G1-0037 大板法式插座带USB/Type-C*2(10W) French socket with USB/Type-C*2(10W) ¥:570.00
	SF-G1-0030 大板二位连体WiFi触摸三开+德式插座 Two-position WiFi touch 3 switch + German socket ¥:595.00		SF-G1-0038 大板三位德式插座 Three-position German socket ¥:405.00
	SF-G1-0031 大板二位连体WiFi触摸一开+法式插座 Two-position WiFi touch 1 switch + French socket ¥:495.00		SF-G1-0039 大板三位法式插座 Three-position French socket ¥:405.00
	SF-G1-0032 大板二位连体WiFi触摸二开+法式插座 Two-position WiFi touch 2 switch + French socket ¥:545.00		SF-G1-0040 大板三位俄式插座 Three-position Russian socket ¥:405.00









SF-G1钢化玻璃白色/Tempered glass white

	SF-G1-0041 大板德式插座带2USB*3 German socket with 2USB*3 ¥:825.00		SF-G1-0042 大板法式插座带2USB*3 French socket with 2USB*3 ¥:825.00
	SF-G1-0043 大板德式插座带USB/Type-C*3(10W) German socket with USB/Type-C*3(10W) ¥:855.00		SF-G1-0044 大板法式插座带USB/Type-C*3(10W) French socket with USB/Type-C*3(10W) ¥:855.00
	SF-G1-0045 大板四位德式插座 Four-position German socket ¥:540.00		SF-G1-0046 大板五位德式插座 Five-position German socket ¥:675.00
	SF-G1-0047 大板四位法式插座 Four-position French socket ¥:540.00		SF-G1-0048 大板五位法式插座 Five-position French socket ¥:675.00
	SF-G1-0049 大板四位俄式插座 Four-position Russian socket ¥:540.00		SF-G1-0050 大板五位俄式插座 Five-position Russian socket ¥:675.00
	SF-G1-0051 大板德式插座带2USB*4 German socket with 2USB*4 ¥:1100.00		SF-G1-0052 大板德式插座带2USB*5 German socket with 2USB*5 ¥:1375.00
	SF-G1-0053 大板法式插座带2USB*4 French socket with 2USB*4 ¥:1100.00		SF-G1-0054 大板法式插座带2USB*5 French socket with 2USB*5 ¥:1375.00
	SF-G1-0055 大板德式插座带USB/Type-C*4 (10W) German socket with USB/Type-C *4(10W) ¥:1140.00		SF-G1-0056 大板德式插座带USB/Type-C*5 (10W) German socket with USB/Type-C *5(10W) ¥:1425.00
	SF-G1-0057 大板法式插座带USB/Type-C*4 (10W) French socket with USB/Type-C *4(10W) ¥:1140.00		SF-G1-0058 大板法式插座带USB/Type-C*5 (10W) French socket with USB/Type-C *5(10W) ¥:1425.00







SF-G1钢化玻璃白色/Tempered glass white

	SF-G1-0059 一开单控开关 ¥:117.00 1 gang 1 way switch 一开双控开关 ¥:120.00 1 gang 2 way switch 一开多控开关 ¥:138.00 1 gang 3 way switch		SF-G1-0067 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:127.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:133.00		SF-G1-0075 13A方角插座 13A square corner socket ¥:117.00
	SF-G1-0060 一开单控复位开关 1 gang 1 way Reset switch ¥:122.00 一开双控复位开关 1 gang 2 way Reset switch ¥:125.00		SF-G1-0068 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:137.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:143.00		SF-G1-0076 德式插座 German socket ¥:117.00
	SF-G1-0061 二开单控开关 ¥:127.00 2 gang 1 way switch 二开双控开关 ¥:133.00 2 gang 2 way switch		SF-G1-0069 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:137.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:146.00		SF-G1-0077 法式插座 French socket ¥:117.00
	SF-G1-0062 二开单控复位开关 2 gang 1 way Reset switch ¥:137.00 二开双控复位开关 2 gang 2 way Reset switch ¥:143.00		SF-G1-0070 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:152.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:161.00		SF-G1-0078 俄式插座 Russian socket ¥:117.00
	SF-G1-0063 三开单控开关 ¥:137.00 3 gang 1 way switch 三开双控开关 ¥:146.00 3 gang 2 way switch		SF-G1-0071 门铃开关(荧光) Doorbell switch(Fluorescent lamp) ¥:122.00		SF-G1-0079 德意式插座 German+Italian socket ¥:137.00
	SF-G1-0064 三开单复位开关 ¥:152.00 3 gang 1 way Reset switch 三开双复位开关 ¥:161.00 3 gang 2 way Reset switch		SF-G1-0072 门禁开关(荧光) Gating switch(Fluorescent lamp) ¥:122.00		SF-G1-0080 德式USB+Type-c German USB+Type-C ¥:277.00
	SF-G1-0065 一开单控开关(荧光) ¥:117.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:120.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:138.00 1 gang 3 way switch(Fluorescent lamp)		SF-G1-0073 百叶窗升降开关(荧光) louwer window lifter switch (Fluorescent lamp) ¥:137.00		SF-G1-0081 法式USB+Type-c French USB+Type-C ¥:277.00
	SF-G1-0066 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:122.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:125.00		SF-G1-0074 多功能插座 Universal socket ¥:117.00		SF-G1-0082 德式插座+二位USB 2 USB with German socket ¥:267.00

SF-G1钢化玻璃白色/Tempered glass white

	SF-G1-0083 法式插座+二位USB 2 USB with French socket ¥:267.00		SF-G1-0091 法式透明防溅插座 French transparent splash-proof socket ¥:141.00		SF-G1-0099 卫星插座 Satellite socket ¥:142.00
	SF-G1-0084 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:265.00		SF-G1-0092 德式插座+防水 German socket + Waterproof belt ¥:127.00		SF-G1-0100 二位卫星插座 Double Satellite socket ¥:162.00
	SF-G1-0085 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal) ¥:335.00		SF-G1-0093 法式插座+防水 French socket + Waterproof belt ¥:127.00		SF-G1-0101 电视卫星插座 Satellite and TV socket ¥:147.00
	SF-G1-0086 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:265.00		SF-G1-0094 电视插座 TV socket ¥:127.00		SF-G1-0102 电话卫星插座 ¥:147.00 Satellite and telephone socket 电脑卫星插座 ¥:152.00 Satellite and computer socket
	SF-G1-0087 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥:335.00		SF-G1-0095 电话插座 ¥:127.00 telephone socket 电脑插座 ¥:137.00 computer socket		SF-G1-0103 二位USB插座 Double USB socket ¥:247.00
	SF-G1-0088 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:265.00		SF-G1-0096 二位电视插座 Double TV socket ¥:137.00		SF-G1-0104 二位音响插座 Single audio socket ¥:147.00
	SF-G1-0089 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:265.00		SF-G1-0097 二位电话插座 ¥:137.00 Double telephone socket 二位电脑插座 ¥:147.00 Double computer socket 电话电脑插座 ¥:142.00 telephone+computer socket		SF-G1-0105 四位音响插座 Double audio socket ¥:167.00
	SF-G1-0090 德式透明防溅插座 German type transparent splash-proof socket ¥:141.00		SF-G1-0098 电视电话插座 ¥:137.00 TV + telephone socket 电视电脑插座 ¥:142.00 TV + computer socket		SF-G1-0106 紧急呼叫开关 Emergency call switch ¥:217.00

SF-G1钢化玻璃白色/Tempered glass white

	SF-G1-0107 调光开关300W Dimming 300W ¥:190.00 调光开关500W Dimming 500W ¥:230.00 调光开关1000W Dimming 1000W ¥:260.00 调光LED开关200W ¥:230.00 Dimming LED 200W		SF-G1-0115 凹型人体感应地脚灯 The human body induction footlights ¥:302.00		SF-G1-0121 121型二位德式插座(短连体) 121 Double German socket(short) ¥:141.00
	SF-G1-0108 调速开关300W ¥:190.00 Speed 300W 调速开关500W ¥:230.00 Speed 500W		SF-G1-0116 剃须插座 Shaving socket ¥:492.00		SF-G1-0122 121型二位法式插座(短连体) 121 Double French socket(short) ¥:141.00
	SF-G1-0109 调音开关 Tuning switch (fire) ¥:240.00		SF-G1-0117 空白面板 Blank plate ¥:98.00		SF-G1-0123 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:141.00
	SF-G1-0110 触摸延时开关 ¥:190.00 Touch delay switch 声光控延时开关 ¥:190.00 Sound-light controlled delay switch		SF-G1-0118 二位德式插座(单体) Double German socket(single) ¥:145.00		SF-G1-0124 一位连体边框 one face frame ¥:80.00
	SF-G1-0111 人体感应开关 Human body induction ¥:300.00		SF-G1-0119 二位法式插座(单体) Double French socket (single) ¥:145.00		SF-G1-0125 二位连体边框 Double face frame ¥:200.00
	SF-G1-0112 叮咚门铃 Ding dong doorbell ¥:230.00		SF-G1-0120 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:410.00		SF-G1-0126 三位连体边框 Three face frame ¥:280.00
	SF-G1-0113 插卡取电(机械式) ¥:292.00 Mechanical card for electricity 插卡取电(低频) ¥:422.00 Low frequency induction card for electricity 插卡取电(高频) ¥:552.00 High frequency induction card for electricity		SF-G1-0127 四位连体边框 four face frame ¥:360.00		
	SF-G1-0114 凹型地脚灯 The footlights ¥:202.00		SF-G1-0128 五位连体边框 five face frame ¥:440.00		

SF-G2

SERIES

钢化玻璃面板


Tempered glass panel



The high transparency and smooth texture of glass give switches and sockets a unique fashionable and modern feel. Whether it is a minimalist home decor or a luxurious European style, the glass-faced switch and socket can perfectly match it, adding a touch of refinement and elegance to the space.

SF-G2

钢化玻璃金色/Tempered glass gold



SF-G2-0129
20A红绿开关
20A Red and green switch
¥:185.00



SF-G2-0130
空白出线孔
Blank outlet hole
¥:98.00



SF-G2-0131
1/2 电视插座+白板
1/2 TV socket+blank panel
¥:132.00




SF-G2-0132
1/2 电话插座+白板
1/2 telephone socket+blank panel
¥:132.00



SF-G2-0133
1/2 电脑插座+白板
1/2 computer socket+blank panel
¥:142.00



SF-G2-0134
1/2 电脑插座六类+白板
1/2 Computer socket(Cat6)
+blank panel
¥:172.00




SF-G2-0135
1/2 卫星插座+白板
1/2 satellite socket+blank panel
¥:147.00




SF-G2-0136
1/2 HDMI+白板
1/2 HDMI+blank panel
¥:255.00



SF-G2-0137
1/2 USB+type-c10W+白板
1/2 USB+type-c10W+blank panel
¥:210.00



SF-G2-0138
1/2 白板+白板
blank panel+blank panel
¥:103.00



SF-G2-0139
1/2 双HDMI
1/2 Dual HDMI
¥:420.00



SF-G2-0140
1/2 电视+HDMI
1/2 TV socket+1/2 HDMI socket
¥:297.00




SF-G2-0141
1/2 电话+HDMI
1/2 telephone socket+1/2
HDMI socket
¥:297.00



SF-G2-0142
1/2 电脑插座+HDMI
1/2 computer socket+HDMI
¥:307.00



SF-G2-0143
1/2 电脑插座六类+HDMI
1/2 Computer socket(Cat6)+HDMI
¥:337.00



SF-G2-0144
1/2 卫星+HDMI
1/2 satellite socket+HDMI
¥:312.00



SF-G2-0145
1/2 USB/TYPE-C+HDMI
¥:375.00



SF-G2-0146
二位1/2 USB/TYPE-C
Double 1/2 USB/TYPE-C
¥:330.00



SF-G2-0147
1/2 电视+USB/TYPE-C
1/2 TV socket+1/2USB/TYPE-C
¥:252.00



SF-G2-0148
1/2 电话+USB/TYPE-C
1/2 telephone socket+
1/2 USB/TYPE-C
¥:252.00



SF-G2-0149
1/2 电脑+USB/TYPE-C
1/2 Computer socket+ USB/TYPE-C
¥:262.00













SF-G2-0150
1/2 电脑六类+USB/TYPE-C
1/2 Computer socket(Cat6)
+USB/TYPE-C
¥:292.00

















SF-G2-0151
1/2 卫星+USB/TYPE-C
1/2 satellite socket+USB/TYPE-C
¥:267.00










SF-G2钢化玻璃金色/Tempered glass gold

	SF-G2-0001 WiFi 触摸一位开关 WiFi Touch 1 gang switch ¥:360.00		SF-G2-0009 大板俄式插座 Russian socket ¥:135.00		SF-G2-0017 大板法式插座带2USB French socket with 2USB ¥:275.00
	SF-G2-0002 ZIGBEE 触摸一位开关 ZIGBEE Touch 1 gang switch ¥:430.00		SF-G2-0010 大板电视插座 TV socket ¥:145.00		SF-G2-0018 大板德式插座带USB/Type-C(10W) German socket with USB/Type-C(10W) ¥:285.00
	SF-G2-0003 WiFi触摸二位开关 WiFi Touch 2 gang switch ¥:410.00		SF-G2-0011 大板电话插座 ¥:145.00 telephone socket 大板电脑插座 ¥:155.00 computer socket		SF-G2-0019 大板德式插座带USB/Type-C(20W) German socket with USB/Type-C(20W) ¥:335.00
	SF-G2-0004 ZIGBEE触摸二位开关 ZIGBEE Touch 2 gang switch ¥:480.00		SF-G2-0012 大板电视电话插座 ¥:155.00 TV+ telephone socket 大板电视电脑插座 ¥:160.00 TV+computer socket		SF-G2-0020 大板法式插座带USB/Type-C(10W) French socket with USB/Type-C(10W) ¥:285.00
	SF-G2-0005 WiFi触摸三位开关 WiFi Touch 1 gang switch ¥:460.00		SF-G2-0013 大板电话电脑插座 telephone + computer socket ¥:160.00		SF-G2-0021 大板法式插座带USB/Type-C(20W) French socket with USB/Type-C(20W) ¥:335.00
	SF-G2-0006 ZIGBEE触摸三位开关 ZIGBEE Touch 3 gang switch ¥:530.00		SF-G2-0014 大板调光 300W Dimming 300W ¥:228.00		SF-G2-0022 121双联德式插座 Double German socket ¥:291.00
	SF-G2-0007 大板德式插座 German socket ¥:135.00		SF-G2-0015 大板调速 300W Speed 300W ¥:228.00		SF-G2-0023 121双联法式插座 Double French socket ¥:291.00
	SF-G2-0008 大板法式插座 French socket ¥:135.00		SF-G2-0016 大板德式插座带2USB German socket with 2USB ¥:275.00		SF-G2-0024 121双联俄式插座 Double Russian socket ¥:291.00








SF-G2钢化玻璃金色/Tempered glass gold

	SF-G2-0025 大板德式+德式插座 German+German socket ¥:270.00		SF-G2-0033 大板二位连体wifi触摸三开+法式插座 Two-position WiFi touch 3 switch + French socket ¥:595.00
	SF-G2-0026 大板法式+法式插座 French+French socket ¥:270.00		SF-G2-0034 大板德式插座带2USB*2 German socket with 2USB*2 ¥:550.00
	SF-G2-0027 大板俄式+俄式插座 Russian+Russian socket ¥:270.00		SF-G2-0035 大板法式插座带2USB*2 French socket with 2USB*2 ¥:550.00
	SF-G2-0028 大板二位连体WiFi触摸一开+德式插座 Two-position WiFi touch 1 switch + German socket ¥:495.00		SF-G2-0036 大板德式插座带USB/Type-C*2(10W) German socket with USB/Type-C*2(10W) ¥:570.00
	SF-G2-0029 大板二位连体WiFi触摸二开+德式插座 Two-position WiFi touch 2 switch + German socket ¥:545.00		SF-G2-0037 大板法式插座带USB/Type-C*2(10W) French socket with USB/Type-C*2(10W) ¥:570.00
	SF-G2-0030 大板二位连体WiFi触摸三开+德式插座 Two-position WiFi touch 3 switch + German socket ¥:595.00		SF-G2-0038 大板三位德式插座 Three-position German socket ¥:405.00
	SF-G2-0031 大板二位连体WiFi触摸一开+法式插座 Two-position WiFi touch 1 switch + French socket ¥:495.00		SF-G2-0039 大板三位法式插座 Three-position French socket ¥:405.00
	SF-G2-0032 大板二位连体WiFi触摸二开+法式插座 Two-position WiFi touch 2 switch + French socket ¥:545.00		SF-G2-0040 大板三位俄式插座 Three-position Russian socket ¥:405.00







SF-G2钢化玻璃金色/Tempered glass gold

	SF-G2-0041 大板德式插座带2USB*3 German socket with 2USB*3 ¥:825.00		SF-G2-0042 大板法式插座带2USB*3 French socket with 2USB*3 ¥:825.00
	SF-G2-0043 大板德式插座带USB/Type-C*3(10W) German socket with USB/Type-C*3(10W) ¥:855.00		SF-G2-0044 大板法式插座带USB/Type-C*3(10W) French socket with USB/Type-C*3(10W) ¥:855.00
	SF-G2-0045 大板四位德式插座 Four-position German socket ¥:540.00		SF-G2-0046 大板五位德式插座 Five-position German socket ¥:675.00
	SF-G2-0047 大板四位法式插座 Four-position French socket ¥:540.00		SF-G2-0048 大板五位法式插座 Five-position French socket ¥:675.00
	SF-G2-0049 大板四位俄式插座 Four-position Russian socket ¥:540.00		SF-G2-0050 大板五位俄式插座 Five-position Russian socket ¥:675.00
	SF-G2-0051 大板德式插座带2USB*4 German socket with 2USB*4 ¥:1100.00		SF-G2-0052 大板德式插座带2USB*5 German socket with 2USB*5 ¥:1375.00
	SF-G2-0053 大板法式插座带2USB*4 French socket with 2USB*4 ¥:1100.00		SF-G2-0054 大板法式插座带2USB*5 French socket with 2USB*5 ¥:1375.00
	SF-G2-0055 大板德式插座带USB/Type-C*4 (10W) German socket with USB/Type-C *4(10W) ¥:1140.00		SF-G2-0056 大板德式插座带USB/Type-C*5 (10W) German socket with USB/Type-C *5(10W) ¥:1425.00
	SF-G2-0057 大板法式插座带USB/Type-C*4 (10W) French socket with USB/Type-C *4(10W) ¥:1140.00		SF-G2-0058 大板法式插座带USB/Type-C*5 (10W) French socket with USB/Type-C *5(10W) ¥:1425.00







SF-G2钢化玻璃金色/Tempered glass gold

	SF-G2-0059 一开单控开关 ¥:117.00 1 gang 1 way switch 一开双控开关 ¥:120.00 1 gang 2 way switch 一开多控开关 ¥:138.00 1 gang 3 way switch		SF-G2-0067 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:127.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:133.00		SF-G2-0075 13A方角插座 13A square corner socket ¥:117.00
	SF-G2-0060 一开单控复位开关 1 gang 1 way Reset switch ¥:122.00 一开双控复位开关 1 gang 2 way Reset switch ¥:125.00		SF-G2-0068 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:137.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:143.00		SF-G2-0076 德式插座 German socket ¥:117.00
	SF-G2-0061 二开单控开关 ¥:127.00 2 gang 1 way switch 二开双控开关 ¥:133.00 2 gang 2 way switch		SF-G2-0069 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:137.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:146.00		SF-G2-0077 法式插座 French socket ¥:117.00
	SF-G2-0062 二开单控复位开关 2 gang 1 way Reset switch ¥:137.00 二开双控复位开关 2 gang 2 way Reset switch ¥:143.00		SF-G2-0070 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:152.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:161.00		SF-G2-0078 俄式插座 Russian socket ¥:117.00
	SF-G2-0063 三开单控开关 ¥:137.00 3 gang 1 way switch 三开双控开关 ¥:146.00 3 gang 2 way switch		SF-G2-0071 门铃开关(荧光) Doorbell switch(Fluorescent lamp) ¥:122.00		SF-G2-0079 德意式插座 German+Italian socket ¥:137.00
	SF-G2-0064 三开单复位开关 ¥:152.00 3 gang 1 way Reset switch 三开双复位开关 ¥:161.00 3 gang 2 way Reset switch		SF-G2-0072 门禁开关(荧光) Gating switch(Fluorescent lamp) ¥:122.00		SF-G2-0080 德式USB+Type-c German USB+Type-C ¥:277.00
	SF-G2-0065 一开单控开关(荧光) ¥:117.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:120.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:138.00 1 gang 3 way switch(Fluorescent lamp)		SF-G2-0073 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:137.00		SF-G2-0081 法式USB+Type-c French USB+Type-C ¥:277.00
	SF-G2-0066 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:122.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:125.00		SF-G2-0074 多功能插座 Universal socket ¥:117.00		SF-G2-0082 德式插座+二位USB 2 USB with German socket ¥:267.00

SF-G2钢化玻璃金色/Tempered glass gold

	SF-G2-0083 法式插座+二位USB 2 USB with French socket ¥:267.00		SF-G2-0091 法式透明防溅插座 French transparent splash-proof socket ¥:141.00		SF-G2-0099 卫星插座 Satellite socket ¥:142.00
	SF-G2-0084 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal)(10W) ¥:265.00		SF-G2-0092 德式插座+防水 German socket + Waterproof belt ¥:127.00		SF-G2-0100 二位卫星插座 Double Satellite socket ¥:162.00
	SF-G2-0085 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal)(20W) ¥:335.00		SF-G2-0093 法式插座+防水 French socket + Waterproof belt ¥:127.00		SF-G2-0101 电视卫星插座 Satellite and TV socket ¥:147.00
	SF-G2-0086 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(10W) ¥:265.00		SF-G2-0094 电视插座 TV socket ¥:127.00		SF-G2-0102 电话卫星插座 ¥:147.00 Satellite and telephone socket 电脑卫星插座 ¥:152.00 Satellite and computer socket
	SF-G2-0087 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(20W) ¥:335.00		SF-G2-0095 电话插座 ¥:127.00 telephone socket 电脑插座 ¥:137.00 computer socket		SF-G2-0103 二位USB插座 Double USB socket ¥:247.00
	SF-G2-0088 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:265.00		SF-G2-0096 二位电视插座 Double TV socket ¥:137.00		SF-G2-0104 二位音响插座 Single audio socket ¥:147.00
	SF-G2-0089 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:265.00		SF-G2-0097 二位电话插座 ¥:137.00 Double telephone socket 二位电脑插座 ¥:147.00 Double computer socket 电话电脑插座 ¥:142.00 telephone+computer socket		SF-G2-0105 四位音响插座 Double audio socket ¥:167.00
	SF-G2-0090 德式透明防溅插座 German type transparent splash-proof socket ¥:141.00		SF-G2-0098 电视电话插座 ¥:137.00 TV + telephone socket 电视电脑插座 ¥:142.00 TV + computer socket		SF-G2-0106 紧急呼叫开关 Emergency call switch ¥:217.00

SF-G2钢化玻璃金色/Tempered glass gold


	SF-G2-0107 调光开关300W Dimming 300W ¥:190.00 调光开关500W Dimming 500W ¥:230.00 调光开关1000W Dimming 1000W ¥:260.00 调光LED开关200W ¥:230.00 Dimming LED 200W		SF-G2-0115 凹型人体感应地脚灯 The human body induction footlights ¥:302.00		SF-G2-0121 121型二位德式插座(短连体) 121 Double German socket(short) ¥:141.00
	SF-G2-0108 调速开关300W ¥:190.00 Speed 300W 调速开关500W ¥:230.00 Speed 500W		SF-G2-0116 剃须插座 Shaving socket ¥:492.00		SF-G2-0122 121型二位法式插座(短连体) 121 Double French socket(short) ¥:141.00
	SF-G2-0109 调音开关 Tuning switch (fire) ¥:240.00		SF-G2-0117 空白面板 Blank plate ¥:98.00		SF-G2-0123 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:141.00
	SF-G2-0110 触摸延时开关 ¥:190.00 Touch delay switch 声光控延时开关 ¥:190.00 Sound-light controlled delay switch		SF-G2-0118 二位德式插座(单体) Double German socket(single) ¥:145.00		SF-G2-0124 一位连体边框 one face frame ¥:80.00
	SF-G2-0111 人体感应开关 Human body induction ¥:300.00		SF-G2-0119 二位法式插座(单体) Double French socket (single) ¥:145.00		SF-G2-0125 二位连体边框 Double face frame ¥:200.00
	SF-G2-0112 叮咚门铃 Ding dong doorbell ¥:230.00		SF-G2-0120 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:410.00		SF-G2-0126 三位连体边框 Three face frame ¥:280.00
	SF-G2-0113 插卡取电(机械式) ¥:292.00 Mechanical card for electricity 插卡取电(低频) ¥:422.00 Low frequency induction card for electricity 插卡取电(高频) ¥:552.00 High frequency induction card for electricity		SF-G2-0127 四位连体边框 four face frame ¥:360.00		
	SF-G2-0114 凹型地脚灯 The footlights ¥:202.00		SF-G2-0128 五位连体边框 five face frame ¥:440.00		

SF-G3

SERIES

钢化玻璃面板

Tempered glass panel



The high transparency and smooth texture of glass give switches and sockets a unique fashionable and modern feel. Whether it is a minimalist home decor or a luxurious European style, the glass-faced switch and socket can perfectly match it, adding a touch of refinement and elegance to the space.

SF-G3

钢化玻璃黑色/Tempered glass black



SF-G3-0129
20A红绿开关
20A Red and green switch
¥:185.00



SF-G3-0137
1/2 USB+type-c10W+白板
1/2 USB+type-c10W+blank panel
¥:210.00



SF-G3-0145
1/2 USB/TYPE-C+HDMI
¥:375.00



SF-G3-0130
空白出线孔
Blank outlet hole
¥:98.00



SF-G3-0138
1/2 白板+白板
blank panel+blank panel
¥:103.00



SF-G3-0146
二位1/2 USB/TYPE-C
Double 1/2 USB/TYPE-C
¥:330.00



SF-G3-0131
1/2 电视插座+白板
1/2 TV socket+blank panel
¥:132.00



SF-G3-0139
1/2 双HDMI
1/2 Dual HDMI
¥:420.00



SF-G3-0147
1/2 电视+USB/TYPE-C
1/2 TV socket+1/2USB/TYPE-C
¥:252.00



SF-G3-0132
1/2 电话插座+白板
1/2 telephone socket+blank panel
¥:132.00



SF-G3-0140
1/2 电视+HDMI
1/2 TV socket+1/2 HDMI socket
¥:297.00



SF-G3-0148
1/2 电话+USB/TYPE-C
1/2 telephone socket+
1/2 USB/TYPE-C
¥:252.00



SF-G3-0133
1/2 电脑插座+白板
1/2 computer socket+blank panel
¥:142.00



SF-G3-0141
1/2 电话+HDMI
1/2 telephone socket+1/2
HDMI socket
¥:297.00



SF-G3-0149
1/2 电脑+USB/TYPE-C
1/2 Computer socket+ USB/TYPE-C
¥:262.00



SF-G3-0134
1/2 电脑插座六类+白板
1/2 Computer socket(Cat6)
+blank panel
¥:172.00



SF-G3-0142
1/2 电脑插座+HDMI
1/2 computer socket+HDMI
¥:307.00



SF-G3-0150
1/2 电脑六类+USB/TYPE-C
1/2 Computer socket(Cat6)
+USB/TYPE-C
¥:292.00



SF-G3-0135
1/2 卫星插座+白板
1/2 satellite socket+blank panel
¥:147.00



SF-G3-0143
1/2 电脑插座六类+HDMI
1/2 Computer socket(Cat6)+HDMI
¥:337.00



SF-G3-0151
1/2 卫星+USB/TYPE-C
1/2 satellite socket+USB/TYPE-C
¥:267.00
















SF-G3-0136
1/2 HDMI+白板
1/2 HDMI+blank panel
¥:255.00














SF-G3-0144
1/2 卫星+HDMI
1/2 satellite socket+HDMI
¥:312.00

SF-G3钢化玻璃黑色/Tempered glass black

	SF-G3-0001 WiFi 触摸一位开关 WiFi Touch 1 gang switch ¥:360.00		SF-G3-0009 大板俄式插座 Russian socket ¥:135.00		SF-G3-0017 大板法式插座带2USB French socket with 2USB ¥:275.00
	SF-G3-0002 ZIGBEE 触摸一位开关 ZIGBEE Touch 1 gang switch ¥:430.00		SF-G3-0010 大板电视插座 TV socket ¥:145.00		SF-G3-0018 大板德式插座带USB/Type-C(10W) German socket with USB/Type-C(10W) ¥:285.00
	SF-G3-0003 WiFi触摸二位开关 WiFi Touch 2 gang switch ¥:410.00		SF-G3-0011 大板电话插座 ¥:145.00 telephone socket 大板电脑插座 ¥:155.00 computer socket		SF-G3-0019 大板德式插座带USB/Type-C(20W) German socket with USB/Type-C(20W) ¥:335.00
	SF-G3-0004 ZIGBEE触摸二位开关 ZIGBEE Touch 2 gang switch ¥:480.00		SF-G3-0012 大板电视电话插座 ¥:155.00 TV+ telephone socket 大板电视电脑插座 ¥:160.00 TV+computer socket		SF-G3-0020 大板法式插座带USB/Type-C(10W) French socket with USB/Type-C(10W) ¥:285.00
	SF-G3-0005 WiFi触摸三位开关 WiFi Touch 3 gang switch ¥:460.00		SF-G3-0013 大板电话电脑插座 telephone + computer socket ¥:160.00		SF-G3-0021 大板法式插座带USB/Type-C(20W) French socket with USB/Type-C(20W) ¥:335.00
	SF-G3-0006 ZIGBEE触摸三位开关 ZIGBEE Touch 3 gang switch ¥:530.00		SF-G3-0014 大板调光 300W Dimming 300W ¥:228.00		SF-G3-0022 121双联德式插座 Double German socket ¥:291.00
	SF-G3-0007 大板德式插座 German socket ¥:135.00		SF-G3-0015 大板调速 300W Speed 300W ¥:228.00		SF-G3-0023 121双联法式插座 Double French socket ¥:291.00
	SF-G3-0008 大板法式插座 French socket ¥:135.00		SF-G3-0016 大板德式插座带2USB German socket with 2USB ¥:275.00		SF-G3-0024 121双联俄式插座 Double Russian socket ¥:291.00


SF-G3钢化玻璃黑色/Tempered glass black

	SF-G3-0025 大板德式+德式插座 German+German socket ¥:270.00		SF-G3-0033 大板二位连体wifi触摸三开+法式插座 Two-position WiFi touch 3 switch + French socket ¥:595.00
	SF-G3-0026 大板法式+法式插座 French+French socket ¥:270.00		SF-G3-0034 大板德式插座带2USB*2 German socket with 2USB*2 ¥:550.00
	SF-G3-0027 大板俄式+俄式插座 Russian+Russian socket ¥:270.00		SF-G3-0035 大板法式插座带2USB*2 French socket with 2USB*2 ¥:550.00
	SF-G3-0028 大板二位连体WiFi触摸一开+德式插座 Two-position WiFi touch 1 switch + German socket ¥:495.00		SF-G3-0036 大板德式插座带USB/Type-C*2(10W) German socket with USB/Type-C*2(10W) ¥:570.00
	SF-G3-0029 大板二位连体WiFi触摸二开+德式插座 Two-position WiFi touch 2 switch + German socket ¥:545.00		SF-G3-0037 大板法式插座带USB/Type-C*2(10W) French socket with USB/Type-C*2(10W) ¥:570.00
	SF-G3-0030 大板二位连体WiFi触摸三开+德式插座 Two-position WiFi touch 3 switch + German socket ¥:595.00		SF-G3-0038 大板三位德式插座 Three-position German socket ¥:405.00
	SF-G3-0031 大板二位连体WiFi触摸一开+法式插座 Two-position WiFi touch 1 switch + French socket ¥:495.00		SF-G3-0039 大板三位法式插座 Three-position French socket ¥:405.00
	SF-G3-0032 大板二位连体WiFi触摸二开+法式插座 Two-position WiFi touch 2 switch + French socket ¥:545.00		SF-G3-0040 大板三位俄式插座 Three-position Russian socket ¥:405.00


SF-G3钢化玻璃黑色/Tempered glass black




SF-G3-0041
大板德式插座带2USB*3
German socket with 2USB*3
¥:825.00




SF-G3-0042
大板法式插座带2USB*3
French socket with 2USB*3
¥:825.00




SF-G3-0043
大板德式插座带USB/Type-C*3(10W)
German socket with USB/Type-C*3(10W)
¥:855.00




SF-G3-0044
大板法式插座带USB/Type-C*3(10W)
French socket with USB/Type-C*3(10W)
¥:855.00




SF-G3-0045
大板四位德式插座
Four-position German socket
¥:540.00




SF-G3-0046
大板五位德式插座
Five-position German socket
¥:675.00




SF-G3-0047
大板四位法式插座
Four-position French socket
¥:540.00




SF-G3-0048
大板五位法式插座
Five-position French socket
¥:675.00



SF-G3-0049
大板四位俄式插座
Four-position Russian socket
¥:540.00




SF-G3-0050
大板五位俄式插座
Five-position Russian socket
¥:675.00




SF-G3-0051
大板德式插座带2USB*4
German socket with 2USB*4
¥:1100.00




SF-G3-0052
大板德式插座带2USB*5
German socket with 2USB*5
¥:1375.00




SF-G3-0053
大板法式插座带2USB*4
French socket with 2USB*4
¥:1100.00




SF-G3-0054
大板法式插座带2USB*5
French socket with 2USB*5
¥:1375.00




SF-G3-0055
大板德式插座带USB/Type-C*4
(10W)
German socket with USB/Type-C
*4(10W)
¥:1140.00



SF-G3-0056
大板德式插座带USB/Type-C*5
(10W)
German socket with USB/Type-C
*5(10W)
¥:1425.00



SF-G3-0057
大板法式插座带USB/Type-C*4
(10W)
French socket with USB/Type-C
*4(10W)
¥:1140.00



SF-G3-0058
大板法式插座带USB/Type-C*5
(10W)
French socket with USB/Type-C
*5(10W)
¥:1425.00

SF-G3钢化玻璃黑色/Tempered glass black



SF-G3-0059
一开单控开关 ¥:117.00
1 gang 1 way switch
一开双控开关 ¥:120.00
1 gang 2 way switch
一开多控开关 ¥:138.00
1 gang 3 way switch



SF-G3-0067
二开单控开关(荧光)
2 gang 1 way switch
(Fluorescent lamp)
¥:127.00
二开双控开关(荧光)
2 gang 2 way switch
(Fluorescent lamp)
¥:133.00




SF-G3-0075
13A方角插座
13A square corner socket
¥:117.00



SF-G3-0060
一开单控复位开关
1 gang 1 way Reset switch
¥:122.00
一开双控复位开关
1 gang 2 way Reset switch
¥:125.00



SF-G3-0068
二开单控复位开关(荧光)
2 gang 1 way Reset switch
(Fluorescent lamp)
¥:137.00
二开双控复位开关(荧光)
2 gang 2 way Reset switch
(Fluorescent lamp)
¥:143.00



SF-G3-0076
德式插座
German socket
¥:117.00



SF-G3-0061
二开单控开关 ¥:127.00
2 gang 1 way switch
二开双控开关 ¥:133.00
2 gang 2 way switch



SF-G3-0069
三开单控开关(荧光)
3 gang 1 way switch
(Fluorescent lamp)
¥:137.00
三开双控开关(荧光)
3 gang 2 way switch
(Fluorescent lamp)
¥:146.00



SF-G3-0077
法式插座
French socket
¥:117.00



SF-G3-0062
二开单控复位开关
2 gang 1 way Reset switch
¥:137.00
二开双控复位开关
2 gang 2 way Reset switch
¥:143.00



SF-G3-0070
三开单复位开关(荧光)
3 gang 1 way Reset switch
(Fluorescent lamp)
¥:152.00
三开双复位开关(荧光)
3 gang 2 way Reset switch
(Fluorescent lamp)
¥:161.00




SF-G3-0078
俄式插座
Russian socket
¥:117.00



SF-G3-0063
三开单控开关 ¥:137.00
3 gang 1 way switch
三开双控开关 ¥:146.00
3 gang 2 way switch



SF-G3-0071
门铃开关(荧光)
Doorbell switch(Fluorescent lamp)
¥:122.00



SF-G3-0079
德意式插座
German+Italian socket
¥:137.00



SF-G3-0064
三开单复位开关 ¥:152.00
3 gang 1 way Reset switch
三开双复位开关 ¥:161.00
3 gang 2 way Reset switch



SF-G3-0072
门禁开关(荧光)
Gating switch(Fluorescent lamp)
¥:122.00



SF-G3-0080
德式USB+Type-c
German USB+Type-C
¥:277.00



SF-G3-0065
一开单控开关(荧光) ¥:117.00
1 gang 1 way switch(Fluorescent lamp)
一开双控开关(荧光) ¥:120.00
1 gang 2 way switch(Fluorescent lamp)
一开多控开关(荧光) ¥:138.00
1 gang 3 way switch(Fluorescent lamp)



SF-G3-0073
百叶窗升降开关(荧光)
louwer window lifter switch
(Fluorescent lamp)
¥:137.00



SF-G3-0081
法式USB+Type-c
French USB+Type-C
¥:277.00



SF-G3-0066
一开单控复位开关(荧光)
1 gang 1 way Reset switch
(Fluorescent lamp)
¥:122.00
一开双控复位开关(荧光)
1 gang 2 way Reset switch
(Fluorescent lamp)
¥:125.00





SF-G3-0074
多功能插座
Universal socket
¥:117.00






SF-G3-0082
德式插座+二位USB
2 USB with German socket
¥:267.00

SF-G3钢化玻璃黑色/Tempered glass black

	SF-G3-0083 法式插座+二位USB 2 USB with French socket ¥:267.00		SF-G3-0091 法式透明防溅插座 French transparent splash-proof socket ¥:141.00		SF-G3-0099 卫星插座 Satellite socket ¥:142.00
	SF-G3-0084 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal)(10W) ¥:265.00		SF-G3-0092 德式插座+防水 German socket + Waterproof belt ¥:127.00		SF-G3-0100 二位卫星插座 Double Satellite socket ¥:162.00
	SF-G3-0085 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal)(20W) ¥:335.00		SF-G3-0093 法式插座+防水 French socket + Waterproof belt ¥:127.00		SF-G3-0101 电视卫星插座 Satellite and TV socket ¥:147.00
	SF-G3-0086 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(10W) ¥:265.00		SF-G3-0094 电视插座 TV socket ¥:127.00		SF-G3-0102 电话卫星插座 Satellite and telephone socket ¥:147.00 电脑卫星插座 Satellite and computer socket ¥:152.00
	SF-G3-0087 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(20W) ¥:335.00		SF-G3-0095 电话插座 telephone socket ¥:127.00 电脑插座 computer socket ¥:137.00		SF-G3-0103 二位USB插座 Double USB socket ¥:247.00
	SF-G3-0088 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:265.00		SF-G3-0096 二位电视插座 Double TV socket ¥:137.00		SF-G3-0104 二位音响插座 Single audio socket ¥:147.00
	SF-G3-0089 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:265.00		SF-G3-0097 二位电话插座 Double telephone socket ¥:137.00 二位电脑插座 Double computer socket ¥:147.00 电话电脑插座 telephone+computer socket ¥:142.00		SF-G3-0105 四位音响插座 Double audio socket ¥:167.00
	SF-G3-0090 德式透明防溅插座 German type transparent splash-proof socket ¥:141.00		SF-G3-0098 电视电话插座 TV + telephone socket ¥:137.00 电视电脑插座 TV + computer socket ¥:142.00		SF-G3-0106 紧急呼叫开关 Emergency call switch ¥:217.00


SF-G3钢化玻璃黑色/Tempered glass black

	SF-G3-0107 调光开关300W Dimming 300W ¥:190.00 调光开关500W Dimming 500W ¥:230.00 调光开关1000W Dimming 1000W ¥:260.00 调光LED开关200W Dimming LED 200W ¥:230.00		SF-G3-0115 凹型人体感应地脚灯 The human body induction footlights ¥:302.00		SF-G3-0121 121型二位德式插座(短连体) 121 Double German socket(short) ¥:141.00
	SF-G3-0108 调速开关300W Speed 300W ¥:190.00 调速开关500W Speed 500W ¥:230.00		SF-G3-0116 剃须插座 Shaving socket ¥:492.00		SF-G3-0122 121型二位法式插座(短连体) 121 Double French socket(short) ¥:141.00
	SF-G3-0109 调音开关 Tuning switch (fire) ¥:240.00		SF-G3-0117 空白面板 Blank plate ¥:98.00		SF-G3-0123 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:141.00
	SF-G3-0110 触摸延时开关 Touch delay switch ¥:190.00 声光控延时开关 Sound-light controlled delay switch ¥:190.00		SF-G3-0118 二位德式插座(单体) Double German socket(single) ¥:145.00		SF-G3-0124 一位连体边框 one face frame ¥:80.00
	SF-G3-0111 人体感应开关 Human body induction ¥:300.00		SF-G3-0119 二位法式插座(单体) Double French socket (single) ¥:145.00		SF-G3-0125 二位连体边框 Double face frame ¥:200.00
	SF-G3-0112 叮咚门铃 Ding dong doorbell ¥:230.00		SF-G3-0120 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:410.00		SF-G3-0126 三位连体边框 Three face frame ¥:280.00
	SF-G3-0113 插卡取电(机械式) Mechanical card for electricity ¥:292.00 插卡取电(低频) Low frequency induction card for electricity ¥:422.00 插卡取电(高频) High frequency induction card for electricity ¥:552.00		SF-G3-0127 四位连体边框 four face frame ¥:360.00		
	SF-G3-0114 凹型地脚灯 The footlights ¥:202.00		SF-G3-0128 五位连体边框 five face frame ¥:440.00		

SF-G4

SERIES

钢化玻璃面板
Tempered glass panel























The high transparency and smooth texture of glass give switches and sockets a unique fashionable and modern feel.

Whether it is a minimalist home decor or a luxurious European style, the glass-faced switch and socket can perfectly match it, adding a touch of refinement and elegance to the space.

















SF-G4钢化玻璃灰色/Tempered glass grey

	SF-G4-0129 20A红绿开关 20A Red and green switch ¥:185.00		SF-G4-0137 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:210.00		SF-G4-0145 1/2 USB/TYPE-C+HDMI ¥:375.00
	SF-G4-0130 空白出线孔 Blank outlet hole ¥:98.00		SF-G4-0138 1/2 白板+白板 blank panel+blank panel ¥:103.00		SF-G4-0146 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:330.00
	SF-G4-0131 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:132.00		SF-G4-0139 1/2 双HDMI 1/2 Dual HDMI ¥:420.00		SF-G4-0147 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:252.00
	SF-G4-0132 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:132.00		SF-G4-0140 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:297.00		SF-G4-0148 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:252.00
	SF-G4-0133 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:142.00		SF-G4-0141 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:297.00		SF-G4-0149 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:262.00
	SF-G4-0134 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:172.00		SF-G4-0142 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:307.00		SF-G4-0150 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:292.00
	SF-G4-0135 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:147.00		SF-G4-0143 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:337.00		SF-G4-0151 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:267.00
	SF-G4-0136 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:255.00		SF-G4-0144 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:312.00		



















SF-G4钢化玻璃灰色/Tempered glass grey

	SF-G4-0001 WiFi 触摸一位开关 WiFi Touch 1 gang switch ¥:360.00		SF-G4-0009 大板俄式插座 Russian socket ¥:135.00		SF-G4-0017 大板法式插座带2USB French socket with 2USB ¥:275.00
	SF-G4-0002 ZIGBEE 触摸一位开关 ZIGBEE Touch 1 gang switch ¥:430.00		SF-G4-0010 大板电视插座 TV socket ¥:145.00		SF-G4-0018 大板德式插座带USB/Type-C(10W) German socket with USB/Type-C(10W) ¥:285.00
	SF-G4-0003 WiFi触摸二位开关 WiFi Touch 2 gang switch ¥:410.00		SF-G4-0011 大板电话插座 ¥:145.00 telephone socket 大板电脑插座 ¥:155.00 computer socket		SF-G4-0019 大板德式插座带USB/Type-C(20W) German socket with USB/Type-C(20W) ¥:335.00
	SF-G4-0004 ZIGBEE触摸二位开关 ZIGBEE Touch 2 gang switch ¥:480.00		SF-G4-0012 大板电视电话插座 ¥:155.00 TV+ telephone socket 大板电视电脑插座 ¥:160.00 TV+computer socket		SF-G4-0020 大板法式插座带USB/Type-C(10W) French socket with USB/Type-C(10W) ¥:285.00
	SF-G4-0005 WiFi触摸三位开关 WiFi Touch 1 gang switch ¥:460.00		SF-G4-0013 大板电话电脑插座 telephone + computer socket ¥:160.00		SF-G4-0021 大板法式插座带USB/Type-C(20W) French socket with USB/Type-C(20W) ¥:335.00
	SF-G4-0006 ZIGBEE触摸三位开关 ZIGBEE Touch 3 gang switch ¥:530.00		SF-G4-0014 大板调光 300W Dimming 300W ¥:228.00		SF-G4-0022 121双联德式插座 Double German socket ¥:291.00
	SF-G4-0007 大板德式插座 German socket ¥:135.00		SF-G4-0015 大板调速 300W Speed 300W ¥:228.00		SF-G4-0023 121双联法式插座 Double French socket ¥:291.00
	SF-G4-0008 大板法式插座 French socket ¥:135.00		SF-G4-0016 大板德式插座带2USB German socket with 2USB ¥:275.00		SF-G4-0024 121双联俄式插座 Double Russian socket ¥:291.00










SF-G4钢化玻璃灰色/Tempered glass grey

	SF-G4-0025 大板德式+德式插座 German+German socket ¥:270.00		SF-G4-0033 大板二位连体wifi触摸三开+法式插座 Two-position WiFi touch 3 switch + French socket ¥:595.00
	SF-G4-0026 大板法式+法式插座 French+French socket ¥:270.00		SF-G4-0034 大板德式插座带2USB*2 German socket with 2USB*2 ¥:550.00
	SF-G4-0027 大板俄式+俄式插座 Russian+Russian socket ¥:270.00		SF-G4-0035 大板法式插座带2USB*2 French socket with 2USB*2 ¥:550.00
	SF-G4-0028 大板二位连体WiFi触摸一开+德式插座 Two-position WiFi touch 1 switch + German socket ¥:495.00		SF-G4-0036 大板德式插座带USB/Type-C*2(10W) German socket with USB/Type-C*2(10W) ¥:570.00
	SF-G4-0029 大板二位连体WiFi触摸二开+德式插座 Two-position WiFi touch 2 switch + German socket ¥:545.00		SF-G4-0037 大板法式插座带USB/Type-C*2(10W) French socket with USB/Type-C*2(10W) ¥:570.00
	SF-G4-0030 大板二位连体WiFi触摸三开+德式插座 Two-position WiFi touch 3 switch + German socket ¥:595.00		SF-G4-0038 大板三位德式插座 Three-position German socket ¥:405.00
	SF-G4-0031 大板二位连体WiFi触摸一开+法式插座 Two-position WiFi touch 1 switch + French socket ¥:495.00		SF-G4-0039 大板三位法式插座 Three-position French socket ¥:405.00
	SF-G4-0032 大板二位连体WiFi触摸二开+法式插座 Two-position WiFi touch 2 switch + French socket ¥:545.00		SF-G4-0040 大板三位俄式插座 Three-position Russian socket ¥:405.00









SF-G4钢化玻璃灰色/Tempered glass grey

	SF-G4-0041 大板德式插座带2USB*3 German socket with 2USB*3 ¥:825.00		SF-G4-0042 大板法式插座带2USB*3 French socket with 2USB*3 ¥:825.00
	SF-G4-0043 大板德式插座带USB/Type-C*3(10W) German socket with USB/Type-C*3(10W) ¥:855.00		SF-G4-0044 大板法式插座带USB/Type-C*3(10W) French socket with USB/Type-C*3(10W) ¥:855.00
	SF-G4-0045 大板四位德式插座 Four-position German socket ¥:540.00		SF-G4-0046 大板五位德式插座 Five-position German socket ¥:675.00
	SF-G4-0047 大板四位法式插座 Four-position French socket ¥:540.00		SF-G4-0048 大板五位法式插座 Five-position French socket ¥:675.00
	SF-G4-0049 大板四位俄式插座 Four-position Russian socket ¥:540.00		SF-G4-0050 大板五位俄式插座 Five-position Russian socket ¥:675.00
	SF-G4-0051 大板德式插座带2USB*4 German socket with 2USB*4 ¥:1100.00		SF-G4-0052 大板德式插座带2USB*5 German socket with 2USB*5 ¥:1375.00
	SF-G4-0053 大板法式插座带2USB*4 French socket with 2USB*4 ¥:1100.00		SF-G4-0054 大板法式插座带2USB*5 French socket with 2USB*5 ¥:1375.00
	SF-G4-0055 大板德式插座带USB/Type-C*4 (10W) German socket with USB/Type-C *4(10W) ¥:1140.00		SF-G4-0056 大板德式插座带USB/Type-C*5 (10W) German socket with USB/Type-C *5(10W) ¥:1425.00
	SF-G4-0057 大板法式插座带USB/Type-C*4 (10W) French socket with USB/Type-C *4(10W) ¥:1140.00		SF-G4-0058 大板法式插座带USB/Type-C*5 (10W) French socket with USB/Type-C *5(10W) ¥:1425.00
















SF-G4钢化玻璃灰色/Tempered glass grey

	SF-G4-0059 一开单控开关 ¥:117.00 1 gang 1 way switch 一开双控开关 ¥:120.00 1 gang 2 way switch 一开多控开关 ¥:138.00 1 gang 3 way switch		SF-G4-0067 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:127.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:133.00		SF-G4-0075 13A方角插座 13A square corner socket ¥:117.00
	SF-G4-0060 一开单控复位开关 1 gang 1 way Reset switch ¥:122.00 一开双控复位开关 1 gang 2 way Reset switch ¥:125.00		SF-G4-0068 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:137.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:143.00		SF-G4-0076 德式插座 German socket ¥:117.00
	SF-G4-0061 二开单控开关 ¥:127.00 2 gang 1 way switch 二开双控开关 ¥:133.00 2 gang 2 way switch		SF-G4-0069 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:137.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:146.00		SF-G4-0077 法式插座 French socket ¥:117.00
	SF-G4-0062 二开单控复位开关 2 gang 1 way Reset switch ¥:137.00 二开双控复位开关 2 gang 2 way Reset switch ¥:143.00		SF-G4-0070 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:152.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:161.00		SF-G4-0078 俄式插座 Russian socket ¥:117.00
	SF-G4-0063 三开单控开关 ¥:137.00 3 gang 1 way switch 三开双控开关 ¥:146.00 3 gang 2 way switch		SF-G4-0071 门铃开关(荧光) Doorbell switch(Fluorescent lamp) ¥:122.00		SF-G4-0079 德意式插座 German+Italian socket ¥:137.00
	SF-G4-0064 三开单复位开关 ¥:152.00 3 gang 1 way Reset switch 三开双复位开关 ¥:161.00 3 gang 2 way Reset switch		SF-G4-0072 门禁开关(荧光) Gating switch(Fluorescent lamp) ¥:122.00		SF-G4-0080 德式USB+Type-c German USB+Type-C ¥:277.00
	SF-G4-0065 一开单控开关(荧光) ¥:117.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:120.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:138.00 1 gang 3 way switch(Fluorescent lamp)		SF-G4-0073 百叶窗升降开关(荧光) louwer window lifter switch (Fluorescent lamp) ¥:137.00		SF-G4-0081 法式USB+Type-c French USB+Type-C ¥:277.00
	SF-G4-0066 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:122.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:125.00		SF-G4-0074 多功能插座 Universal socket ¥:117.00		SF-G4-0082 德式插座+二位USB 2 USB with German socket ¥:267.00

SF-G4钢化玻璃灰色/Tempered glass grey

	SF-G4-0083 法式插座+二位USB 2 USB with French socket ¥:267.00		SF-G4-0091 法式透明防溅插座 French transparent splash-proof socket ¥:141.00		SF-G4-0099 卫星插座 Satellite socket ¥:142.00
	SF-G4-0084 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal)(10W) ¥:265.00		SF-G4-0092 德式插座+防水 German socket + Waterproof belt ¥:127.00		SF-G4-0100 二位卫星插座 Double Satellite socket ¥:162.00
	SF-G4-0085 德式插座USB+Type-C(横) German socket USB+Type-C (horizontal) ¥:335.00		SF-G4-0093 法式插座+防水 French socket + Waterproof belt ¥:127.00		SF-G4-0101 电视卫星插座 Satellite and TV socket ¥:147.00
	SF-G4-0086 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(10W) ¥:265.00		SF-G4-0094 电视插座 TV socket ¥:127.00		SF-G4-0102 电话卫星插座 ¥:147.00 Satellite and telephone socket 电脑卫星插座 ¥:152.00 Satellite and computer socket
	SF-G4-0087 法式插座USB+Type-C(横) French socket USB+Type-C (horizontal)(20W) ¥:335.00		SF-G4-0095 电话插座 ¥:127.00 telephone socket 电脑插座 ¥:137.00 computer socket		SF-G4-0103 二位USB插座 Double USB socket ¥:247.00
	SF-G4-0088 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:265.00		SF-G4-0096 二位电视插座 Double TV socket ¥:137.00		SF-G4-0104 二位音响插座 Single audio socket ¥:147.00
	SF-G4-0089 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:265.00		SF-G4-0097 二位电话插座 ¥:137.00 Double telephone socket 二位电脑插座 ¥:147.00 Double computer socket 电话电脑插座 ¥:142.00 telephone+computer socket		SF-G4-0105 四位音响插座 Double audio socket ¥:167.00
	SF-G4-0090 德式透明防溅插座 German type transparent splash-proof socket ¥:141.00		SF-G4-0098 电视电话插座 ¥:137.00 TV + telephone socket 电视电脑插座 ¥:142.00 TV + computer socket		SF-G4-0106 紧急呼叫开关 Emergency call switch ¥:217.00

SF-G4钢化玻璃灰色/Tempered glass grey

	SF-G4-0107 调光开关300W ¥:190.00 Dimming 300W 调光开关500W ¥:230.00 Dimming 500W 调光开关1000W ¥:260.00 Dimming 1000W 调光LED开关200W ¥:230.00 Dimming LED 200W		SF-G4-0115 凹型人体感应地脚灯 The human body induction footlights ¥:302.00		SF-G4-0121 121型二位德式插座(短连体) 121 Double German socket(short) ¥:141.00
	SF-G4-0108 调速开关300W ¥:190.00 Speed 300W 调速开关500W ¥:230.00 Speed 500W		SF-G4-0116 剃须插座 Shaving socket ¥:492.00		SF-G4-0122 121型二位法式插座(短连体) 121 Double French socket(short) ¥:141.00
	SF-G4-0109 调音开关 Tuning switch (fire) ¥:240.00		SF-G4-0117 空白面板 Blank plate ¥:98.00		SF-G4-0123 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:141.00
	SF-G4-0110 触摸延时开关 ¥:190.00 Touch delay switch 声光控延时开关 ¥:190.00 Sound-light controlled delay switch		SF-G4-0118 二位德式插座(单体) Double German socket(single) ¥:145.00		SF-G4-0124 一位连体边框 one face frame ¥:80.00
	SF-G4-0111 人体感应开关 Human body induction ¥:300.00		SF-G4-0119 二位法式插座(单体) Double French socket (single) ¥:145.00		SF-G4-0125 二位连体边框 Double face frame ¥:200.00
	SF-G4-0112 叮咚门铃 Ding dong doorbell ¥:230.00		SF-G4-0120 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:410.00		SF-G4-0126 三位连体边框 Three face frame ¥:280.00
	SF-G4-0113 插卡取电(机械式) ¥:292.00 Mechanical card for electricity 插卡取电(低频) ¥:422.00 Low frequency induction card for electricity 插卡取电(高频) ¥:552.00 High frequency induction card for electricity		SF-G4-0127 四位连体边框 four face frame ¥:360.00		
	SF-G4-0114 凹型地脚灯 The footlights ¥:202.00		SF-G4-0128 五位连体边框 five face frame ¥:440.00		

SF-K1


SERIES

PC面板 PC panel







Simple panel design, not carved but exudes a unique charm,
highlighting the extraordinary style.







简约的面板设计，不事雕琢却散发着独特的魅力，彰显出非凡的格调。






SF-K1 PC白色/PC white

	SF-K1-0070 20A红绿开关 20A Red and green switch ¥:107.00		SF-K1-0078 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:137.00		SF-K1-0086 1/2 USB/TYPE-C+HDMI ¥:297.00
	SF-K1-0071 空白出线孔 Blank outlet hole ¥:26.00		SF-K1-0079 1/2 白板+白板 blank panel+blank panel ¥:31.00		SF-K1-0087 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:252.00
	SF-K1-0072 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:60.00		SF-K1-0080 1/2 双HDMI 1/2 Dual HDMI ¥:342.00		SF-K1-0088 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:175.00
	SF-K1-0073 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:60.00		SF-K1-0081 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:220.00		SF-K1-0089 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:175.00
	SF-K1-0074 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:70.00		SF-K1-0082 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:220.00		SF-K1-0090 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:184.00
	SF-K1-0075 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:100.00		SF-K1-0083 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:229.00		SF-K1-0091 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:215.00
	SF-K1-0076 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:75.00		SF-K1-0084 1/2 电脑插座六类+HDMI 1/2 satellite socket(Cat6)+HDMI ¥:260.00		SF-K1-0092 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:190.00
	SF-K1-0077 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:182.00		SF-K1-0085 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:235.00		SF-K1-0093 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:342.00




SF-K1 PC白色/PC white

	SF-K1-0001 一开单控开关 ¥:45.00 1 gang 1 way switch 一开双控开关 ¥:48.00 1 gang 2 way switch 一开多控开关 ¥:66.00 1 gang 3 way switch		SF-K1-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:55.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:61.00		SF-K1-0017 13A方角插座 13A square corner socket ¥:45.00
	SF-K1-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:50.00 一开双控复位开关 1 gang 2 way Reset switch ¥:53.00		SF-K1-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:65.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:71.00		SF-K1-0018 德式插座 German socket ¥:45.00
	SF-K1-0003 二开单控开关 ¥:55.00 2 gang 1 way switch 二开双控开关 ¥:61.00 2 gang 2 way switch		SF-K1-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:65.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:74.00		SF-K1-0019 法式插座 French socket ¥:45.00
	SF-K1-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:65.00 二开双控复位开关 2 gang 2 way Reset switch ¥:71.00		SF-K1-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:80.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:89.00		SF-K1-0020 俄式插座 Russian socket ¥:45.00
	SF-K1-0005 三开单控开关 ¥:65.00 3 gang 1 way switch 三开双控开关 ¥:74.00 3 gang 2 way switch		SF-K1-0013 门铃开关(荧光) Doorbell switch(Fluorescent lamp) ¥:50.00		SF-K1-0021 德意式插座 German+Italian socket ¥:65.00
	SF-K1-0006 三开单复位开关 ¥:80.00 3 gang 1 way Reset switch 三开双复位开关 ¥:89.00 3 gang 2 way Reset switch		SF-K1-0014 门禁开关(荧光) Gating switch(Fluorescent lamp) ¥:50.00		SF-K1-0022 德式USB+Type-c German USB+Type-C ¥:205.00
	SF-K1-0007 一开单控开关(荧光) ¥:45.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:48.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:66.00 1 gang 3 way switch(Fluorescent lamp)		SF-K1-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:65.00		SF-K1-0023 法式USB+Type-c French USB+Type-C ¥:205.00
	SF-K1-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:50.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:53.00		SF-K1-0016 多功能插座 Universal socket ¥:45.00		SF-K1-0024 德式插座+二位USB 2 USB with German socket ¥:195.00

SF-K1 PC白色/PC white

	SF-K1-0025 法式插座+二位USB 2 USB with French socket ¥:195.00		SF-K1-0033 法式透明防溅插座 French transparent splash-proof socket ¥:68.00		SF-K1-0041 卫星插座 Satellite socket ¥:70.00
	SF-K1-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:192.00		SF-K1-0034 德式插座+防水 German socket + Waterproof belt ¥:55.00		SF-K1-0042 二位卫星插座 Double Satellite socket ¥:90.00
	SF-K1-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal) ¥:262.00		SF-K1-0035 法式插座+防水 French socket + Waterproof belt ¥:55.00		SF-K1-0043 电视卫星插座 Satellite and TV socket ¥:75.00
	SF-K1-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:192.00		SF-K1-0036 电视插座 TV socket ¥:55.00		SF-K1-0044 电话卫星插座 ¥:75.00 Satellite and telephone socket 电脑卫星插座 ¥:80.00 Satellite and computer socket
	SF-K1-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥:262.00		SF-K1-0037 电话插座 ¥:55.00 telephone socket 电脑插座 ¥:65.00 computer socket		SF-K1-0045 二位USB插座 Double USB socket ¥:175.00
	SF-K1-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:192.00		SF-K1-0038 二位电视插座 Double TV socket ¥:65.00		SF-K1-0046 二位音响插座 Single audio socket ¥:75.00
	SF-K1-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:192.00		SF-K1-0039 二位电话插座 ¥:65.00 Double telephone socket 二位电脑插座 ¥:75.00 Double computer socket 电话电脑插座 ¥:70.00 telephone+computer socket		SF-K1-0047 四位音响插座 Double audio socket ¥:95.00
	SF-K1-0032 德式透明防溅插座 German type transparent splash-proof socket ¥:68.00		SF-K1-0040 电视电话插座 ¥:65.00 TV + telephone socket 电视电脑插座 ¥:70.00 TV + computer socket		SF-K1-0048 紧急呼叫开关 Emergency call switch ¥:145.00

SF-K1 PC白色/PC white

	SF-K1-0049 调光开关300W ¥:118.00 Dimming 300W 调光开关500W ¥:158.00 Dimming 500W 调光开关1000W ¥:188.00 Dimming 1000W 调光LED开关200W ¥:158.00 Dimming LED 200W		SF-K1-0057 凹型人体感应地脚灯 The human body induction footlights ¥:230.00		SF-K1-0062 121型二位德式插座(短连体) 121 Double German socket(short) ¥:68.00
	SF-K1-0050 调速开关300W ¥:118.00 Speed 300W 调速开关500W ¥:158.00 Speed 500W		SF-K1-0058 剃须插座 Shaving socket ¥:420.00		SF-K1-0063 121型二位法式插座(短连体) 121 Double French socket(short) ¥:68.00
	SF-K1-0051 调音开关 Tuning switch (fire) ¥:168.00		SF-K1-0059 空白面板 Blank plate ¥:26.00		SF-K1-0064 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:68.00
	SF-K1-0052 触摸延时开关 ¥:118.00 Touch delay switch 声光控延时开关 ¥:118.00 Sound-light controlled delay switch		SF-K1-0060 二位德式插座(单体) Double German socket(single) ¥:72.00		SF-K1-0065 一位连体边框 one face frame ¥:12.00
	SF-K1-0053 人体感应开关 Human body induction ¥:228.00		SF-K1-0061 二位法式插座(单体) Double French socket (single) ¥:72.00		SF-K1-0066 二位连体边框 Double face frame ¥:25.00
	SF-K1-0054 叮咚门铃 Ding dong doorbell ¥:158.00		SF-K1-0067 三位连体边框 Three face frame ¥:40.00		SF-K1-0068 四位连体边框 four face frame ¥:55.00
	SF-K1-0055 插卡取电(机械式) ¥:220.00 Mechanical card for electricity 插卡取电(低频) ¥:350.00 Low frequency induction card for electricity 插卡取电(高频) ¥:480.00 High frequency induction card for electricity		SF-K1-0069 五位连体边框 five face frame ¥:70.00		


SF-K2

烤漆面板 SERIES
Lacquered panel











Simple panel design, not carved but exudes a unique charm,
highlighting the extraordinary style.









简约的面板设计，不事雕琢却散发着独特的魅力，彰显出非凡的格调。














SF-K2烤漆金色/Paint gold

	SF-K2-0070 20A红绿开关 20A Red and green switch ¥:123.00		SF-K2-0078 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:148.00		SF-K2-0086 1/2 USB/TYPE-C+HDMI ¥:313.00
	SF-K2-0071 空白出线孔 Blank outlet hole ¥:36.00		SF-K2-0079 1/2 白板+白板 blank panel+blank panel ¥:41.00		SF-K2-0087 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:268.00
	SF-K2-0072 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:70.00		SF-K2-0080 1/2 双HDMI 1/2 Dual HDMI ¥:358.00		SF-K2-0088 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:190.00
	SF-K2-0073 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:70.00		SF-K2-0081 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:235.00		SF-K2-0089 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:190.00
	SF-K2-0074 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:80.00		SF-K2-0082 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:235.00		SF-K2-0090 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:200.00
	SF-K2-0075 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:110.00		SF-K2-0083 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:245.00		SF-K2-0091 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:230.00
	SF-K2-0076 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:85.00		SF-K2-0084 1/2 电脑插座六类+HDMI 1/2 computer socket(Cat6)+HDMI ¥:275.00		SF-K2-0092 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:205.00
	SF-K2-0077 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:193.00		SF-K2-0085 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:250.00		SF-K2-0093 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:348.00







SF-K2烤漆金色/Paint gold

	SF-K2-0001 一开单控开关 ¥:55.00 1 gang 1 way switch 一开双控开关 ¥:58.00 1 gang 2 way switch 一开多控开关 ¥:76.00 1 gang 3 way switch		SF-K2-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:65.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:71.00		SF-K2-0017 13A方角插座 13A square corner socket ¥:55.00
	SF-K2-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:60.00 一开双控复位开关 1 gang 2 way Reset switch ¥:63.00		SF-K2-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:75.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:81.00		SF-K2-0018 德式插座 German socket ¥:55.00
	SF-K2-0003 二开单控开关 ¥:65.00 2 gang 1 way switch 二开双控开关 ¥:71.00 2 gang 2 way switch		SF-K2-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:75.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:84.00		SF-K2-0019 法式插座 French socket ¥:55.00
	SF-K2-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:75.00 二开双控复位开关 2 gang 2 way Reset switch ¥:81.00		SF-K2-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:90.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:104.00		SF-K2-0020 俄式插座 Russian socket ¥:55.00
	SF-K2-0005 三开单控开关 ¥:75.00 3 gang 1 way switch 三开双控开关 ¥:84.00 3 gang 2 way switch		SF-K2-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:60.00		SF-K2-0021 德意式插座 German+Italian socket ¥:75.00
	SF-K2-0006 三开单复位开关 ¥:90.00 3 gang 1 way Reset switch 三开双复位开关 ¥:104.00 3 gang 2 way Reset switch		SF-K2-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:60.00		SF-K2-0022 德式USB+Type-c German USB+Type-C ¥:215.00
	SF-K2-0007 一开单控开关(荧光) ¥:55.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:58.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:76.00 1 gang 3 way switch(Fluorescent lamp)		SF-K2-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:75.00		SF-K2-0023 法式USB+Type-c French USB+Type-C ¥:215.00
	SF-K2-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:60.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:63.00		SF-K2-0016 多功能插座 Universal socket ¥:55.00		SF-K2-0024 德式插座+二位USB 2 USB with German socket ¥:205.00

SF-K2烤漆金色/Paint gold

	SF-K2-0025 法式插座+二位USB 2 USB with French socket ¥ :205.00		SF-K2-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :79.00		SF-K2-0041 卫星插座 Satellite socket ¥ :80.00
	SF-K2-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :203.00		SF-K2-0034 德式插座+防水 German socket + Waterproof belt ¥ :65.00		SF-K2-0042 二位卫星插座 Double Satellite socket ¥ :100.00
	SF-K2-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :273.00		SF-K2-0035 法式插座+防水 French socket + Waterproof belt ¥ :65.00		SF-K2-0043 电视卫星插座 Satellite and TV socket ¥ :85.00
	SF-K2-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :203.00		SF-K2-0036 电视插座 TV socket ¥ :65.00		SF-K2-0044 电话卫星插座 ¥ :85.00 Satellite and telephone socket 电脑卫星插座 ¥ :90.00 Satellite and computer socket
	SF-K2-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :273.00		SF-K2-0037 电话插座 telephone socket ¥ :65.00 电脑插座 computer socket ¥ :75.00		SF-K2-0045 二位USB插座 Double USB socket ¥ :185.00
	SF-K2-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :203.00		SF-K2-0038 二位电视插座 Double TV socket ¥ :75.00		SF-K2-0046 二位音响插座 Single audio socket ¥ :85.00
	SF-K2-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :203.00		SF-K2-0039 二位电话插座 ¥ :75.00 Double telephone socket 二位电脑插座 ¥ :85.00 Double computer socket 电话电脑插座 ¥ :80.00 telephone+computer socket		SF-K2-0047 四位音响插座 Double audio socket ¥ :105.00
	SF-K2-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :79.00		SF-K2-0040 电视电话插座 ¥ :75.00 TV + telephone socket 电视电脑插座 ¥ :80.00 TV + computer socket		SF-K2-0048 紧急呼叫开关 Emergency call switch ¥ :155.00

SF-K2烤漆金色/Paint gold

	SF-K2-0049 调光开关300W ¥ :128.00 Dimming 300W 调光开关500W ¥ :168.00 Dimming 500W 调光开关1000W ¥ :198.00 Dimming 1000W 调光LED开关200W ¥ :168.00 Dimming LED 200W		SF-K2-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :240.00		SF-K2-0062 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :79.00
	SF-K2-0050 调速开关300W ¥ :128.00 Speed 300W 调速开关500W ¥ :168.00 Speed 500W		SF-K2-0058 剃须插座 Shaving socket ¥ :430.00		SF-K2-0063 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :79.00
	SF-K2-0051 调音开关 Tuning switch(fire) ¥ :178.00		SF-K2-0059 空白面板 Blank plate ¥ :36.00		SF-K2-0064 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :79.00
	SF-K2-0052 触摸延时开关 ¥ :128.00 Touch delay switch 声光控延时开关 ¥ :128.00 Sound-light controlled delay switch		SF-K2-0060 二位德式插座(单体) Double German socket(single) ¥ :83.00		SF-K2-0065 一位连体边框 one face frame ¥ :18.00
	SF-K2-0053 人体感应开关 Human body induction ¥ :238.00		SF-K2-0061 二位法式插座(单体) Double French socket (single) ¥ :83.00		SF-K2-0066 二位连体边框 Double face frame ¥ :50.00
	SF-K2-0054 叮咚门铃 Ding dong doorbell ¥ :168.00		SF-K2-0067 三位连体边框 Three face frame ¥ :80.00		
	SF-K2-0055 插卡取电(机械式) ¥ :230.00 Mechanical card for electricity 插卡取电(低频) ¥ :360.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :490.00 High frequency induction card for electricity		SF-K2-0068 四位连体边框 four face frame ¥ :110.00		
	SF-K2-0056 凹型地脚灯 The footlights ¥ :140.00		SF-K2-0069 五位连体边框 five face frame ¥ :140.00		


SF-K3

烤漆黑色 SERIES
Black paint finish



Simple panel design, not carved but exudes a unique charm,
highlighting the extraordinary style.

简约的面板设计，不事雕琢却散发着独特的魅力，彰显出非凡的格调。



SF-K3烤漆黑色/Paint black

	SF-K3-0070 20A红绿开关 20A Red and green switch ¥:123.00		SF-K3-0078 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:148.00		SF-K3-0086 1/2 USB/TYPE-C+HDMI ¥:313.00
	SF-K3-0071 空白出线孔 Blank outlet hole ¥:36.00		SF-K3-0079 1/2 白板+白板 blank panel+blank panel ¥:41.00		SF-K3-0087 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:268.00
	SF-K3-0072 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:70.00		SF-K3-0080 1/2 双HDMI 1/2 Dual HDMI ¥:358.00		SF-K3-0088 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:190.00
	SF-K3-0073 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:70.00		SF-K3-0081 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:235.00		SF-K3-0089 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:190.00
	SF-K3-0074 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:80.00		SF-K3-0082 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:235.00		SF-K3-0090 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:200.00
	SF-K3-0075 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:110.00		SF-K3-0083 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:245.00		SF-K3-0091 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:230.00
	SF-K3-0076 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:85.00		SF-K3-0084 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:275.00		SF-K3-0092 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:205.00
	SF-K3-0077 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:193.00		SF-K3-0085 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:250.00		SF-K3-0093 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:348.00

SF-K3烤漆黑色/Paint black

	SF-K3-0001 一开单控开关 ¥:55.00 1 gang 1 way switch 一开双控开关 ¥:58.00 1 gang 2 way switch 一开多控开关 ¥:76.00 1 gang 3 way switch		SF-K3-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:65.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:71.00		SF-K3-0017 13A方角插座 13A square corner socket ¥:55.00
	SF-K3-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:60.00 一开双控复位开关 1 gang 2 way Reset switch ¥:63.00		SF-K3-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:75.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:81.00		SF-K3-0018 德式插座 German socket ¥:55.00
	SF-K3-0003 二开单控开关 ¥:65.00 2 gang 1 way switch 二开双控开关 ¥:71.00 2 gang 2 way switch		SF-K3-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:75.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:84.00		SF-K3-0019 法式插座 French socket ¥:55.00
	SF-K3-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:75.00 二开双控复位开关 2 gang 2 way Reset switch ¥:81.00		SF-K3-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:90.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:104.00		SF-K3-0020 俄式插座 Russian socket ¥:55.00
	SF-K3-0005 三开单控开关 ¥:75.00 3 gang 1 way switch 三开双控开关 ¥:84.00 3 gang 2 way switch		SF-K3-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:60.00		SF-K3-0021 德意式插座 German+Italian socket ¥:75.00
	SF-K3-0006 三开单复位开关 ¥:90.00 3 gang 1 way Reset switch 三开双复位开关 ¥:104.00 3 gang 2 way Reset switch		SF-K3-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:60.00		SF-K3-0022 德式USB+Type-c German USB+Type-C ¥:215.00
	SF-K3-0007 一开单控开关(荧光) ¥:55.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:58.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:76.00 1 gang 3 way switch(Fluorescent lamp)		SF-K3-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:75.00		SF-K3-0023 法式USB+Type-c French USB+Type-C ¥:215.00
	SF-K3-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:60.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:63.00		SF-K3-0016 多功能插座 Universal socket ¥:55.00		SF-K3-0024 德式插座+二位USB 2 USB with German socket ¥:205.00

SF-K3烤漆黑色/Paint black

	SF-K3-0025 法式插座+二位USB 2 USB with French socket ¥ :205.00		SF-K3-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :79.00		SF-K3-0041 卫星插座 Satellite socket ¥ :80.00
	SF-K3-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :203.00		SF-K3-0034 德式插座+防水 German socket + Waterproof belt ¥ :65.00		SF-K3-0042 二位卫星插座 Double Satellite socket ¥ :100.00
	SF-K3-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C(20W) (horizontal) ¥ :273.00		SF-K3-0035 法式插座+防水 French socket + Waterproof belt ¥ :65.00		SF-K3-0043 电视卫星插座 Satellite and TV socket ¥ :85.00
	SF-K3-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :203.00		SF-K3-0036 电视插座 TV socket ¥ :65.00		SF-K3-0044 电话卫星插座 ¥ :85.00 Satellite and telephone socket 电脑卫星插座 ¥ :90.00 Satellite and computer socket
	SF-K3-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :273.00		SF-K3-0037 电话插座 ¥ :65.00 telephone socket 电脑插座 ¥ :75.00 computer socket		SF-K3-0045 二位USB插座 Double USB socket ¥ :185.00
	SF-K3-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :203.00		SF-K3-0038 二位电视插座 Double TV socket ¥ :75.00		SF-K3-0046 二位音响插座 Single audio socket ¥ :85.00
	SF-K3-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :203.00		SF-K3-0039 二位电话插座 ¥ :75.00 Double telephone socket 二位电脑插座 ¥ :85.00 Double computer socket 电话电脑插座 ¥ :80.00 telephone+computer socket		SF-K3-0047 四位音响插座 Double audio socket ¥ :105.00
	SF-K3-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :79.00		SF-K3-0040 电视电话插座 ¥ :75.00 TV + telephone socket 电视电脑插座 ¥ :80.00 TV + computer socket		SF-K3-0048 紧急呼叫开关 Emergency call switch ¥ :155.00

SF-K3烤漆黑色/Paint black

	SF-K3-0049 调光开关300W ¥ :128.00 Dimming 300W 调光开关500W ¥ :168.00 Dimming 500W 调光开关1000W ¥ :198.00 Dimming 1000W 调光LED开关200W ¥ :168.00 Dimming LED 200W		SF-K3-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :240.00		SF-K3-0062 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :79.00
	SF-K3-0050 调速开关300W ¥ :128.00 Speed 300W 调速开关500W ¥ :168.00 Speed 500W		SF-K3-0058 剃须插座 Shaving socket ¥ :430.00		SF-K3-0063 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :79.00
	SF-K3-0051 调音开关 Tuning switch(fire) ¥ :178.00		SF-K3-0059 空白面板 Blank plate ¥ :36.00		SF-K3-0064 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :79.00
	SF-K3-0052 触摸延时开关 ¥ :128.00 Touch delay switch 声光控延时开关 ¥ :128.00 Sound-light controlled delay switch		SF-K3-0060 二位德式插座(单体) Double German socket(single) ¥ :83.00		SF-K3-0065 一位连体边框 one face frame ¥ :18.00
	SF-K3-0053 人体感应开关 Human body induction ¥ :238.00		SF-K3-0061 二位法式插座(单体) Double French socket (single) ¥ :83.00		SF-K3-0066 二位连体边框 Double face frame ¥ :50.00
	SF-K3-0054 叮咚门铃 Ding dong doorbell ¥ :168.00		SF-K3-0067 三位连体边框 Three face frame ¥ :80.00		
	SF-K3-0055 插卡取电(机械式) ¥ :230.00 Mechanical card for electricity 插卡取电(低频) ¥ :360.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :490.00 High frequency induction card for electricity		SF-K3-0068 四位连体边框 four face frame ¥ :110.00		
	SF-K3-0056 凹型地脚灯 The footlights ¥ :140.00		SF-K3-0069 五位连体边框 five face frame ¥ :140.00		


SF-K4

烤漆灰色 SERIES
Grey paint finish








Simple panel design, not carved but exudes a unique charm,
highlighting the extraordinary style.



简约的面板设计，不事雕琢却散发着独特的魅力，彰显出非凡的格调。





SF-K4 烤漆灰色/Paint grey

	SF-K4-0070 20A红绿开关 20A Red and green switch ¥:123.00		SF-K4-0078 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:148.00		SF-K4-0086 1/2 USB/TYPE-C+HDMI ¥:313.00
	SF-K4-0071 空白出线孔 Blank outlet hole ¥:36.00		SF-K4-0079 1/2 白板+白板 blank panel+blank panel ¥:41.00		SF-K4-0087 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:268.00
	SF-K4-0072 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:70.00		SF-K4-0080 1/2 双HDMI 1/2 Dual HDMI ¥:358.00		SF-K4-0088 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:190.00
	SF-K4-0073 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:70.00		SF-K4-0081 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:235.00		SF-K4-0089 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:190.00
	SF-K4-0074 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:80.00		SF-K4-0082 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:235.00		SF-K4-0090 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:200.00
	SF-K4-0075 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:110.00		SF-K4-0083 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:245.00		SF-K4-0091 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:230.00
	SF-K4-0076 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:85.00		SF-K4-0084 1/2 电脑插座六类+HDMI 1/2 computer socket(Cat6)+HDMI ¥:275.00		SF-K4-0092 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:205.00
	SF-K4-0077 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:193.00		SF-K4-0085 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:250.00		SF-K4-0093 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:348.00





SF-K4 烤漆灰色/Paint grey

	SF-K4-0001 一开单控开关 ¥:55.00 1 gang 1 way switch 一开双控开关 ¥:58.00 1 gang 2 way switch 一开多控开关 ¥:76.00 1 gang 3 way switch		SF-K4-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:65.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:71.00		SF-K4-0017 13A方角插座 13A square corner socket ¥:55.00
	SF-K4-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:60.00 一开双控复位开关 1 gang 2 way Reset switch ¥:63.00		SF-K4-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:75.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:81.00		SF-K4-0018 德式插座 German socket ¥:55.00
	SF-K4-0003 二开单控开关 ¥:65.00 2 gang 1 way switch 二开双控开关 ¥:71.00 2 gang 2 way switch		SF-K4-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:75.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:84.00		SF-K4-0019 法式插座 French socket ¥:55.00
	SF-K4-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:75.00 二开双控复位开关 2 gang 2 way Reset switch ¥:81.00		SF-K4-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:90.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:104.00		SF-K4-0020 俄式插座 Russian socket ¥:55.00
	SF-K4-0005 三开单控开关 ¥:75.00 3 gang 1 way switch 三开双控开关 ¥:84.00 3 gang 2 way switch		SF-K4-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:60.00		SF-K4-0021 德意式插座 German+Italian socket ¥:75.00
	SF-K4-0006 三开单复位开关 ¥:90.00 3 gang 1 way Reset switch 三开双复位开关 ¥:104.00 3 gang 2 way Reset switch		SF-K4-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:60.00		SF-K4-0022 德式USB+Type-c German USB+Type-C ¥:215.00
	SF-K4-0007 一开单控开关(荧光) ¥:55.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:58.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:76.00 1 gang 3 way switch(Fluorescent lamp)		SF-K4-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:75.00		SF-K4-0023 法式USB+Type-c French USB+Type-C ¥:215.00
	SF-K4-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:60.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:63.00		SF-K4-0016 多功能插座 Universal socket ¥:55.00		SF-K4-0024 德式插座+二位USB 2 USB with German socket ¥:205.00

SF-K4 烤漆灰色/Paint grey

	SF-K4-0025 法式插座+二位USB 2 USB with French socket ¥ :205.00		SF-K4-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :79.00		SF-K4-0041 卫星插座 Satellite socket ¥ :80.00
	SF-K4-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :203.00		SF-K4-0034 德式插座+防水 German socket + Waterproof belt ¥ :65.00		SF-K4-0042 二位卫星插座 Double Satellite socket ¥ :100.00
	SF-K4-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :273.00		SF-K4-0035 法式插座+防水 French socket + Waterproof belt ¥ :65.00		SF-K4-0043 电视卫星插座 Satellite and TV socket ¥ :85.00
	SF-K4-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :203.00		SF-K4-0036 电视插座 TV socket ¥ :65.00		SF-K4-0044 电话卫星插座 ¥ :85.00 Satellite and telephone socket 电脑卫星插座 ¥ :90.00 Satellite and computer socket
	SF-K4-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :273.00		SF-K4-0037 电话插座 ¥ :65.00 telephone socket 电脑插座 ¥ :75.00 computer socket		SF-K4-0045 二位USB插座 Double USB socket ¥ :185.00
	SF-K4-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :203.00		SF-K4-0038 二位电视插座 Double TV socket ¥ :75.00		SF-K4-0046 二位音响插座 Single audio socket ¥ :85.00
	SF-K4-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :203.00		SF-K4-0039 二位电话插座 ¥ :75.00 Double telephone socket 二位电脑插座 ¥ :85.00 Double computer socket 电话电脑插座 ¥ :80.00 telephone+computer socket		SF-K4-0047 四位音响插座 Double audio socket ¥ :105.00
	SF-K4-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :79.00		SF-K4-0040 电视电话插座 ¥ :75.00 TV + telephone socket 电视电脑插座 ¥ :80.00 TV + computer socket		SF-K4-0048 紧急呼叫开关 Emergency call switch ¥ :155.00

SF-K4 烤漆灰色/Paint grey

	SF-K4-0049 调光开关300W ¥ :128.00 Dimming 300W 调光开关500W ¥ :168.00 Dimming 500W 调光开关1000W ¥ :198.00 Dimming 1000W 调光LED开关200W ¥ :168.00 Dimming LED 200W		SF-K4-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :240.00		SF-K4-0062 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :79.00
	SF-K4-0050 调速开关300W ¥ :128.00 Speed 300W 调速开关500W ¥ :168.00 Speed 500W		SF-K4-0058 剃须插座 Shaving socket ¥ :430.00		SF-K4-0063 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :79.00
	SF-K4-0051 调音开关 Tuning switch(fire) ¥ :178.00		SF-K4-0059 空白面板 Blank plate ¥ :36.00		SF-K4-0064 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :79.00
	SF-K4-0052 触摸延时开关 ¥ :128.00 Touch delay switch 声光控延时开关 ¥ :128.00 Sound-light controlled delay switch		SF-K4-0060 二位德式插座(单体) Double German socket(single) ¥ :83.00		SF-K4-0065 一位连体边框 one face frame ¥ :18.00
	SF-K4-0053 人体感应开关 Human body induction ¥ :238.00		SF-K4-0061 二位法式插座(单体) Double French socket (single) ¥ :83.00		SF-K4-0066 二位连体边框 Double face frame ¥ :50.00
	SF-K4-0054 叮咚门铃 Ding dong doorbell ¥ :168.00		SF-K4-0067 三位连体边框 Three face frame ¥ :80.00		
	SF-K4-0055 插卡取电(机械式) ¥ :230.00 Mechanical card for electricity 插卡取电(低频) ¥ :360.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :490.00 High frequency induction card for electricity		SF-K4-0068 四位连体边框 four face frame ¥ :110.00		
	SF-K4-0056 凹型地脚灯 The footlights ¥ :140.00		SF-K4-0069 五位连体边框 five face frame ¥ :140.00		














OB-Z1

SERIES















PC白色 PC white














OB-Z1PC白色/ PC white

	OB-Z1-0071 20A红绿开关 20A Red and green switch ¥:119.00		OB-Z1-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:139.00		OB-Z1-0087 1/2 USB/TYPE-C+HDMI ¥:299.00
	OB-Z1-0072 空白出线孔 Blank outlet hole ¥:28.00		OB-Z1-0080 1/2 白板+白板 blank panel+blank panel ¥:33.00		OB-Z1-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:254.00
	OB-Z1-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:62.00		OB-Z1-0081 1/2 双HDMI 1/2 Dual HDMI ¥:344.00		OB-Z1-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:177.00
	OB-Z1-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:62.00		OB-Z1-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:222.00		OB-Z1-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:177.00
	OB-Z1-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:72.00		OB-Z1-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:222.00		OB-Z1-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:186.00
	OB-Z1-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:102.00		OB-Z1-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:231.00		OB-Z1-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:217.00
	OB-Z1-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:77.00		OB-Z1-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:262.00		OB-Z1-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:192.00
	OB-Z1-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥ 184.00		OB-Z1-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:237.00		




OB-Z1PC白色/ PC white

	OB-Z1-0001 一开单控开关 ¥:47.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:50.00 1 gang 2 way switch 一开多控开关 ¥:68.00 1 gang 3 way switch		OB-Z1-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:57.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:63.00		OB-Z1-0017 13A方角插座 13A square corner socket ¥:47.00
	OB-Z1-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:52.00 一开双控复位开关 1 gang 2 way Reset switch ¥:55.00		OB-Z1-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:67.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:73.00		OB-Z1-0018 德式插座 German socket ¥:47.00
	OB-Z1-0003 二开单控开关 ¥:57.00 2 gang 1 way switch 二开双控开关 ¥:63.00 2 gang 2 way switch		OB-Z1-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:67.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:76.00		OB-Z1-0019 法式插座 French socket ¥:47.00
	OB-Z1-0004 二开单复位开关 2 gang 1 way Reset switch ¥:67.00 二开双控复位开关 2 gang 2 way Reset switch ¥:73.00		OB-Z1-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:82.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:91.00		OB-Z1-0020 俄式插座 Russian socket ¥:47.00
	OB-Z1-0005 三开单控开关 ¥:67.00 3 gang 1 way switch 三开双控开关 ¥:76.00 3 gang 2 way switch		OB-Z1-0013 门铃开关(荧光) Doorbell switch(Fluorescent lamp) ¥:52.00		OB-Z1-0021 德意式插座 German+Italian socket ¥:67.00
	OB-Z1-0006 三开单复位开关 ¥:82.00 3 gang 1 way Reset switch 三开双复位开关 ¥:91.00 3 gang 2 way Reset switch		OB-Z1-0014 门禁开关(荧光) Gating switch(Fluorescent lamp) ¥:52.00		OB-Z1-0022 德式USB+Type-c German USB+Type-C ¥:207.00
	OB-Z1-0007 一开单控开关(荧光) ¥:47.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:50.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:68.00 1 gang 3 way switch(Fluorescent lamp)		OB-Z1-0015 百叶窗升降开关(荧光) louwer window lifter switch (Fluorescent lamp) ¥:67.00		OB-Z1-0023 法式USB+Type-c French USB+Type-C ¥:207.00
	OB-Z1-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:52.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:55.00		OB-Z1-0016 多功能插座 Universal socket ¥:47.00		OB-Z1-0024 德式插座+二位USB 2 USB with German socket ¥:197.00

OB-Z1PC白色/ PC white

	OB-Z1-00 法式插座+二位USB 2 USB with French socket ¥:197.00		OB-Z1-0033 法式透明防溅插座 French transparent splash-proof socket ¥:70.00		OB-Z1-0041 卫星插座 Satellite socket ¥:72.00
	OB-Z1-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:194.00		OB-Z1-0034 德式插座+防水 German socket + Waterproof belt ¥:57.00		OB-Z1-0042 二位卫星插座 Double Satellite socket ¥:92.00
	OB-Z1-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C(20W) (horizontal) ¥:264.00		OB-Z1-0035 法式插座+防水 French socket + Waterproof belt ¥:57.00		OB-Z1-0043 电视卫星插座 Satellite and TV socket ¥:77.00
	OB-Z1-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:194.00		OB-Z1-0036 电视插座 TV socket ¥:57.00		OB-Z1-0044 电话卫星插座 ¥:77.00 Satellite and telephone socket 电脑卫星插座 ¥:82.00 Satellite and computer socket
	OB-Z1-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥:264.00		OB-Z1-0037 电话插座 ¥:57.00 telephone socket 电脑插座 ¥:67.00 computer socket		OB-Z1-0045 二位USB插座 Double USB socket ¥:177.00
	OB-Z1-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:194.00		OB-Z1-0038 二位电视插座 Double TV socket ¥:67.00		OB-Z1-0046 二位音响插座 Single audio socket ¥:77.00
	OB-Z1-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:194.00		OB-Z1-0039 二位电话插座 ¥:67.00 Double telephone socket 二位电脑插座 ¥:77.00 Double computer socket 电话电脑插座 ¥:72.00 telephone+computer socket		OB-Z1-0047 四位音响插座 Double audio socket ¥:97.00
	OB-Z1-0032 德式透明防溅插座 German type transparent splash-proof socket ¥:70.00		OB-Z1-0040 电视电话插座 ¥:67.00 TV + telephone socket 电视电脑插座 ¥:72.00 TV + computer socket		OB-Z1-0048 紧急呼叫开关 Emergency call switch ¥:147.00

OB-Z1PC白色/ PC white

	OB-Z1-0049 调光开关300W ¥:120.00 Dimming 300W 调光开关500W ¥:160.00 Dimming 500W 调光开关1000W ¥:190.00 Dimming 1000W 调光LED开关200W ¥:160.00 Dimming LED 200W		OB-Z1-0057 凹型人体感应地脚灯 The human body induction footlights ¥:232.00		OB-Z1-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥:70.00
	OB-Z1-0050 调速开关300W ¥:120.00 Speed 300W 调速开关500W ¥:160.00 Speed 500W		OB-Z1-0058 剃须插座 Shaving socket ¥:422.00		OB-Z1-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥:70.00
	OB-Z1-0051 调音开关 Tuning switch (fire) ¥:170.00		OB-Z1-0059 空白面板 Blank plate ¥:28.00		OB-Z1-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:70.00
	OB-Z1-0052 触摸延时开关 ¥:120.00 Touch delay switch 声光控延时开关 ¥:120.00 Sound-light controlled delay switch		OB-Z1-0060 二位德式插座(单体) Double German socket(single) ¥:74.00		OB-Z1-0066 一位连体边框 One face frame ¥:14.00
	OB-Z1-0053 人体感应开关 Human body induction ¥:230.00		OB-Z1-0061 二位法式插座(单体) Double French socket (single) ¥:74.00		OB-Z1-0067 二位连体边框 Double face frame ¥:29.00
	OB-Z1-0054 叮咚门铃 Ding dong doorbell ¥:160.00		OB-Z1-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:344.00		OB-Z1-0068 三位连体边框 Three face frame ¥:46.00
	OB-Z1-0055 插卡取电(机械式) ¥:222.00 Mechanical card for electricity 插卡取电(低频) ¥:352.00 Low frequency induction card for electricity 插卡取电(高频) ¥:482.00 High frequency induction card for electricity		OB-Z1-0069 四位连体边框 four face frame ¥:63.00		
	OB-Z1-0056 凹型地脚灯 The footlights ¥:132.00		OB-Z1-0070 五位连体边框 five face frame ¥:80.00		


OB-Z2

SERIES

肤感金色
Skin feels Gold




OB-ZZ肤感金色/Skin feels gold




OB-ZZ-0071
20A红绿开关
20A Red and green switch
¥:128.00




OB-ZZ-0072
空白出线孔
Blank outlet hole
¥:41.00




OB-ZZ-0073
1/2 电视插座+白板
1/2 TV socket+blank panel
¥:75.00




OB-ZZ-0074
1/2 电话插座+白板
1/2 telephone socket+blank panel
¥:75.00




OB-ZZ-0075
1/2 电脑插座+白板
1/2 computer socket+blank panel
¥:85.00



OB-ZZ-0076
1/2 电脑插座六类+白板
1/2 Computer socket(Cat6)
+blank panel
¥:115.00




OB-ZZ-0077
1/2 卫星插座+白板
1/2 satellite socket+blank panel
¥:90.00



OB-ZZ-0078
1/2 HDMI+白板
1/2 HDMI+blank panel
¥:198.00



OB-ZZ-0079
1/2 USB+type-c10W+白板
1/2 USB+type-c10W+blank panel
¥:153.00



OB-ZZ-0080
1/2 白板+白板
blank panel+blank panel
¥:46.00



OB-ZZ-0081
1/2 双HDMI
1/2 Dual HDMI
¥:363.00



OB-ZZ-0082
1/2 电视+HDMI
1/2 TV socket+1/2 HDMI socket
¥:240.00




OB-ZZ-0083
1/2 电话+HDMI
1/2 telephone socket+1/2
HDMI socket
¥:240.00



OB-ZZ-0084
1/2 电脑插座+HDMI
1/2 computer socket+HDMI
¥:250.00



OB-ZZ-0085
1/2 电脑插座六类+HDMI
1/2 Computer socket(Cat6)+HDMI
¥:280.00



OB-ZZ-0086
1/2 卫星+HDMI
1/2 satellite socket+HDMI
¥:255.00



OB-ZZ-0087
1/2 USB/TYPE-C+HDMI
¥:318.00



OB-ZZ-0088
二位1/2 USB/TYPE-C
Double 1/2 USB/TYPE-C
¥:273.00



OB-ZZ-0089
1/2 电视+USB/TYPE-C
1/2 TV socket+1/2USB/TYPE-C
¥:195.00



OB-ZZ-0090
1/2 电话+USB/TYPE-C
1/2 telephone socket+
1/2 USB/TYPE-C
¥:195.00



OB-ZZ-0091
1/2 电脑+USB/TYPE-C
1/2 Computer socket+ USB/TYPE-C
¥:205.00




OB-ZZ-0092
1/2 电脑六类+USB/TYPE-C
1/2 Computer socket(Cat6)
+USB/TYPE-C
¥:235.00




OB-ZZ-0093
1/2 卫星+USB/TYPE-C
1/2 satellite socket+USB/TYPE-C
¥:210.00


OB-ZZ肤感金色/Skin feels gold




OB-ZZ-0001
一开单控开关 ¥:60.00
1 gang 1 way switch
一开双控开关 ¥:63.00
1 gang 2 way switch
一开多控开关 ¥:81.00
1 gang 3 way switch




OB-ZZ-0002
一开单控复位开关
1 gang 1 way Reset switch
¥:65.00
一开双控复位开关
1 gang 2 way Reset switch
¥:68.00




OB-ZZ-0003
二开单控开关 ¥:70.00
2 gang 1 way switch
二开双控开关 ¥:76.00
2 gang 2 way switch




OB-ZZ-0004
二开单控复位开关
2 gang 1 way Reset switch
¥:80.00
二开双控复位开关
2 gang 2 way Reset switch
¥:86.00




OB-ZZ-0005
三开单控开关 ¥:80.00
3 gang 1 way switch
三开双控开关 ¥:89.00
3 gang 2 way switch



OB-ZZ-0006
三开单复位开关 ¥:95.00
3 gang 1 way Reset switch
三开双复位开关 ¥:109.00
3 gang 2 way Reset switch



OB-ZZ-0007
一开单控开关(荧光) ¥:60.00
1 gang 1 way switch(Fluorescent lamp)
一开双控开关(荧光) ¥:63.00
1 gang 2 way switch(Fluorescent lamp)
一开多控开关(荧光) ¥:81.00
1 gang 3 way switch(Fluorescent lamp)



OB-ZZ-0008
一开单控复位开关(荧光)
1 gang 1 way Reset switch
(Fluorescent lamp)
¥:65.00
一开双控复位开关(荧光)
1 gang 2 way Reset switch
(Fluorescent lamp)
¥:68.00



OB-ZZ-0009
二开单控开关(荧光)
2 gang 1 way switch
(Fluorescent lamp)
¥:70.00
二开双控开关(荧光)
2 gang 2 way switch
(Fluorescent lamp)
¥:76.00



OB-ZZ-0010
二开单控复位开关(荧光)
2 gang 1 way Reset switch
(Fluorescent lamp)
¥:80.00
二开双控复位开关(荧光)
2 gang 2 way Reset switch
(Fluorescent lamp)
¥:86.00



OB-ZZ-0011
三开单控开关(荧光)
3 gang 1 way switch
(Fluorescent lamp)
¥:80.00
三开双控开关(荧光)
3 gang 2 way switch
(Fluorescent lamp)
¥:89.00



OB-ZZ-0012
三开单复位开关(荧光)
3 gang 1 way Reset switch
(Fluorescent lamp)
¥:95.00
三开双复位开关(荧光)
3 gang 2 way Reset switch
(Fluorescent lamp)
¥:109.00




OB-ZZ-0013
门铃开关(荧光)
Doorbell switch
(Fluorescent lamp)
¥:65.00



OB-ZZ-0014
门禁开关(荧光)
Gating switch
(Fluorescent lamp)
¥:65.00



OB-ZZ-0015
百叶窗升降开关(荧光)
louver window lifter switch
(Fluorescent lamp)
¥:80.00



OB-ZZ-0016
多功能插座
Universal socket
¥:60.00



OB-ZZ-0017
13A方角插座
13A square corner socket
¥:60.00



OB-ZZ-0018
德式插座
German socket
¥:60.00



OB-ZZ-0019
法式插座
French socket
¥:60.00



OB-ZZ-0020
俄式插座
Russian socket
¥:60.00



OB-ZZ-0021
德意式插座
German+Italian socket
¥:80.00



OB-ZZ-0022
德式USB+Type-c
German USB+Type-C
¥:220.00










OB-ZZ-0023
法式USB+Type-c
French USB+Type-C
¥:220.00












OB-ZZ-0024
德式插座+二位USB
2 USB with German socket
¥:210.00

OB-ZZ肤感金色/Skin feels gold

	OB-ZZ-0025 法式插座+二位USB 2 USB with French socket ¥ :210.00		OB-ZZ-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :84.00		OB-ZZ-0041 卫星插座 Satellite socket ¥ :85.00
	OB-ZZ-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :208.00		OB-ZZ-0034 德式插座+防水 German socket + Waterproof belt ¥ :70.00		OB-ZZ-0042 二位卫星插座 Double Satellite socket ¥ :105.00
	OB-ZZ-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C(20W) (horizontal) ¥ :278.00		OB-ZZ-0035 法式插座+防水 French socket + Waterproof belt ¥ :70.00		OB-ZZ-0043 电视卫星插座 Satellite and TV socket ¥ :90.00
	OB-ZZ-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :208.00		OB-ZZ-0036 电视插座 TV socket ¥ :70.00		OB-ZZ-0044 电话卫星插座 ¥:90.00 Satellite and telephone socket 电脑卫星插座 ¥:95.00 Satellite and computer socket
	OB-ZZ-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :278.00		OB-ZZ-0037 电话插座 ¥:70.00 telephone socket 电脑插座 ¥:80.00 computer socket		OB-ZZ-0045 二位USB插座 Double USB socket ¥ :190.00
	OB-ZZ-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :208.00		OB-ZZ-0038 二位电视插座 Double TV socket ¥ :80.00		OB-ZZ-0046 二位音响插座 Single audio socket ¥ :90.00
	OB-ZZ-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :208.00		OB-ZZ-0039 二位电话插座 ¥:80.00 Double telephone socket 二位电脑插座 ¥:90.00 Double computer socket 电话电脑插座 ¥:85.00 telephone+computer socket		OB-ZZ-0047 四位音响插座 Double audio socket ¥ :110.00
	OB-ZZ-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :84.00		OB-ZZ-0040 电视电话插座 ¥:80.00 TV + telephone socket 电视电脑插座 ¥:85.00 TV + computer socket		OB-ZZ-0048 紧急呼叫开关 Emergency call switch ¥ :160.00

OB-ZZ肤感金色/Skin feels gold

	OB-ZZ-0049 调光开关300W ¥:133.00 Dimming 300W 调光开关500W ¥:173.00 Dimming 500W 调光开关1000W ¥:203.00 Dimming 1000W 调光LED开关200W ¥:173.00 Dimming LED 200W		OB-ZZ-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :245.00		OB-ZZ-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :84.00
	OB-ZZ-0050 调速开关300W ¥:133.00 Speed 300W 调速开关500W ¥:173.00 Speed 500W		OB-ZZ-0058 剃须插座 Shaving socket ¥ :435.00		OB-ZZ-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :84.00
	OB-ZZ-0051 调音开关 Tuning switch(fire) ¥ :183.00		OB-ZZ-0059 空白面板 Blank plate ¥ :41.00		OB-ZZ-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :84.00
	OB-ZZ-0052 触摸延时开关 ¥:133.00 Touch delay switch 声光控延时开关 ¥:133.00 Sound-light controlled delay switch		OB-ZZ-0060 二位德式插座(单体) Double German socket(single) ¥ :88.00		OB-ZZ-0066 一位连体边框 One face frame ¥ :23.00
	OB-ZZ-0053 人体感应开关 Human body induction ¥ :243.00		OB-ZZ-0061 二位法式插座(单体) Double French socket (single) ¥ :88.00		OB-ZZ-0067 二位连体边框 Double face frame ¥ :60.00
	OB-ZZ-0054 叮咚门铃 Ding dong doorbell ¥ :173.00		OB-ZZ-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :353.00		OB-ZZ-0068 三位连体边框 Three face frame ¥ :95.00
	OB-ZZ-0055 插卡取电(机械式) ¥:235.00 Mechanical card for electricity 插卡取电(低频) ¥:365.00 Low frequency induction card for electricity 插卡取电(高频) ¥:495.00 High frequency induction card for electricity		OB-ZZ-0069 四位连体边框 four face frame ¥ :130.00		
	OB-ZZ-0056 凹型地脚灯 The footlights ¥ :145.00		OB-ZZ-0070 五位连体边框 five face frame ¥ :165.00		

OB-Z3

SERIES





肤感黑色
Skin feels Black




OB-Z3肤感黑色/Skin feels black

	OB-Z3-0071 20A红绿开关 20A Red and green switch ¥:128.00		OB-Z3-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:153.00		OB-Z3-0087 1/2 USB/TYPE-C+HDMI ¥:318.00
	OB-Z3-0072 空白出线孔 Blank outlet hole ¥:41.00		OB-Z3-0080 1/2 白板+白板 blank panel+blank panel ¥:46.00		OB-Z3-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:273.00
	OB-Z3-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:75.00		OB-Z3-0081 1/2 双HDMI 1/2 Dual HDMI ¥:363.00		OB-Z3-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:195.00
	OB-Z3-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:75.00		OB-Z3-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:240.00		OB-Z3-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:195.00
	OB-Z3-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:85.00		OB-Z3-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:240.00		OB-Z3-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:205.00
	OB-Z3-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:115.00		OB-Z3-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:250.00		OB-Z3-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:235.00
	OB-Z3-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:90.00		OB-Z3-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:280.00		OB-Z3-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:210.00
	OB-Z3-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:198.00		OB-Z3-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:255.00		








OB-Z3肤感黑色/Skin feels black

	OB-Z3-0001 一开单控开关 ¥:60.00 1 gang 1 way switch 一开双控开关 ¥:63.00 1 gang 2 way switch 一开多控开关 ¥:81.00 1 gang 3 way switch		OB-Z3-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:70.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:76.00		OB-Z3-0017 13A方角插座 13A square corner socket ¥:60.00
	OB-Z3-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:65.00 一开双控复位开关 1 gang 2 way Reset switch ¥:68.00		OB-Z3-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:80.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:86.00		OB-Z3-0018 德式插座 German socket ¥:60.00
	OB-Z3-0003 二开单控开关 ¥:70.00 2 gang 1 way switch 二开双控开关 ¥:76.00 2 gang 2 way switch		OB-Z3-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:80.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:89.00		OB-Z3-0019 法式插座 French socket ¥:60.00
	OB-Z3-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:80.00 二开双控复位开关 2 gang 2 way Reset switch ¥:86.00		OB-Z3-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:95.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:109.00		OB-Z3-0020 俄式插座 Russian socket ¥:60.00
	OB-Z3-0005 三开单控开关 ¥:80.00 3 gang 1 way switch 三开双控开关 ¥:89.00 3 gang 2 way switch		OB-Z3-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:65.00		OB-Z3-0021 德意式插座 German+Italian socket ¥:80.00
	OB-Z3-0006 三开单复位开关 ¥:95.00 3 gang 1 way Reset switch 三开双复位开关 ¥:109.00 3 gang 2 way Reset switch		OB-Z3-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:65.00		OB-Z3-0022 德式USB+Type-c German USB+Type-C ¥:220.00
	OB-Z3-0007 一开单控开关(荧光) ¥:60.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:63.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:81.00 1 gang 3 way switch(Fluorescent lamp)		OB-Z3-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:80.00		OB-Z3-0023 法式USB+Type-c French USB+Type-C ¥:220.00
	OB-Z3-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:65.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:68.00		OB-Z3-0016 多功能插座 Universal socket ¥:60.00		OB-Z3-0024 德式插座+二位USB 2 USB with German socket ¥:210.00

OB-Z3肤感黑色/Skin feels black

	OB-Z3-0025 法式插座+二位USB 2 USB with French socket ¥ :210.00		OB-Z3-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :84.00		OB-Z3-0041 卫星插座 Satellite socket ¥ :85.00
	OB-Z3-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :208.00		OB-Z3-0034 德式插座+防水 German socket + Waterproof belt ¥ :70.00		OB-Z3-0042 二位卫星插座 Double Satellite socket ¥ :105.00
	OB-Z3-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :278.00		OB-Z3-0035 法式插座+防水 French socket + Waterproof belt ¥ :70.00		OB-Z3-0043 电视卫星插座 Satellite and TV socket ¥ :90.00
	OB-Z3-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :208.00		OB-Z3-0036 电视插座 TV socket ¥ :70.00		OB-Z3-0044 电话卫星插座 ¥:90.00 Satellite and telephone socket 电脑卫星插座 ¥:95.00 Satellite and computer socket
	OB-Z3-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :278.00		OB-Z3-0037 电话插座 ¥:70.00 telephone socket 电脑插座 ¥:80.00 computer socket		OB-Z3-0045 二位USB插座 Double USB socket ¥ :190.00
	OB-Z3-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :208.00		OB-Z3-0038 二位电视插座 Double TV socket ¥ :80.00		OB-Z3-0046 二位音响插座 Single audio socket ¥ :90.00
	OB-Z3-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :208.00		OB-Z3-0039 二位电话插座 ¥:80.00 Double telephone socket 二位电脑插座 ¥:90.00 Double computer socket 电话电脑插座 ¥:85.00 telephone+computer socket		OB-Z3-0047 四位音响插座 Double audio socket ¥ :110.00
	OB-Z3-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :84.00		OB-Z3-0040 电视电话插座 ¥:80.00 TV + telephone socket 电视电脑插座 ¥:85.00 TV + computer socket		OB-Z3-0048 紧急呼叫开关 Emergency call switch ¥ :160.00

OB-Z3肤感黑色/Skin feels black

	OB-Z3-0049 调光开关300W ¥:133.00 Dimming 300W 调光开关500W ¥:173.00 Dimming 500W 调光开关1000W ¥:203.00 Dimming 1000W 调光LED开关200W ¥:173.00 Dimming LED 200W		OB-Z3-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :245.00		OB-Z3-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :84.00
	OB-Z3-0050 调速开关300W ¥:133.00 Speed 300W 调速开关500W ¥:173.00 Speed 500W		OB-Z3-0058 剃须插座 Shaving socket ¥ :435.00		OB-Z3-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :84.00
	OB-Z3-0051 调音开关 Tuning switch(fire) ¥ :183.00		OB-Z3-0059 空白面板 Blank plate ¥ :41.00		OB-Z3-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :84.00
	OB-Z3-0052 触摸延时开关 ¥:133.00 Touch delay switch 声光控延时开关 ¥:133.00 Sound-light controlled delay switch		OB-Z3-0060 二位德式插座(单体) Double German socket(single) ¥ :88.00		OB-Z3-0066 一位连体边框 One face frame ¥ :23.00
	OB-Z3-0053 人体感应开关 Human body induction ¥ :243.00		OB-Z3-0061 二位法式插座(单体) Double French socket (single) ¥ :88.00		OB-Z3-0067 二位连体边框 Double face frame ¥ :60.00
	OB-Z3-0054 叮咚门铃 Ding dong doorbell ¥ :173.00		OB-Z3-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :353.00		OB-Z3-0068 三位连体边框 Three face frame ¥ :95.00
	OB-Z3-0055 插卡取电(机械式) ¥:235.00 Mechanical card for electricity 插卡取电(低频) ¥:365.00 Low frequency induction card for electricity 插卡取电(高频) ¥:495.00 High frequency induction card for electricity		OB-Z3-0069 四位连体边框 four face frame ¥ :130.00		
	OB-Z3-0056 凹型地脚灯 The footlights ¥ :145.00		OB-Z3-0070 五位连体边框 five face frame ¥ :165.00		








OB-Z4

SERIES






肤感灰色
Skin feels Grey






OB-Z4肤感灰色/Skin feels grey

	OB-Z4-0071 20A红绿开关 20A Red and green switch ¥:128.00		OB-Z4-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:153.00		OB-Z4-0087 1/2 USB/TYPE-C+HDMI ¥:318.00
	OB-Z4-0072 空白出线孔 Blank outlet hole ¥:41.00		OB-Z4-0080 1/2 白板+白板 blank panel+blank panel ¥:46.00		OB-Z4-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:273.00
	OB-Z4-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:75.00		OB-Z4-0081 1/2 双HDMI 1/2 Dual HDMI ¥:363.00		OB-Z4-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:195.00
	OB-Z4-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:75.00		OB-Z4-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:240.00		OB-Z4-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:195.00
	OB-Z4-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:85.00		OB-Z4-0083 1/2 电话+ HDMI 1/2 telephone socket+1/2 HDMI socket ¥:240.00		OB-Z4-0091 1/2 电脑+ USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:205.00
	OB-Z4-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:115.00		OB-Z4-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:250.00		OB-Z4-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:235.00
	OB-Z4-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:90.00		OB-Z4-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:280.00		OB-Z4-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:210.00
	OB-Z4-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:198.00		OB-Z4-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:255.00		







OB-Z4肤感灰色/Skin feels grey

	OB-Z4-0001 一开单控开关 ¥:60.00 1 gang 1 way switch 一开双控开关 ¥:63.00 1 gang 2 way switch 一开多控开关 ¥:81.00 1 gang 3 way switch		OB-Z4-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:70.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:76.00		OB-Z4-0017 13A方角插座 13A square corner socket ¥:60.00
	OB-Z4-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:65.00 一开双控复位开关 1 gang 2 way Reset switch ¥:68.00		OB-Z4-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:80.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:86.00		OB-Z4-0018 德式插座 German socket ¥:60.00
	OB-Z4-0003 二开单控开关 ¥:70.00 2 gang 1 way switch 二开双控开关 ¥:76.00 2 gang 2 way switch		OB-Z4-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:80.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:89.00		OB-Z4-0019 法式插座 French socket ¥:60.00
	OB-Z4-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:80.00 二开双控复位开关 2 gang 2 way Reset switch ¥:86.00		OB-Z4-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:95.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:109.00		OB-Z4-0020 俄式插座 Russian socket ¥:60.00
	OB-Z4-0005 三开单控开关 ¥:80.00 3 gang 1 way switch 三开双控开关 ¥:89.00 3 gang 2 way switch		OB-Z4-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:65.00		OB-Z4-0021 德意式插座 German+Italian socket ¥:80.00
	OB-Z4-0006 三开单复位开关 ¥:95.00 3 gang 1 way Reset switch 三开双复位开关 ¥:109.00 3 gang 2 way Reset switch		OB-Z4-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:65.00		OB-Z4-0022 德式USB+Type-c German USB+Type-C ¥:220.00
	OB-Z4-0007 一开单控开关(荧光) ¥:60.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:63.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:81.00 1 gang 3 way switch(Fluorescent lamp)		OB-Z4-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:80.00		OB-Z4-0023 法式USB+Type-c French USB+Type-C ¥:220.00
	OB-Z4-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:65.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:68.00		OB-Z4-0016 多功能插座 Universal socket ¥:60.00		OB-Z4-0024 德式插座+二位USB 2 USB with German socket ¥:210.00

OB-Z4肤感灰色/Skin feels grey

	OB-Z4-0025 法式插座+二位USB 2 USB with French socket ¥ :210.00		OB-Z4-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :84.00		OB-Z4-0041 卫星插座 Satellite socket ¥ :85.00
	OB-Z4-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :208.00		OB-Z4-0034 德式插座+防水 German socket + Waterproof belt ¥ :70.00		OB-Z4-0042 二位卫星插座 Double Satellite socket ¥ :105.00
	OB-Z4-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :278.00		OB-Z4-0035 法式插座+防水 French socket + Waterproof belt ¥ :70.00		OB-Z4-0043 电视卫星插座 Satellite and TV socket ¥ :90.00
	OB-Z4-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :208.00		OB-Z4-0036 电视插座 TV socket ¥ :70.00		OB-Z4-0044 电话卫星插座 ¥:90.00 Satellite and telephone socket 电脑卫星插座 ¥:95.00 Satellite and computer socket
	OB-Z4-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :278.00		OB-Z4-0037 电话插座 ¥:70.00 telephone socket 电脑插座 ¥:80.00 computer socket		OB-Z4-0045 二位USB插座 Double USB socket ¥ :190.00
	OB-Z4-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :208.00		OB-Z4-0038 二位电视插座 Double TV socket ¥ :80.00		OB-Z4-0046 二位音响插座 Single audio socket ¥ :90.00
	OB-Z4-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :208.00		OB-Z4-0039 二位电话插座 ¥:80.00 Double telephone socket 二位电脑插座 ¥:90.00 Double computer socket 电话电脑插座 ¥:85.00 telephone+computer socket		OB-Z4-0047 四位音响插座 Double audio socket ¥ :110.00
	OB-Z4-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :84.00		OB-Z4-0040 电视电话插座 ¥:80.00 TV + telephone socket 电视电脑插座 ¥:85.00 TV + computer socket		OB-Z4-0048 紧急呼叫开关 Emergency call switch ¥ :160.00


OB-Z4肤感灰色/Skin feels grey

	OB-Z4-0049 调光开关300W ¥:133.00 Dimming 300W 调光开关500W ¥:173.00 Dimming 500W 调光开关1000W ¥:203.00 Dimming 1000W 调光LED开关200W ¥:173.00 Dimming LED 200W		OB-Z4-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :245.00		OB-Z4-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :84.00
	OB-Z4-0050 调速开关300W ¥:133.00 Speed 300W 调速开关500W ¥:173.00 Speed 500W		OB-Z4-0058 剃须插座 Shaving socket ¥ :435.00		OB-Z4-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :84.00
	OB-Z4-0051 调音开关 Tuning switch(fire) ¥ :183.00		OB-Z4-0059 空白面板 Blank plate ¥ :41.00		OB-Z4-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :84.00
	OB-Z4-0052 触摸延时开关 ¥:133.00 Touch delay switch 声光控延时开关 ¥:133.00 Sound-light controlled delay switch		OB-Z4-0060 二位德式插座(单体) Double German socket(single) ¥ :88.00		OB-Z4-0066 一位连体边框 One face frame ¥ :23.00
	OB-Z4-0053 人体感应开关 Human body induction ¥ :243.00		OB-Z4-0061 二位法式插座(单体) Double French socket (single) ¥ :88.00		OB-Z4-0067 二位连体边框 Double face frame ¥ :60.00
	OB-Z4-0054 叮咚门铃 Ding dong doorbell ¥ :173.00		OB-Z4-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :353.00		OB-Z4-0068 三位连体边框 Three face frame ¥ :95.00
	OB-Z4-0055 插卡取电(机械式) ¥:235.00 Mechanical card for electricity 插卡取电(低频) ¥:365.00 Low frequency induction card for electricity 插卡取电(高频) ¥:495.00 High frequency induction card for electricity		OB-Z4-0069 四位连体边框 four face frame ¥ :130.00		
	OB-Z4-0056 凹型地脚灯 The footlights ¥ :145.00		OB-Z4-0070 五位连体边框 five face frame ¥ :165.00		


OB-D1 SERIES

PC大按键白色

White large buttons of the PC




OB-D1PC白色/ PC white




OB-D1-0062
20A红绿开关
20A Red and green switch
¥:119.00




OB-D1-0063
空白出线孔
Blank outlet hole
¥:28.00




OB-D1-0064
1/2 电视插座+白板
1/2 TV socket+blank panel
¥:62.00




OB-D1-0065
1/2 电话插座+白板
1/2 telephone socket+blank panel
¥:62.00




OB-D1-0066
1/2 电脑插座+白板
1/2 computer socket+blank panel
¥:72.00



OB-D1-0067
1/2 电脑插座六类+白板
1/2 Computer socket(Cat6)
+blank panel
¥:102.00




OB-D1-0068
1/2 卫星插座+白板
1/2 satellite socket+blank panel
¥:77.00



OB-D1-0069
1/2 HDMI+白板
1/2 HDMI+blank panel
¥ 184.00



OB-D1-0070
1/2 USB+type-c10W+白板
1/2 USB+type-c10W+blank panel
¥:139.00



OB-D1-0071
1/2 白板+白板
blank panel+blank panel
¥:33.00



OB-D1-0072
1/2 双HDMI
1/2 Dual HDMI
¥:344.00



OB-D1-0073
1/2 电视+HDMI
1/2 TV socket+1/2 HDMI socket
¥:222.00



OB-D1-0074
1/2 电话+ HDMI
1/2 telephone socket+1/2
HDMI socket
¥:222.00



OB-D1-0075
1/2 电脑插座+ HDMI
1/2 computer socket+HDMI
¥:231.00



OB-D1-0076
1/2 电脑插座六类+ HDMI
1/2 computer socket(Cat6)+HDMI
¥:262.00



OB-D1-0077
1/2 卫星+ HDMI
1/2 satellite socket+HDMI
¥:237.00



OB-D1-0078
1/2 USB/TYPE-C+HDMI
¥:299.00



OB-D1-0079
二位1/2 USB/TYPE-C
Double 1/2 USB/TYPE-C
¥:254.00



OB-D1-0080
1/2 电视+USB/TYPE-C
1/2 TV socket+1/2USB/TYPE-C
¥:177.00



OB-D1-0081
1/2 电话+USB/TYPE-C
1/2 telephone socket+
1/2 USB/TYPE-C
¥:177.00



OB-D1-0082
1/2 电脑+ USB/TYPE-C
1/2 Computer socket+ USB/TYPE-C
¥:186.00



OB-D1-0083
1/2 电脑六类+USB/TYPE-C
1/2 Computer socket(Cat6)
+USB/TYPE-C
¥:217.00



OB-D1-0084
1/2 卫星+USB/TYPE-C
1/2 satellite socket+USB/TYPE-C
¥:192.00



OB-D1-0001
一开单控开关 ¥:47.00
1 gang 1 way switch
一开双控开关 ¥:50.00
1 gang 2 way switch
一开多控开关 ¥:68.00
1 gang 3 way switch



OB-D1-0002
一开单控复位开关
1 gang 1 way Reset switch
¥:52.00
一开双控复位开关
1 gang 2 way Reset switch
¥:55.00



OB-D1-0003
二开单控开关 ¥:57.00
2 gang 1 way switch
二开双控开关 ¥:63.00
2 gang 2 way switch



OB-D1-0004
二开单控复位开关
2 gang 1 way Reset switch
¥:67.00
二开双控复位开关
2 gang 2 way Reset switch
¥:73.00



OB-D1-0005
三开单控开关 ¥:67.00
3 gang 1 way switch
三开双控开关 ¥:76.00
3 gang 2 way switch



OB-D1-0006
三开单复位开关 ¥:82.00
3 gang 1 way Reset switch
三开双复位开关 ¥:91.00
3 gang 2 way Reset switch



OB-D1-0007
门铃开关
Doorbell switch
¥:52.00




OB-D1-0008
门禁开关
Gating switch
¥:52.00



OB-D1-0009
百叶窗升降开关
louwer window lifter switch
¥:67.00



OB-D1-0010
多功能插座
Universal socket
¥:47.00



OB-D1-0011
13A方角插座
13A square corner socket
¥:47.00



OB-D1-0012
德式插座
German socket
¥:47.00



OB-D1-0013
法式插座
French socket
¥:47.00



OB-D1-0014
俄式插座
Russian socket
¥:47.00



OB-D1-0015
德意式插座
German+Italian socket
¥:67.00



OB-D1-0016
德式USB+Type-c
German USB+Type-C
¥:207.00



OB-D1-0017
法式USB+Type-c
French USB+Type-C
¥:207.00



OB-D1-0018
德式插座+二位USB
2 USB with German socket
¥:197.00



OB-D1-0019
法式插座+二位USB
2 USB with French socket
¥:197.00



OB-D1-0020
德式插座USB+Type-C(横)(10W)
German socket USB+Type-C
(horizontal)(10W)
¥:194.00



OB-D1-0021
德式插座USB+Type-C(横)(20W)
German socket USB+Type-C
(horizontal)(20W)
¥:264.00



OB-D1-0022
法式插座USB+Type-C(横)(10W)
French socket USB+Type-C
(horizontal)(10W)
¥:194.00



OB-D1-0023
法式插座USB+Type-C(横)(20W)
French socket USB+Type-C
(horizontal)(20W)
¥:264.00



OB-D1-0024
德式插座带二位USB(横)
German socket with 2 USB
(horizontal)
¥:194.00

OB-D1PC白色/ PC white

	OB-D1-0025 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:194.00		OB-D1-0033 二位电话插座 ¥:67.00 Double telephone socket 二位电脑插座 ¥:77.00 Double computer socket 电话电脑插座 ¥:72.00 telephone+computer socket		OB-D1-0041 四位音响插座 Double audio socket ¥:97.00
	OB-D1-0026 德式透明防溅插座 German type transparent splash-proof socket ¥:70.00		OB-D1-0034 电视电话插座 ¥:67.00 TV + telephone socket 电视电脑插座 ¥:72.00 TV + computer socket		OB-D1-0042 紧急呼叫开关 Emergency call switch ¥:147.00
	OB-D1-0027 法式透明防溅插座 French transparent splash-proof socket ¥:70.00		OB-D1-0035 卫星插座 Satellite socket ¥:72.00		OB-D1-0043 调光开关300W ¥:120.00 Dimming 300W 调光开关500W ¥:160.00 Dimming 500W 调光开关1000W ¥:190.00 Dimming 1000W 调光LED开关200W ¥:160.00 Dimming LED 200W
	OB-D1-0028 德式插座+防水 German socket + Waterproof belt ¥:57.00		OB-D1-0036 二位卫星插座 Double Satellite socket ¥:92.00		OB-D1-0044 调速开关300W ¥:120.00 Speed 300W 调速开关500W ¥:160.00 Speed 500W
	OB-D1-0029 法式插座+防水 French socket + Waterproof belt ¥:57.00		OB-D1-0037 电视卫星插座 Satellite and TV socket ¥:77.00		OB-D1-0045 调音开关 Tuning switch (fire) ¥:170.00
	OB-D1-0030 电视插座 TV socket ¥:57.00		OB-D1-0038 电话卫星插座 ¥:77.00 Satellite and telephone socket 电脑卫星插座 ¥:82.00 Satellite and computer socket		OB-D1-0046 触摸延时开关 ¥:120.00 Touch delay switch 声光控延时开关 ¥:120.00 Sound-light controlled delay switch
	OB-D1-0031 电话插座 ¥:57.00 telephone socket 电脑插座 ¥:67.00 computer socket		OB-D1-0039 二位USB插座 Double USB socket ¥:177.00		OB-D1-0047 人体感应开关 Human body induction ¥:230.00
	OB-D1-0032 二位电视插座 Double TV socket ¥:67.00		OB-D1-0040 二位音响插座 Single audio socket ¥:77.00		OB-D1-0048 叮咚门铃 Ding dong doorbell ¥:160.00

OB-D1PC白色/ PC white

	OB-D1-0049 插卡取电(机械式) ¥:222.00 Mechanical card for electricity 插卡取电(低频) ¥:352.00 Low frequency induction card for electricity 插卡取电(高频) ¥:482.00 High frequency induction card for electricity		OB-D1-0050 凹型地脚灯 The footlights ¥:132.00		OB-D1-0051 凹型人体感应地脚灯 The human body induction footlights ¥:232.00
	OB-D1-0052 剃须插座 Shaving socket ¥:422.00		OB-D1-0053 空白面板 Blank plate ¥:28.00		OB-D1-0054 请勿打扰请勿清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:344.00
	OB-D1-0055 二位德式插座(单体) Double German socket(single) ¥:74.00		OB-D1-0056 二位法式插座(单体) Double French socket (single) ¥:74.00		OB-D1-0057 一位连体边框 One face frame ¥:14.00
	OB-D1-0058 二位连体边框 Double face frame ¥:29.00		OB-D1-0060 四位连体边框 four face frame ¥:63.00		OB-D1-0061 五位连体边框 five face frame ¥:80.00
	OB-D1-0059 三位连体边框 Three face frame ¥:46.00				




OB-D2 SERIES

喷漆大按键金色


Gold-colored large paint-button



OB-D2 喷漆大按键金色/ Gold large paint-button

	OB-D2-0062 1/2 USB+type-c10W+白板 20A Red and green switch ¥:128.00		OB-D2-0070 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:153.00		OB-D2-0078 1/2 USB/TYPE-C+HDMI ¥:318.00
	OB-D2-0063 空白出线孔 Blank outlet hole ¥:41.00		OB-D2-0071 1/2 白板+白板 blank panel+blank panel ¥:46.00		OB-D2-0079 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:273.00
	OB-D2-0064 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:75.00		OB-D2-0072 1/2 双HDMI 1/2 Dual HDMI ¥:363.00		OB-D2-0080 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:195.00
	OB-D2-0065 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:75.00		OB-D2-0073 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:240.00		OB-D2-0081 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:195.00
	OB-D2-0066 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:85.00		OB-D2-0074 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:240.00		OB-D2-0082 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:205.00
	OB-D2-0067 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:115.00		OB-D2-0075 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:250.00		OB-D2-0083 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:235.00
	OB-D2-0068 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:90.00		OB-D2-0076 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:280.00		OB-D2-0084 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:210.00
	OB-D2-0069 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:198.00		OB-D2-0077 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:255.00		

OB-D2 喷漆大按键金色/ Gold large paint-button

	OB-D2-0001 一开单控开关 ¥:60.00 1 gang 1 way switch 一开双控开关 ¥:63.00 1 gang 2 way switch 一开多控开关 ¥:81.00 1 gang 3 way switch		OB-D2-0009 百叶窗升降开关 louver window lifter switch ¥:80.00		OB-D2-0017 法式USB+Type-c French USB+Type-C ¥:220.00
	OB-D2-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:65.00 一开双控复位开关 1 gang 2 way Reset switch ¥:68.00		OB-D2-0010 多功能插座 Universal socket ¥:60.00		OB-D2-0018 德式插座+二位USB 2 USB with German socket ¥:210.00
	OB-D2-0003 二开单控开关 ¥:70.00 2 gang 1 way switch 二开双控开关 ¥:76.00 2 gang 2 way switch		OB-D2-0011 13A方角插座 13A square corner socket ¥:60.00		OB-D2-0019 法式插座+二位USB 2 USB with French socket ¥:210.00
	OB-D2-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:80.00 二开双控复位开关 2 gang 2 way Reset switch ¥:86.00		OB-D2-0012 德式插座 German socket ¥:60.00		OB-D2-0020 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:208.00
	OB-D2-0005 三开单控开关 ¥:80.00 3 gang 1 way switch 三开双控开关 ¥:89.00 3 gang 2 way switch		OB-D2-0013 法式插座 French socket ¥:60.00		OB-D2-0021 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥:278.00
	OB-D2-0006 三开单复位开关 ¥:95.00 3 gang 1 way Reset switch 三开双复位开关 ¥:109.00 3 gang 2 way Reset switch		OB-D2-0014 俄式插座 Russian socket ¥:60.00		OB-D2-0022 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:208.00
	OB-D2-0007 门铃开关 Doorbell switch ¥:65.00		OB-D2-0015 德意式插座 German+Italian socket ¥:80.00		OB-D2-0023 法式插座USB+Type-C(20W) French socket USB+Type-C (horizontal)(20W) ¥:278.00
	OB-D2-0008 门禁开关 Gating switch ¥:65.00		OB-D2-0016 德式USB+Type-c German USB+Type-C ¥:220.00		OB-D2-0024 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:208.00

OB-D2 喷漆大按键金色/ Gold large paint-button

	OB-D2-0025 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:208.00		OB-D2-0033 二位电话插座 ¥:80.00 Double telephone socket 二位电脑插座 ¥:90.00 Double computer socket 电话电脑插座 ¥:85.00 telephone+computer socket		OB-D2-0041 四位音响插座 Double audio socket ¥:110.00
	OB-D2-0026 德式透明防溅插座 German type transparent splash-proof socket ¥:84.00		OB-D2-0034 电视电话插座 ¥:80.00 TV + telephone socket 电视电脑插座 ¥:85.00 TV + computer socket		OB-D2-0042 紧急呼叫开关 Emergency call switch ¥:160.00
	OB-D2-0027 法式透明防溅插座 French transparent splash-proof socket ¥:84.00		OB-D2-0035 卫星插座 Satellite socket ¥:85.00		OB-D2-0043 调光开关300W ¥:133.00 Dimming 300W 调光开关500W ¥:173.00 Dimming 500W 调光开关1000W ¥:203.00 Dimming 1000W 调光LED开关200W ¥:173.00 Dimming LED 200W
	OB-D2-0028 德式插座+防水 German socket + Waterproof belt ¥:70.00		OB-D2-0036 二位卫星插座 Double Satellite socket ¥:105.00		OB-D2-0044 调速开关300W ¥:133.00 Speed 300W 调速开关500W ¥:173.00 Speed 500W
	OB-D2-0029 法式插座+防水 French socket + Waterproof belt ¥:70.00		OB-D2-0037 电视卫星插座 Satellite and TV socket ¥:90.00		OB-D2-0045 调音开关 Tuning switch(fire) ¥:183.00
	OB-D2-0030 电视插座 TV socket ¥:70.00		OB-D2-0038 电话卫星插座 ¥:90.00 Satellite and telephone socket 电脑卫星插座 ¥:95.00 Satellite and computer socket		OB-D2-0046 触摸延时开关 ¥:133.00 Touch delay switch 声光控延时开关 ¥:133.00 Sound-light controlled delay switch
	OB-D2-0031 电话插座 ¥:70.00 telephone socket 电脑插座 ¥:80.00 computer socket		OB-D2-0039 二位USB插座 Double USB socket ¥:190.00		OB-D2-0047 人体感应开关 Human body induction ¥:243.00
	OB-D2-0032 二位电视插座 Double TV socket ¥:80.00		OB-D2-0040 二位音响插座 Single audio socket ¥:90.00		OB-D2-0048 叮咚门铃 Ding dong doorbell ¥:173.00

OB-D2 喷漆大按键金色/ Gold large paint-button

	OB-D2-0049 插卡取电(机械式) ¥:235.00 Mechanical card for electricity 插卡取电(低频) ¥:365.00 Low frequency induction card for electricity 插卡取电(高频) ¥:495.00 High frequency induction card for electricity		OB-D2-0050 凹型地脚灯 The footlights ¥:145.00		OB-D2-0051 凹型人体感应地脚灯 The human body induction footlights ¥:245.00
	OB-D2-0052 剃须插座 Shaving socket ¥:435.00		OB-D2-0053 空白面板 Blank plate ¥:41.00		OB-D2-0054 请勿打扰请即清理 门铃开关(触模式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:353.00
	OB-D2-0055 二位德式插座(单体) Double German socket(single) ¥:88.00		OB-D2-0056 二位法式插座(单体) Double French socket (single) ¥:88.00		OB-D2-0057 一位连体边框 One face frame ¥:23.00
	OB-D2-0058 二位连体边框 Double face frame ¥:60.00		OB-D2-0060 四位连体边框 four face frame ¥:130.00		OB-D2-0061 五位连体边框 five face frame ¥:165.00
	OB-D2-0059 三位连体边框 Three face frame ¥:95.00				

OB-D3 SERIES

喷漆大按键黑色
Black large paint-button



OB-D3 喷漆大按键黑色/ Black large paint-button

	OB-D3-0062 20A红绿开关 20A Red and green switch ¥:128.00		OB-D3-0070 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:153.00		OB-D3-0078 1/2 USB/TYPE-C+HDMI ¥:318.00
	OB-D3-0063 空白出线孔 Blank outlet hole ¥:41.00		OB-D3-0071 1/2 白板+白板 blank panel+blank panel ¥:46.00		OB-D3-0079 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:273.00
	OB-D3-0064 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:75.00		OB-D3-0072 1/2 双HDMI 1/2 Dual HDMI ¥:363.00		OB-D3-0080 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:195.00
	OB-D3-0065 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:75.00		OB-D3-0073 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:240.00		OB-D3-0081 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:195.00
	OB-D3-0066 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:85.00		OB-D3-0074 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:240.00		OB-D3-0082 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:205.00
	OB-D3-0067 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:115.00		OB-D3-0075 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:250.00		OB-D3-0083 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:235.00
	OB-D3-0068 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:90.00		OB-D3-0076 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:280.00		OB-D3-0084 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:210.00
	OB-D3-0069 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:198.00		OB-D3-0077 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:255.00		

OB-D3 喷漆大按键黑色/ Black large paint-button

	OB-D3-0001 一开单控开关 ¥:60.00 1 gang 1 way switch 一开双控开关 ¥:63.00 1 gang 2 way switch 一开多控开关 ¥:81.00 1 gang 3 way switch		OB-D3-0009 百叶窗升降开关 louwer window lifter switch ¥:80.00		OB-D3-0017 法式USB+Type-c French USB+Type-C ¥:220.00
	OB-D3-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:65.00 一开双控复位开关 1 gang 2 way Reset switch ¥:68.00		OB-D3-0010 多功能插座 Universal socket ¥:60.00		OB-D3-0018 德式插座+二位USB 2 USB with German socket ¥:210.00
	OB-D3-0003 二开单控开关 ¥:70.00 2 gang 1 way switch 二开双控开关 ¥:76.00 2 gang 2 way switch		OB-D3-0011 13A方角插座 13A square corner socket ¥:60.00		OB-D3-0019 法式插座+二位USB 2 USB with French socket ¥:210.00
	OB-D3-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:80.00 二开双控复位开关 2 gang 2 way Reset switch ¥:86.00		OB-D3-0012 德式插座 German socket ¥:60.00		OB-D3-0020 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:208.00
	OB-D3-0005 三开单控开关 ¥:80.00 3 gang 1 way switch 三开双控开关 ¥:89.00 3 gang 2 way switch		OB-D3-0013 法式插座 French socket ¥:60.00		OB-D3-0021 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥:278.00
	OB-D3-0006 三开单复位开关 ¥:95.00 3 gang 1 way Reset switch 三开双复位开关 ¥:109.00 3 gang 2 way Reset switch		OB-D3-0014 俄式插座 Russian socket ¥:60.00		OB-D3-0022 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:208.00
	OB-D3-0007 门铃开关 Doorbell switch ¥:65.00		OB-D3-0015 德意式插座 German+Italian socket ¥:80.00		OB-D3-0023 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥:278.00
	OB-D3-0008 门禁开关 Gating switch ¥:65.00		OB-D3-0016 德式USB+Type-c German USB+Type-C ¥:220.00		OB-D3-0024 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:208.00

OB-D3 喷漆大按键黑色/ Black large paint-button

	OB-D3-0025 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:208.00		OB-D3-0033 二位电话插座 ¥:80.00 Double telephone socket 二位电脑插座 ¥:90.00 Double computer socket 电话电脑插座 ¥:85.00 telephone+computer socket		OB-D3-0041 四位音响插座 Double audio socket ¥:110.00
	OB-D3-0026 德式透明防溅插座 German type transparent splash-proof socket ¥:84.00		OB-D3-0034 电视电话插座 ¥:80.00 TV + telephone socket 电视电脑插座 ¥:85.00 TV + computer socket		OB-D3-0042 紧急呼叫开关 Emergency call switch ¥:160.00
	OB-D3-0027 法式透明防溅插座 French transparent splash-proof socket ¥:84.00		OB-D3-0035 卫星插座 Satellite socket ¥:85.00		OB-D3-0043 调光开关300W ¥:133.00 Dimming 300W 调光开关500W ¥:173.00 Dimming 500W 调光开关1000W ¥:203.00 Dimming 1000W 调光LED开关200W ¥:173.00 Dimming LED 200W
	OB-D3-0028 德式插座+防水 German socket + Waterproof belt ¥:70.00		OB-D3-0036 二位卫星插座 Double Satellite socket ¥:105.00		OB-D3-0044 调速开关300W ¥:133.00 Speed 300W 调速开关500W ¥:173.00 Speed 500W
	OB-D3-0029 法式插座+防水 French socket + Waterproof belt ¥:70.00		OB-D3-0037 电视卫星插座 Satellite and TV socket ¥:90.00		OB-D3-0045 调音开关 Tuning switch(fire) ¥:183.00
	OB-D3-0030 电视插座 TV socket ¥:70.00		OB-D3-0038 电话卫星插座 ¥:90.00 Satellite and telephone socket 电脑卫星插座 ¥:95.00 Satellite and computer socket		OB-D3-0046 触摸延时开关 ¥:133.00 Touch delay switch 声光控延时开关 ¥:133.00 Sound-light controlled delay switch
	OB-D3-0031 电话插座 ¥:70.00 telephone socket 电脑插座 ¥:80.00 computer socket		OB-D3-0039 二位USB插座 Double USB socket ¥:190.00		OB-D3-0047 人体感应开关 Human body induction ¥:243.00
	OB-D3-0032 二位电视插座 Double TV socket ¥:80.00		OB-D3-0040 二位音响插座 Single audio socket ¥:90.00		OB-D3-0048 叮咚门铃 Ding dong doorbell ¥:173.00


OB-D3 喷漆大按键黑色/ Black large paint-button

	OB-D3-0049 插卡取电(机械式) ¥:235.00 Mechanical card for electricity 插卡取电(低频) ¥:365.00 Low frequency induction card for electricity 插卡取电(高频) ¥:495.00 High frequency induction card for electricity		OB-D3-0050 凹型地脚灯 The footlights ¥:145.00		OB-D3-0051 凹型人体感应地脚灯 The human body induction footlights ¥:245.00
	OB-D3-0052 剃须插座 Shaving socket ¥:435.00		OB-D3-0053 空白面板 Blank plate ¥:41.00		OB-D3-0054 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:353.00
	OB-D3-0055 二位德式插座(单体) Double German socket(single) ¥:88.00		OB-D3-0056 二位法式插座(单体) Double French socket (single) ¥:88.00		OB-D3-0057 一位连体边框 One face frame ¥:23.00
	OB-D3-0058 二位连体边框 Double face frame ¥:60.00		OB-D3-0060 四位连体边框 four face frame ¥:130.00		OB-D3-0061 五位连体边框 five face frame ¥:165.00
	OB-D3-0059 三位连体边框 Three face frame ¥:95.00				


OB-D4 SERIES

喷漆大按键灰色

The large paint-button is gray.




OB-D4 喷漆大按键灰色/ Grey large paint-button



OB-D4-0062
20A红绿开关
20A Red and green switch
¥:128.00




OB-D4-0063
空白出线孔
Blank outlet hole
¥:41.00




OB-D4-0064
1/2 电视插座+白板
1/2 TV socket+blank panel
¥:75.00




OB-D4-0065
1/2 电话插座+白板
1/2 telephone socket+blank panel
¥:75.00



OB-D4-0066
1/2 电脑插座+白板
1/2 computer socket+blank panel
¥:85.00



OB-D4-0067
1/2 电脑插座六类+白板
1/2 Computer socket(Cat6)
+blank panel
¥:115.00




OB-D4-0068
1/2 卫星插座+白板
1/2 satellite socket+blank panel
¥:90.00



OB-D4-0069
1/2 HDMI+白板
1/2 HDMI+blank panel
¥:198.00



OB-D4-0070
1/2 USB+type-c10W+白板
1/2 USB+type-c10W+blank panel
¥:153.00



OB-D4-0071
1/2 白板+白板
blank panel+blank panel
¥:46.00



OB-D4-0072
1/2 双HDMI
1/2 Dual HDMI
¥:363.00



OB-D4-0073
1/2 电视+HDMI
1/2 TV socket+1/2 HDMI socket
¥:240.00



OB-D4-0074
1/2 电话+HDMI
1/2 telephone socket+1/2
HDMI socket
¥:240.00



OB-D4-0075
1/2 电脑插座+HDMI
1/2 computer socket+HDMI
¥:250.00



OB-D4-0076
1/2 电脑插座六类+HDMI
1/2 Computer socket(Cat6)+HDMI
¥:280.00



OB-D4-0077
1/2 卫星+HDMI
1/2 satellite socket+HDMI
¥:255.00



OB-D4-0078
1/2 USB/TYPE-C+HDMI
¥:318.00



OB-D4-0079
二位1/2 USB/TYPE-C
Double 1/2 USB/TYPE-C
¥:273.00



OB-D4-0080
1/2 电视+USB/TYPE-C
1/2 TV socket+1/2USB/TYPE-C
¥:195.00



OB-D4-0081
1/2 电话+USB/TYPE-C
1/2 telephone socket+
1/2 USB/TYPE-C
¥:195.00



OB-D4-0082
1/2 电脑+USB/TYPE-C
1/2 Computer socket+ USB/TYPE-C
¥:205.00



OB-D4-0083
1/2 电脑六类+USB/TYPE-C
1/2 Computer socket(Cat6)
+USB/TYPE-C
¥:235.00



OB-D4-0084
1/2 卫星+USB/TYPE-C
1/2 satellite socket+USB/TYPE-C
¥:210.00

OB-D4 喷漆大按键灰色/ Grey large paint-button



OB-D4-0001
一开单控开关 ¥:60.00
1 gang 1 way switch
一开双控开关 ¥:63.00
1 gang 2 way switch
一开多控开关 ¥:81.00
1 gang 3 way switch



OB-D4-0002
一开单控复位开关
1 gang 1 way Reset switch
¥:65.00
一开双控复位开关
1 gang 2 way Reset switch
¥:68.00



OB-D4-0003
二开单控开关 ¥:70.00
2 gang 1 way switch
二开双控开关 ¥:76.00
2 gang 2 way switch



OB-D4-0004
二开单控复位开关
2 gang 1 way Reset switch
¥:80.00
二开双控复位开关
2 gang 2 way Reset switch
¥:86.00



OB-D4-0005
三开单控开关 ¥:80.00
3 gang 1 way switch
三开双控开关 ¥:89.00
3 gang 2 way switch



OB-D4-0006
三开单复位开关 ¥:95.00
3 gang 1 way Reset switch
三开双复位开关 ¥:109.00
3 gang 2 way Reset switch



OB-D4-0007
门铃开关
Doorbell switch
¥:65.00



OB-D4-0008
门禁开关
Gating switch
¥:65.00



OB-D4-0009
百叶窗升降开关
louver window lifter switch
¥:80.00



OB-D4-0010
多功能插座
Universal socket
¥:60.00



OB-D4-0011
13A方角插座
13A square corner socket
¥:60.00



OB-D4-0012
德式插座
German socket
¥:60.00



OB-D4-0013
法式插座
French socket
¥:60.00



OB-D4-0014
俄式插座
Russian socket
¥:60.00



OB-D4-0015
德意式插座
German+Italian socket
¥:80.00



OB-D4-0016
德式USB+Type-c
German USB+Type-C
¥:220.00



OB-D4-0017
法式USB+Type-c
French USB+Type-C
¥:220.00



OB-D4-0018
德式插座+二位USB
2 USB with German socket
¥:210.00



OB-D4-0019
法式插座+二位USB
2 USB with French socket
¥:210.00



OB-D4-0020
德式插座USB+Type-C(横)(10W)
German socket USB+Type-C
(horizontal)(10W)
¥:208.00



OB-D4-0021
德式插座USB+Type-C(横)(20W)
German socket USB+Type-C
(horizontal)(20W)
¥:278.00



OB-D4-0022
法式插座USB+Type-C(横)(10W)
French socket USB+Type-C
(horizontal)(10W)
¥:208.00



OB-D4-0023
法式插座USB+Type-C(20W)
French socket USB+Type-C
(horizontal)(20W)
¥:278.00



OB-D4-0024
德式插座带二位USB(横)
German socket with 2 USB
(horizontal)
¥:208.00

OB-D4 喷漆大按键灰色/ Grey large paint-button

	OB-D4-0025 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:208.00		OB-D4-0033 二位电话插座 ¥:80.00 Double telephone socket 二位电脑插座 ¥:90.00 Double computer socket 电话电脑插座 ¥:85.00 telephone+computer socket		OB-D4-0041 四位音响插座 Double audio socket ¥:110.00
	OB-D4-0026 德式透明防溅插座 German type transparent splash-proof socket ¥:84.00		OB-D4-0034 电视电话插座 ¥:80.00 TV + telephone socket 电视电脑插座 ¥:85.00 TV + computer socket		OB-D4-0042 紧急呼叫开关 Emergency call switch ¥:160.00
	OB-D4-0027 法式透明防溅插座 French transparent splash-proof socket ¥:84.00		OB-D4-0035 卫星插座 Satellite socket ¥:85.00		OB-D4-0043 调光开关300W ¥:133.00 Dimming 300W 调光开关500W ¥:173.00 Dimming 500W 调光开关1000W ¥:203.00 Dimming 1000W 调光LED开关200W ¥:173.00 Dimming LED 200W
	OB-D4-0028 德式插座+防水 German socket + Waterproof belt ¥:70.00		OB-D4-0036 二位卫星插座 Double Satellite socket ¥:105.00		OB-D4-0044 调速开关300W ¥:133.00 Speed 300W 调速开关500W ¥:173.00 Speed 500W
	OB-D4-0029 法式插座+防水 French socket + Waterproof belt ¥:70.00		OB-D4-0037 电视卫星插座 Satellite and TV socket ¥:90.00		OB-D4-0045 调音开关 Tuning switch(fire) ¥:183.00
	OB-D4-0030 电视插座 TV socket ¥:70.00		OB-D4-0038 电话卫星插座 ¥:90.00 Satellite and telephone socket 电脑卫星插座 ¥:95.00 Satellite and computer socket		OB-D4-0046 触摸延时开关 ¥:133.00 Touch delay switch 声光控延时开关 ¥:133.00 Sound-light controlled delay switch
	OB-D4-0031 电话插座 ¥:70.00 telephone socket 电脑插座 ¥:80.00 computer socket		OB-D4-0039 二位USB插座 Double USB socket ¥:190.00		OB-D4-0047 人体感应开关 Human body induction ¥:243.00
	OB-D4-0032 二位电视插座 Double TV socket ¥:80.00		OB-D4-0040 二位音响插座 Single audio socket ¥:90.00		OB-D4-0048 叮咚门铃 Ding dong doorbell ¥:173.00

OB-D4 喷漆大按键灰色/ Grey large paint-button

	OB-D4-0049 插卡取电(机械式) ¥:235.00 Mechanical card for electricity 插卡取电(低频) ¥:365.00 Low frequency induction card for electricity 插卡取电(高频) ¥:495.00 High frequency induction card for electricity		OB-D4-0050 凹型地脚灯 The footlights ¥:145.00		OB-D4-0051 凹型人体感应地脚灯 The human body induction footlights ¥:245.00
	OB-D4-0052 剃须插座 Shaving socket ¥:435.00		OB-D4-0053 空白面板 Blank plate ¥:41.00		OB-D4-0054 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:353.00
	OB-D4-0055 二位德式插座(单体) Double German socket(single) ¥:88.00		OB-D4-0056 二位法式插座(单体) Double French socket (single) ¥:88.00		OB-D4-0057 一位连体边框 One face frame ¥:23.00
	OB-D4-0058 二位连体边框 Double face frame ¥:60.00		OB-D4-0060 四位连体边框 four face frame ¥:130.00		
	OB-D4-0059 三位连体边框 Three face frame ¥:95.00		OB-D4-0061 五位连体边框 five face frame ¥:165.00		

OB-L1








SERIES

超薄铝镁银拉丝








Ultra-thin aluminum-magnesium-silver
brushed finish








OB-L1 铝镁银拉丝/ Aluminum magnesium silver drawing

	OB-L1-0071 20A红绿开关 20A Red and green switch ¥:165.00		OB-L1-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:190.00		OB-L1-0087 1/2 USB/TYPE-C+HDMI ¥:355.00
	OB-L1-0072 空白出线孔 Blank outlet hole ¥:78.00		OB-L1-0080 1/2 白板+白板 blank panel+blank panel ¥:83.00		OB-L1-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:310.00
	OB-L1-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:112.00		OB-L1-0081 1/2 双HDMI 1/2 Dual HDMI ¥:400.00		OB-L1-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:232.00
	OB-L1-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:112.00		OB-L1-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:277.00		OB-L1-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:232.00
	OB-L1-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:122.00		OB-L1-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:277.00		OB-L1-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:242.00
	OB-L1-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:152.00		OB-L1-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:287.00		OB-L1-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:272.00
	OB-L1-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:127.00		OB-L1-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:317.00		OB-L1-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:247.00
	OB-L1-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:235.00		OB-L1-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:292.00		








OB-L1 铝镁银拉丝/ Aluminum magnesium silver drawing

	OB-L1-0001 一开单控开关 ¥:97.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:100.00 1 gang 2 way switch 一开多控开关 ¥:118.00 1 gang 3 way switch		OB-L1-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:107.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:113.00		OB-L1-0017 13A方角插座 13A square corner socket ¥:97.00
	OB-L1-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:102.00 一开双控复位开关 1 gang 2 way Reset switch ¥:105.00		OB-L1-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:117.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:123.00		OB-L1-0018 德式插座 German socket ¥:97.00
	OB-L1-0003 二开单控开关 ¥:107.00 2 gang 1 way switch 二开双控开关 ¥:113.00 2 gang 2 way switch		OB-L1-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:117.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:126.00		OB-L1-0019 法式插座 French socket ¥:97.00
	OB-L1-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:117.00 二开双控复位开关 2 gang 2 way Reset switch ¥:123.00		OB-L1-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:132.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:141.00		OB-L1-0020 俄式插座 Russian socket ¥:97.00
	OB-L1-0005 三开单控开关 ¥:117.00 3 gang 1 way switch 三开双控开关 ¥:126.00 3 gang 2 way switch		OB-L1-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:102.00		OB-L1-0021 德意式插座 German+Italian socket ¥:117.00
	OB-L1-0006 三开单复位开关 ¥:132.00 3 gang 1 way Reset switch 三开双复位开关 ¥:141.00 3 gang 2 way Reset switch		OB-L1-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:102.00		OB-L1-0022 德式USB+Type-c German USB+Type-C ¥:257.00
	OB-L1-0007 一开单控开关(荧光) ¥:97.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:100.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:118.00 1 gang 3 way switch(Fluorescent lamp)		OB-L1-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:117.00		OB-L1-0023 法式USB+Type-c French USB+Type-C ¥:257.00
	OB-L1-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:102.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:105.00		OB-L1-0016 多功能插座 Universal socket ¥:97.00		OB-L1-0024 德式插座+二位USB 2 USB with German socket ¥:247.00

OB-L1 铝镁银拉丝/ Aluminum magnesium silver drawing

	OB-L1-0025 法式插座+二位USB 2 USB with French socket ¥ :247.00		OB-L1-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :121.00		OB-L1-0041 卫星插座 Satellite socket ¥ :122.00
	OB-L1-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :245.00		OB-L1-0034 德式插座+防水 German socket + Waterproof belt ¥ :107.00		OB-L1-0042 二位卫星插座 Double Satellite socket ¥ :142.00
	OB-L1-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C(20W) (horizontal) ¥ :315.00		OB-L1-0035 法式插座+防水 French socket + Waterproof belt ¥ :107.00		OB-L1-0043 电视卫星插座 Satellite and TV socket ¥ :127.00
	OB-L1-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :245.00		OB-L1-0036 电视插座 TV socket ¥ :107.00		OB-L1-0044 电话卫星插座 ¥ :127.00 Satellite and telephone socket 电脑卫星插座 ¥ :132.00 Satellite and computer socket
	OB-L1-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :315.00		OB-L1-0037 电话插座 ¥ :107.00 telephone socket 电脑插座 ¥ :117.00 computer socket		OB-L1-0045 二位USB插座 Double USB socket ¥ :227.00
	OB-L1-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :245.00		OB-L1-0038 二位电视插座 Double TV socket ¥ :117.00		OB-L1-0046 二位音响插座 Single audio socket ¥ :127.00
	OB-L1-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :245.00		OB-L1-0039 二位电话插座 ¥ :117.00 Double telephone socket 二位电脑插座 ¥ :127.00 Double computer socket 电话电脑插座 ¥ :122.00 telephone+computer socket		OB-L1-0047 四位音响插座 Double audio socket ¥ :147.00
	OB-L1-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :121.00		OB-L1-0040 电视电话插座 ¥ :117.00 TV + telephone socket 电视电脑插座 ¥ :122.00 TV + computer socket		OB-L1-0048 紧急呼叫开关 Emergency call switch ¥ :197.00

OB-L1 铝镁银拉丝/ Aluminum magnesium silver drawing

	OB-L1-0049 调光开关300W ¥ :170.00 Dimming 300W 调光开关500W ¥ :210.00 Dimming 500W 调光开关1000W ¥ :240.00 Dimming 1000W 调光LED开关200W ¥ :210.00 Dimming LED 200W		OB-L1-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :282.00		OB-L1-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :121.00
	OB-L1-0050 调速开关300W ¥ :170.00 Speed 300W 调速开关500W ¥ :210.00 Speed 500W		OB-L1-0058 剃须插座 Shaving socket ¥ :472.00		OB-L1-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :121.00
	OB-L1-0051 调音开关 Tuning switch(fire) ¥ :220.00		OB-L1-0059 空白面板 Blank plate ¥ :78.00		OB-L1-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :121.00
	OB-L1-0052 触摸延时开关 ¥ :170.00 Touch delay switch 声光控延时开关 ¥ :170.00 Sound-light controlled delay switch		OB-L1-0060 二位德式插座(单体) Double German socket(single) ¥ :125.00		OB-L1-0066 一位连体边框 one face frame ¥ :60.00
	OB-L1-0053 人体感应开关 Human body induction ¥ :280.00		OB-L1-0061 二位法式插座(单体) Double French socket (single) ¥ :125.00		OB-L1-0067 二位连体边框 Double face frame ¥ :160.00
	OB-L1-0054 叮咚门铃 Ding dong doorbell ¥ :210.00		OB-L1-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :390.00		OB-L1-0068 三位连体边框 Three face frame ¥ :240.00
	OB-L1-0055 插卡取电(机械式) ¥ :272.00 Mechanical card for electricity 插卡取电(低频) ¥ :402.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :532.00 High frequency induction card for electricity		OB-L1-0069 四位连体边框 four face frame ¥ :320.00		
	OB-L1-0056 凹型地脚灯 The footlights ¥ :182.00		OB-L1-0070 五位连体边框 five face frame ¥ :400.00		

OB-L2


SERIES

超薄铝镁金拉丝




Ultra-thin aluminum-magnesium-gold
brushed finish





OB-L2 铝镁拉丝金/ Aluminum magnesium gold drawing

	OB-L2-0071 20A红绿开关 20A Red and green switch ¥:165.00		OB-L2-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:190.00		OB-L2-0087 1/2 USB/TYPE-C+HDMI ¥:355.00
	OB-L2-0072 空白出线孔 Blank outlet hole ¥:78.00		OB-L2-0080 1/2 白板+白板 blank panel+blank panel ¥:83.00		OB-L2-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:310.00
	OB-L2-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:112.00		OB-L2-0081 1/2 双HDMI 1/2 Dual HDMI ¥:400.00		OB-L2-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:232.00
	OB-L2-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:112.00		OB-L2-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:277.00		OB-L2-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:232.00
	OB-L2-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:122.00		OB-L2-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:277.00		OB-L2-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:242.00
	OB-L2-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:152.00		OB-L2-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:287.00		OB-L2-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:272.00
	OB-L2-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:127.00		OB-L2-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:317.00		OB-L2-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:247.00
	OB-L2-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:235.00		OB-L2-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:292.00		









OB-L2 铝镁拉丝金/ Aluminum magnesium gold drawing

	OB-L2-0001 一开单控开关 ¥:97.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:100.00 1 gang 2 way switch 一开多控开关 ¥:118.00 1 gang 3 way switch		OB-L2-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:107.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:113.00		OB-L2-0017 13A方角插座 13A square corner socket ¥:97.00
	OB-L2-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:102.00 一开双控复位开关 1 gang 2 way Reset switch ¥:105.00		OB-L2-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:117.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:123.00		OB-L2-0018 德式插座 German socket ¥:97.00
	OB-L2-0003 二开单控开关 ¥:107.00 2 gang 1 way switch 二开双控开关 ¥:113.00 2 gang 2 way switch		OB-L2-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:117.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:126.00		OB-L2-0019 法式插座 French socket ¥:97.00
	OB-L2-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:117.00 二开双控复位开关 2 gang 2 way Reset switch ¥:123.00		OB-L2-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:132.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:141.00		OB-L2-0020 俄式插座 Russian socket ¥:97.00
	OB-L2-0005 三开单控开关 ¥:117.00 3 gang 1 way switch 三开双控开关 ¥:126.00 3 gang 2 way switch		OB-L2-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:102.00		OB-L2-0021 德意式插座 German+Italian socket ¥:117.00
	OB-L2-0006 三开单复位开关 ¥:132.00 3 gang 1 way Reset switch 三开双复位开关 ¥:141.00 3 gang 2 way Reset switch		OB-L2-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:102.00		OB-L2-0022 德式USB+Type-c German USB+Type-C ¥:257.00
	OB-L2-0007 一开单控开关(荧光) ¥:97.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:100.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:118.00 1 gang 3 way switch(Fluorescent lamp)		OB-L2-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:117.00		OB-L2-0023 法式USB+Type-c French USB+Type-C ¥:257.00
	OB-L2-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:102.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:105.00		OB-L2-0016 多功能插座 Universal socket ¥:97.00		OB-L2-0024 德式插座+二位USB 2 USB with German socket ¥:247.00

OB-L2 铝镁拉丝金/ Aluminum magnesium gold drawing

	OB-L2-0025 法式插座+二位USB 2 USB with French socket ¥ :247.00		OB-L2-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :121.00		OB-L2-0041 卫星插座 Satellite socket ¥ :122.00
	OB-L2-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :245.00		OB-L2-0034 德式插座+防水 German socket + Waterproof belt ¥ :107.00		OB-L2-0042 二位卫星插座 Double Satellite socket ¥ :142.00
	OB-L2-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C(20W) (horizontal) ¥ :315.00		OB-L2-0035 法式插座+防水 French socket + Waterproof belt ¥ :107.00		OB-L2-0043 电视卫星插座 Satellite and TV socket ¥ :127.00
	OB-L2-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :245.00		OB-L2-0036 电视插座 TV socket ¥ :107.00		OB-L2-0044 电话卫星插座 ¥ :127.00 Satellite and telephone socket 电脑卫星插座 ¥ :132.00 Satellite and computer socket
	OB-L2-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :315.00		OB-L2-0037 电话插座 ¥ :107.00 telephone socket 电脑插座 ¥ :117.00 computer socket		OB-L2-0045 二位USB插座 Double USB socket ¥ :227.00
	OB-L2-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :245.00		OB-L2-0038 二位电视插座 Double TV socket ¥ :117.00		OB-L2-0046 二位音响插座 Single audio socket ¥ :127.00
	OB-L2-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :245.00		OB-L2-0039 二位电话插座 ¥ :117.00 Double telephone socket 二位电脑插座 ¥ :127.00 Double computer socket 电话电脑插座 ¥ :122.00 telephone+computer socket		OB-L2-0047 四位音响插座 Double audio socket ¥ :147.00
	OB-L2-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :121.00		OB-L2-0040 电视电话插座 ¥ :117.00 TV + telephone socket 电视电脑插座 ¥ :122.00 TV + computer socket		OB-L2-0048 紧急呼叫开关 Emergency call switch ¥ :197.00

OB-L2 铝镁拉丝金/ Aluminum magnesium gold drawing

	OB-L2-0049 调光开关300W Dimming 300W ¥ :170.00 调光开关500W Dimming 500W ¥ :210.00 调光开关1000W Dimming 1000W ¥ :240.00 调光LED开关200W ¥ :210.00 Dimming LED 200W		OB-L2-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :282.00		OB-L2-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :121.00
	OB-L2-0050 调速开关300W ¥ :170.00 Speed 300W 调速开关500W ¥ :210.00 Speed 500W		OB-L2-0058 剃须插座 Shaving socket ¥ :472.00		OB-L2-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :121.00
	OB-L2-0051 调音开关 Tuning switch(fire) ¥ :220.00		OB-L2-0059 空白面板 Blank plate ¥ :78.00		OB-L2-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :121.00
	OB-L2-0052 触摸延时开关 ¥ :170.00 Touch delay switch 声光控延时开关 ¥ :170.00 Sound-light controlled delay switch		OB-L2-0060 二位德式插座(单体) Double German socket(single) ¥ :125.00		OB-L2-0066 一位连体边框 one face frame ¥ :60.00
	OB-L2-0053 人体感应开关 Human body induction ¥ :280.00		OB-L2-0061 二位法式插座(单体) Double French socket (single) ¥ :125.00		OB-L2-0067 二位连体边框 Double face frame ¥ :160.00
	OB-L2-0054 叮咚门铃 Ding dong doorbell ¥ :210.00		OB-L2-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :390.00		OB-L2-0068 三位连体边框 Three face frame ¥ :240.00
	OB-L2-0055 插卡取电(机械式) ¥ :272.00 Mechanical card for electricity 插卡取电(低频) ¥ :402.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :532.00 High frequency induction card for electricity		OB-L2-0069 四位连体边框 four face frame ¥ :320.00		
	OB-L2-0056 凹型地脚灯 The footlights ¥ :182.00		OB-L2-0070 五位连体边框 five face frame ¥ :400.00		

OB-L3

SERIES

超薄铝镁黑拉丝


Ultra-thin aluminum-magnesium-black
brushed finish




OB-L3 铝镁黑拉丝/ Aluminum magnesium black drawing

	OB-L3-0071 20A红绿开关 20A Red and green switch ¥:165.00		OB-L3-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:190.00		OB-L3-0087 1/2 USB/TYPE-C+HDMI ¥:355.00
	OB-L3-0072 空白出线孔 Blank outlet hole ¥:78.00		OB-L3-0080 1/2 白板+白板 blank panel+blank panel ¥:83.00		OB-L3-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:310.00
	OB-L3-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:112.00		OB-L3-0081 1/2 双HDMI 1/2 Dual HDMI ¥:400.00		OB-L3-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:232.00
	OB-L3-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:112.00		OB-L3-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:277.00		OB-L3-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:232.00
	OB-L3-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:122.00		OB-L3-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:277.00		OB-L3-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:242.00
	OB-L3-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:152.00		OB-L3-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:287.00		OB-L3-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:272.00
	OB-L3-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:127.00		OB-L3-0085 1/2 电脑插座六类+HDMI 1/2 satellite socket(Cat6)+HDMI ¥:317.00		OB-L3-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:247.00
	OB-L3-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:235.00		OB-L3-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:292.00		







OB-L3 铝镁黑拉丝/ Aluminum magnesium black drawing

	OB-L3-0001 一开单控开关 ¥:97.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:100.00 1 gang 2 way switch 一开多控开关 ¥:118.00 1 gang 3 way switch		OB-L3-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:107.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:113.00		OB-L3-0017 13A方角插座 13A square corner socket ¥:97.00
	OB-L3-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:102.00 一开双控复位开关 1 gang 2 way Reset switch ¥:105.00		OB-L3-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:117.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:123.00		OB-L3-0018 德式插座 German socket ¥:97.00
	OB-L3-0003 二开单控开关 ¥:107.00 2 gang 1 way switch 二开双控开关 ¥:113.00 2 gang 2 way switch		OB-L3-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:117.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:126.00		OB-L3-0019 法式插座 French socket ¥:97.00
	OB-L3-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:117.00 二开双控复位开关 2 gang 2 way Reset switch ¥:123.00		OB-L3-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:132.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:141.00		OB-L3-0020 俄式插座 Russian socket ¥:97.00
	OB-L3-0005 三开单控开关 ¥:117.00 3 gang 1 way switch 三开双控开关 ¥:126.00 3 gang 2 way switch		OB-L3-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:102.00		OB-L3-0021 德意式插座 German+Italian socket ¥:117.00
	OB-L3-0006 三开单复位开关 ¥:132.00 3 gang 1 way Reset switch 三开双复位开关 ¥:141.00 3 gang 2 way Reset switch		OB-L3-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:102.00		OB-L3-0022 德式USB+Type-c German USB+Type-C ¥:257.00
	OB-L3-0007 一开单控开关(荧光) ¥:97.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:100.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:118.00 1 gang 3 way switch(Fluorescent lamp)		OB-L3-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:117.00		OB-L3-0023 法式USB+Type-c French USB+Type-C ¥:257.00
	OB-L3-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:102.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:105.00		OB-L3-0016 多功能插座 Universal socket ¥:97.00		OB-L3-0024 德式插座+二位USB 2 USB with German socket ¥:247.00

OB-L3 铝镁黑拉丝/ Aluminum magnesium black drawing

	OB-L3-0025 法式插座+二位USB 2 USB with French socket ¥ :247.00		OB-L3-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :121.00		OB-L3-0041 卫星插座 Satellite socket ¥ :122.00
	OB-L3-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :245.00		OB-L3-0034 德式插座+防水 German socket + Waterproof belt ¥ :107.00		OB-L3-0042 二位卫星插座 Double Satellite socket ¥ :142.00
	OB-L3-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :315.00		OB-L3-0035 法式插座+防水 French socket + Waterproof belt ¥ :107.00		OB-L3-0043 电视卫星插座 Satellite and TV socket ¥ :127.00
	OB-L3-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :245.00		OB-L3-0036 电视插座 TV socket ¥ :107.00		OB-L3-0044 电话卫星插座 ¥ :127.00 Satellite and telephone socket 电脑卫星插座 ¥ :132.00 Satellite and computer socket
	OB-L3-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :315.00		OB-L3-0037 电话插座 ¥ :107.00 telephone socket 电脑插座 ¥ :117.00 computer socket		OB-L3-0045 二位USB插座 Double USB socket ¥ :227.00
	OB-L3-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :245.00		OB-L3-0038 二位电视插座 Double TV socket ¥ :117.00		OB-L3-0046 二位音响插座 Single audio socket ¥ :127.00
	OB-L3-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :245.00		OB-L3-0039 二位电话插座 ¥ :117.00 Double telephone socket 二位电脑插座 ¥ :127.00 Double computer socket 电话电脑插座 ¥ :122.00 telephone+computer socket		OB-L3-0047 四位音响插座 Double audio socket ¥ :147.00
	OB-L3-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :121.00		OB-L3-0040 电视电话插座 ¥ :117.00 TV + telephone socket 电视电脑插座 ¥ :122.00 TV + computer socket		OB-L3-0048 紧急呼叫开关 Emergency call switch ¥ :197.00

OB-L3 铝镁黑拉丝/ Aluminum magnesium black drawing

	OB-L3-0049 调光开关300W Dimming 300W ¥ :170.00 调光开关500W Dimming 500W ¥ :210.00 调光开关1000W Dimming 1000W ¥ :240.00 调光LED开关200W ¥ :210.00 Dimming LED 200W		OB-L3-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :282.00		OB-L3-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :121.00
	OB-L3-0050 调速开关300W ¥ :170.00 Speed 300W 调速开关500W ¥ :210.00 Speed 500W		OB-L3-0058 剃须插座 Shaving socket ¥ :472.00		OB-L3-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :121.00
	OB-L3-0051 调音开关 Tuning switch(fire) ¥ :220.00		OB-L3-0059 空白面板 Blank plate ¥ :78.00		OB-L3-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :121.00
	OB-L3-0052 触摸延时开关 ¥ :170.00 Touch delay switch 声光控延时开关 ¥ :170.00 Sound-light controlled delay switch		OB-L3-0060 二位德式插座(单体) Double German socket(single) ¥ :125.00		OB-L3-0066 一位连体边框 one face frame ¥ :60.00
	OB-L3-0053 人体感应开关 Human body induction ¥ :280.00		OB-L3-0061 二位法式插座(单体) Double French socket (single) ¥ :125.00		OB-L3-0067 二位连体边框 Double face frame ¥ :160.00
	OB-L3-0054 叮咚门铃 Ding dong doorbell ¥ :210.00		OB-L3-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :390.00		OB-L3-0068 三位连体边框 Three face frame ¥ :240.00
	OB-L3-0055 插卡取电(机械式) ¥ :272.00 Mechanical card for electricity 插卡取电(低频) ¥ :402.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :532.00 High frequency induction card for electricity		OB-L3-0069 四位连体边框 four face frame ¥ :320.00		OB-L3-0070 五位连体边框 five face frame ¥ :400.00

OB-L4


SERIES

超薄铝镁拉丝灰


Ultra-thin aluminum-magnesium-grey
brushed finish



OB-L4 铝镁拉丝灰/ Aluminum magnesium grey drawing

	OB-L4-0071 20A红绿开关 20A Red and green switch ¥:165.00		OB-L4-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:190.00		OB-L4-0087 1/2 USB/TYPE-C+HDMI ¥:355.00
	OB-L4-0072 空白出线孔 Blank outlet hole ¥:78.00		OB-L4-0080 1/2 白板+白板 blank panel+blank panel ¥:83.00		OB-L4-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:310.00
	OB-L4-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:112.00		OB-L4-0081 1/2 双HDMI 1/2 Dual HDMI ¥:400.00		OB-L4-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:232.00
	OB-L4-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:112.00		OB-L4-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:277.00		OB-L4-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:232.00
	OB-L4-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:122.00		OB-L4-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:277.00		OB-L4-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:242.00
	OB-L4-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:152.00		OB-L4-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:287.00		OB-L4-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:272.00
	OB-L4-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:127.00		OB-L4-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:317.00		OB-L4-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:247.00
	OB-L4-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:235.00		OB-L4-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:292.00		









OB-L4 铝镁拉丝灰/ Aluminum magnesium grey drawing

	OB-L4-0001 一开单控开关 ¥:97.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:100.00 1 gang 2 way switch 一开多控开关 ¥:118.00 1 gang 3 way switch		OB-L4-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:107.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:113.00		OB-L4-0017 13A方角插座 13A square corner socket ¥:97.00
	OB-L4-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:102.00 一开双控复位开关 1 gang 2 way Reset switch ¥:105.00		OB-L4-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:117.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:123.00		OB-L4-0018 德式插座 German socket ¥:97.00
	OB-L4-0003 二开单控开关 ¥:107.00 2 gang 1 way switch 二开双控开关 ¥:113.00 2 gang 2 way switch		OB-L4-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:117.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:126.00		OB-L4-0019 法式插座 French socket ¥:97.00
	OB-L4-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:117.00 二开双控复位开关 2 gang 2 way Reset switch ¥:123.00		OB-L4-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:132.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:141.00		OB-L4-0020 俄式插座 Russian socket ¥:97.00
	OB-L4-0005 三开单控开关 ¥:117.00 3 gang 1 way switch 三开双控开关 ¥:126.00 3 gang 2 way switch		OB-L4-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:102.00		OB-L4-0021 德意式插座 German+Italian socket ¥:117.00
	OB-L4-0006 三开单复位开关 ¥:132.00 3 gang 1 way Reset switch 三开双复位开关 ¥:141.00 3 gang 2 way Reset switch		OB-L4-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:102.00		OB-L4-0022 德式USB+Type-c German USB+Type-C ¥:257.00
	OB-L4-0007 一开单控开关(荧光) ¥:97.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:100.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:118.00 1 gang 3 way switch(Fluorescent lamp)		OB-L4-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:117.00		OB-L4-0023 法式USB+Type-c French USB+Type-C ¥:257.00
	OB-L4-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:102.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:105.00		OB-L4-0016 多功能插座 Universal socket ¥:97.00		OB-L4-0024 德式插座+二位USB 2 USB with German socket ¥:247.00

OB-L4 铝镁拉丝灰/ Aluminum magnesium grey drawing

	OB-L4-0025 法式插座+二位USB 2 USB with French socket ¥ :247.00		OB-L4-0033 法式透明防溅插座 French transparent splash-proof socket ¥ :121.00		OB-L4-0041 卫星插座 Satellite socket ¥ :122.00
	OB-L4-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥ :245.00		OB-L4-0034 德式插座+防水 German socket + Waterproof belt ¥ :107.00		OB-L4-0042 二位卫星插座 Double Satellite socket ¥ :142.00
	OB-L4-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal)(20W) ¥ :315.00		OB-L4-0035 法式插座+防水 French socket + Waterproof belt ¥ :107.00		OB-L4-0043 电视卫星插座 Satellite and TV socket ¥ :127.00
	OB-L4-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥ :245.00		OB-L4-0036 电视插座 TV socket ¥ :107.00		OB-L4-0044 电话卫星插座 ¥ :127.00 Satellite and telephone socket 电脑卫星插座 ¥ :132.00 Satellite and computer socket
	OB-L4-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥ :315.00		OB-L4-0037 电话插座 ¥ :107.00 telephone socket 电脑插座 ¥ :117.00 computer socket		OB-L4-0045 二位USB插座 Double USB socket ¥ :227.00
	OB-L4-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥ :245.00		OB-L4-0038 二位电视插座 Double TV socket ¥ :117.00		OB-L4-0046 二位音响插座 Single audio socket ¥ :127.00
	OB-L4-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥ :245.00		OB-L4-0039 二位电话插座 ¥ :117.00 Double telephone socket 二位电脑插座 ¥ :127.00 Double computer socket 电话电脑插座 ¥ :122.00 telephone+computer socket		OB-L4-0047 四位音响插座 Double audio socket ¥ :147.00
	OB-L4-0032 德式透明防溅插座 German type transparent splash-proof socket ¥ :121.00		OB-L4-0040 电视电话插座 ¥ :117.00 TV + telephone socket 电视电脑插座 ¥ :122.00 TV + computer socket		OB-L4-0048 紧急呼叫开关 Emergency call switch ¥ :197.00

OB-L4 铝镁拉丝灰/ Aluminum magnesium grey drawing

	OB-L4-0049 调光开关300W ¥ :170.00 Dimming 300W 调光开关500W ¥ :210.00 Dimming 500W 调光开关1000W ¥ :240.00 Dimming 1000W 调光LED开关200W ¥ :210.00 Dimming LED 200W		OB-L4-0057 凹型人体感应地脚灯 The human body induction footlights ¥ :282.00		OB-L4-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥ :121.00
	OB-L4-0050 调速开关300W ¥ :170.00 Speed 300W 调速开关500W ¥ :210.00 Speed 500W		OB-L4-0058 剃须插座 Shaving socket ¥ :472.00		OB-L4-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥ :121.00
	OB-L4-0051 调音开关 Tuning switch(fire) ¥ :220.00		OB-L4-0059 空白面板 Blank plate ¥ :78.00		OB-L4-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥ :121.00
	OB-L4-0052 触摸延时开关 ¥ :170.00 Touch delay switch 声光控延时开关 ¥ :170.00 Sound-light controlled delay switch		OB-L4-0060 二位德式插座(单体) Double German socket(single) ¥ :125.00		OB-L4-0066 一位连体边框 one face frame ¥ :60.00
	OB-L4-0053 人体感应开关 Human body induction ¥ :280.00		OB-L4-0061 二位法式插座(单体) Double French socket (single) ¥ :125.00		OB-L4-0067 二位连体边框 Double face frame ¥ :160.00
	OB-L4-0054 叮咚门铃 Ding dong doorbell ¥ :210.00		OB-L4-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥ :390.00		OB-L4-0068 三位连体边框 Three face frame ¥ :240.00
	OB-L4-0055 插卡取电(机械式) ¥ :272.00 Mechanical card for electricity 插卡取电(低频) ¥ :402.00 Low frequency induction card for electricity 插卡取电(高频) ¥ :532.00 High frequency induction card for electricity		OB-L4-0069 四位连体边框 four face frame ¥ :320.00		
	OB-L4-0056 凹型地脚灯 The footlights ¥ :182.00		OB-L4-0070 五位连体边框 five face frame ¥ :400.00		

OB-G1


超薄钢化玻璃白色 SERIES

Ultra-thin









Tempered glass white

The high transparency and smooth texture of glass give switches and sockets a unique fashionable and modern feel.











Whether it is a minimalist home decor or a luxurious European style, the glass-faced switch and socket can perfectly match it, adding a touch of refinement and elegance to the space.













OB-G1超薄钢化玻璃白色/ Ultra-thin tempered glass white

	OB-G1-0071 20A红绿开关 20A Red and green switch ¥:185.00		OB-G1-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:210.00		OB-G1-0087 1/2 USB/TYPE-C +HDMI ¥:375.00
	OB-G1-0072 空白出线孔 Blank outlet hole ¥:98.00		OB-G1-0080 1/2 白板+白板 blank panel+blank panel ¥:103.00		OB-G1-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:330.00
	OB-G1-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:132.00		OB-G1-0081 1/2 双HDMI 1/2 Dual HDMI ¥:420.00		OB-G1-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:252.00
	OB-G1-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:132.00		OB-G1-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:297.00		OB-G1-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:252.00
	OB-G1-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:142.00		OB-G1-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:297.00		OB-G1-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:262.00
	OB-G1-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:172.00		OB-G1-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:307.00		OB-G1-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:292.00
	OB-G1-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:147.00		OB-G1-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:337.00		OB-G1-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:267.00
	OB-G1-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:255.00		OB-G1-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:312.00		









OB-G1超薄钢化玻璃白色/ Ultra-thin tempered glass white

	OB-G1-0001 一开单控开关 ¥:117.00 1 gang 1 way switch 一开双控开关 ¥:120.00 1 gang 2 way switch 一开多控开关 ¥:138.00 1 gang 3 way switch		OB-G1-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:127.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:133.00		OB-G1-0017 13A方角插座 13A square corner socket ¥:117.00
	OB-G1-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:122.00 一开双控复位开关 1 gang 2 way Reset switch ¥:125.00		OB-G1-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:137.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:143.00		OB-G1-0018 德式插座 German socket ¥:117.00
	OB-G1-0003 二开单控开关 ¥:127.00 2 gang 1 way switch 二开双控开关 ¥:133.00 2 gang 2 way switch		OB-G1-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:137.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:146.00		OB-G1-0019 法式插座 French socket ¥:117.00
	OB-G1-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:137.00 二开双控复位开关 2 gang 2 way Reset switch ¥:143.00		OB-G1-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:152.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:161.00		OB-G1-0020 俄式插座 Russian socket ¥:117.00
	OB-G1-0005 三开单控开关 ¥:137.00 3 gang 1 way switch 三开双控开关 ¥:146.00 3 gang 2 way switch		OB-G1-0013 门铃开关(荧光) Doorbell switch(Fluorescent lamp) ¥:122.00		OB-G1-0021 德意式插座 German+Italian socket ¥:137.00
	OB-G1-0006 三开单复位开关 ¥:152.00 3 gang 1 way Reset switch 三开双复位开关 ¥:161.00 3 gang 2 way Reset switch		OB-G1-0014 门禁开关(荧光) Gating switch(Fluorescent lamp) ¥:122.00		OB-G1-0022 德式USB+Type-c German USB+Type-C ¥:277.00
	OB-G1-0007 一开单控开关(荧光) ¥:117.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:120.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:138.00 1 gang 3 way switch(Fluorescent lamp)		OB-G1-0015 百叶窗升降开关(荧光) louwer window lifter switch (Fluorescent lamp) ¥:137.00		OB-G1-0023 法式USB+Type-c French USB+Type-C ¥:277.00
	OB-G1-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:122.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:125.00		OB-G1-0016 多功能插座 Universal socket ¥:117.00		OB-G1-0024 德式插座+二位USB 2 USB with German socket ¥:267.00

OB-G1超薄钢化玻璃白色/ Ultra-thin tempered glass white

	OB-G1-0025 法式插座+二位USB 2 USB with French socket ¥:267.00		OB-G1-0033 法式透明防溅插座 French transparent splash-proof socket ¥:141.00		OB-G1-0041 卫星插座 Satellite socket ¥:142.00
	OB-G1-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:265.00		OB-G1-0034 德式插座+防水 German socket + Waterproof belt ¥:127.00		OB-G1-0042 二位卫星插座 Double Satellite socket ¥:162.00
	OB-G1-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal) ¥:335.00		OB-G1-0035 法式插座+防水 French socket + Waterproof belt ¥:127.00		OB-G1-0043 电视卫星插座 Satellite and TV socket ¥:147.00
	OB-G1-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:265.00		OB-G1-0036 电视插座 TV socket ¥:127.00		OB-G1-0044 电话卫星插座 ¥:147.00 Satellite and telephone socket 电脑卫星插座 ¥:152.00 Satellite and computer socket
	OB-G1-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥:335.00		OB-G1-0037 电话插座 ¥:127.00 telephone socket 电脑插座 ¥:137.00 computer socket		OB-G1-0045 二位USB插座 Double USB socket ¥:247.00
	OB-G1-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:265.00		OB-G1-0038 二位电视插座 Double TV socket ¥:137.00		OB-G1-0046 二位音响插座 Single audio socket ¥:147.00
	OB-G1-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:265.00		OB-G1-0039 二位电话插座 ¥:137.00 Double telephone socket 二位电脑插座 ¥:147.00 Double computer socket 电话电脑插座 ¥:142.00 telephone+computer socket		OB-G1-0047 四位音响插座 Double audio socket ¥:167.00
	OB-G1-0032 德式透明防溅插座 German type transparent splash-proof socket ¥:141.00		OB-G1-0040 电视电话插座 ¥:137.00 TV + telephone socket 电视电脑插座 ¥:142.00 TV + computer socket		OB-G1-0048 紧急呼叫开关 Emergency call switch ¥:217.00

OB-G1超薄钢化玻璃白色/ Ultra-thin tempered glass white

	OB-G1-0049 调光开关300W ¥:190.00 Dimming 300W 调光开关500W ¥:230.00 Dimming 500W 调光开关1000W ¥:260.00 Dimming 1000W 调光LED开关200W ¥:230.00 Dimming LED 200W		OB-G1-0057 凹型人体感应地脚灯 The human body induction footlights ¥:302.00		OB-G1-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥:141.00
	OB-G1-0050 调速开关300W ¥:190.00 Speed 300W 调速开关500W ¥:230.00 Speed 500W		OB-G1-0058 剃须插座 Shaving socket ¥:492.00		OB-G1-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥:141.00
	OB-G1-0051 调音开关 Tuning switch (fire) ¥:240.00		OB-G1-0059 空白面板 Blank plate ¥:98.00		OB-G1-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:141.00
	OB-G1-0052 触摸延时开关 ¥:190.00 Touch delay switch 声光控延时开关 ¥:190.00 Sound-light controlled delay switch		OB-G1-0060 二位德式插座(单体) Double German socket(single) ¥:145.00		OB-G1-0066 一位连体边框 one face frame ¥:80.00
	OB-G1-0053 人体感应开关 Human body induction ¥:300.00		OB-G1-0061 二位法式插座(单体) Double French socket (single) ¥:145.00		OB-G1-0067 二位连体边框 Double face frame ¥:200.00
	OB-G1-0054 叮咚门铃 Ding dong doorbell ¥:230.00		OB-G1-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:410.00		OB-G1-0068 三位连体边框 Three face frame ¥:280.00
	OB-G1-0055 插卡取电(机械式) ¥:292.00 Mechanical card for electricity 插卡取电(低频) ¥:422.00 Low frequency induction card for electricity 插卡取电(高频) ¥:552.00 High frequency induction card for electricity		OB-G1-0069 四位连体边框 four face frame ¥:360.00		
	OB-G1-0056 凹型地脚灯 The footlights ¥:202.00		OB-G1-0070 五位连体边框 five face frame ¥:440.00		

OB-G2


超薄钢化玻璃金色 SERIES

Ultra-thin


Tempered glass gold

The high transparency and smooth texture of glass give switches and sockets a unique fashionable and modern feel.

Whether it is a minimalist home decor or a luxurious European style, the glass-faced switch and socket can perfectly match it, adding a touch of refinement and elegance to the space.



OB-G2 超薄钢化玻璃金色/ Ultra-thin tempered glass gold



OB-G2-0071
20A红绿开关
20A Red and green switch
¥:185.00




OB-G2-0079
1/2 USB+type-c10W+白板
1/2 USB+type-c10W+blank panel
¥:210.00



OB-G2-0087
1/2 USB/TYPE-C +HDMI
¥:375.00




OB-G2-0072
空白出线孔
Blank outlet hole
¥:98.00



OB-G2-0080
1/2 白板+白板
blank panel+blank panel
¥:103.00



OB-G2-0088
二位1/2 USB/TYPE-C
Double 1/2 USB/TYPE-C
¥:330.00



OB-G2-0073
1/2 电视插座+白板
1/2 TV socket+blank panel
¥:132.00



OB-G2-0081
1/2 双HDMI
1/2 Dual HDMI
¥:420.00



OB-G2-0089
1/2 电视+USB/TYPE-C
1/2 TV socket+1/2USB/TYPE-C
¥:252.00




OB-G2-0074
1/2 电话插座+白板
1/2 telephone socket+blank panel
¥:132.00



OB-G2-0082
1/2 电视+HDMI
1/2 TV socket+1/2 HDMI socket
¥:297.00



OB-G2-0090
1/2 电话+USB/TYPE-C
1/2 telephone socket+
1/2 USB/TYPE-C
¥:252.00




OB-G2-0075
1/2 电脑插座+白板
1/2 computer socket+blank panel
¥:142.00



OB-G2-0083
1/2 电话+HDMI
1/2 telephone socket+1/2
HDMI socket
¥:297.00



OB-G2-0091
1/2 电脑+USB/TYPE-C
1/2 Computer socket+ USB/TYPE-C
¥:262.00




OB-G2-0076
1/2 电脑插座六类+白板
1/2 Computer socket(Cat6)
+blank panel
¥:172.00



OB-G2-0084
1/2 电脑插座+HDMI
1/2 computer socket+HDMI
¥:307.00



OB-G2-0092
1/2 电脑六类+USB/TYPE-C
1/2 Computer socket(Cat6)
+USB/TYPE-C
¥:292.00




OB-G2-0077
1/2 卫星插座+白板
1/2 satellite socket+blank panel
¥:147.00




OB-G2-0085
1/2 电脑插座六类+HDMI
1/2 satellite socket(Cat6)+HDMI
¥:337.00



OB-G2-0093
1/2 卫星+USB/TYPE-C
1/2 satellite socket+USB/TYPE-C
¥:267.00



OB-G2-0078
1/2 HDMI+白板
1/2 HDMI+blank panel
¥:255.00



OB-G2-0086
1/2 卫星+HDMI
1/2 satellite socket+HDMI
¥:312.00

OB-G2 超薄钢化玻璃金色/ Ultra-thin tempered glass gold



OB-G2-0001
一开单控开关 ¥:117.00
1 gang 1 way switch
一开双控开关 ¥:120.00
1 gang 2 way switch
一开多控开关 ¥:138.00
1 gang 3 way switch



OB-G2-0009
二开单控开关(荧光)
2 gang 1 way switch
(Fluorescent lamp)
¥:127.00
二开双控开关(荧光)
2 gang 2 way switch
(Fluorescent lamp)
¥:133.00



OB-G2-0017
13A方角插座
13A square corner socket
¥:117.00




OB-G2-0002
一开单控复位开关
1 gang 1 way Reset switch
¥:122.00
一开双控复位开关
1 gang 2 way Reset switch
¥:125.00




OB-G2-0010
二开单控复位开关(荧光)
2 gang 1 way Reset switch
(Fluorescent lamp)
¥:137.00
二开双控复位开关(荧光)
2 gang 2 way Reset switch
(Fluorescent lamp)
¥:143.00



OB-G2-0018
德式插座
German socket
¥:117.00




OB-G2-0003
二开单控开关 ¥:127.00
2 gang 1 way switch
二开双控开关 ¥:133.00
2 gang 2 way switch




OB-G2-0011
三开单控开关(荧光)
3 gang 1 way switch
(Fluorescent lamp)
¥:137.00
三开双控开关(荧光)
3 gang 2 way switch
(Fluorescent lamp)
¥:146.00



OB-G2-0019
法式插座
French socket
¥:117.00




OB-G2-0004
二开单控复位开关
2 gang 1 way Reset switch
¥:137.00
二开双控复位开关
2 gang 2 way Reset switch
¥:143.00



OB-G2-0012
三开单复位开关(荧光)
3 gang 1 way Reset switch
(Fluorescent lamp)
¥:152.00
三开双复位开关(荧光)
3 gang 2 way Reset switch
(Fluorescent lamp)
¥:161.00



OB-G2-0020
俄式插座
Russian socket
¥:117.00




OB-G2-0005
三开单控开关 ¥:137.00
3 gang 1 way switch
三开双控开关 ¥:146.00
3 gang 2 way switch



OB-G2-0013
门铃开关(荧光)
Doorbell switch(Fluorescent lamp)
¥:122.00



OB-G2-0021
德意式插座
German+Italian socket
¥:137.00



OB-G2-0006
三开单复位开关 ¥:152.00
3 gang 1 way Reset switch
三开双复位开关 ¥:161.00
3 gang 2 way Reset switch




OB-G2-0014
门禁开关(荧光)
Gating switch(Fluorescent lamp)
¥:122.00



OB-G2-0022
德式USB+Type-c
German USB+Type-C
¥:277.00



OB-G2-0007
一开单控开关(荧光) ¥:117.00
1 gang 1 way switch(Fluorescent lamp)
一开双控开关(荧光) ¥:120.00
1 gang 2 way switch(Fluorescent lamp)
一开多控开关(荧光) ¥:138.00
1 gang 3 way switch(Fluorescent lamp)




OB-G2-0015
百叶窗升降开关(荧光)
louwer window lifter switch
(Fluorescent lamp)
¥:137.00



OB-G2-0023
法式USB+Type-c
French USB+Type-C
¥:277.00



OB-G2-0008
一开单控复位开关(荧光)
1 gang 1 way Reset switch
(Fluorescent lamp)
¥:122.00
一开双控复位开关(荧光)
1 gang 2 way Reset switch
(Fluorescent lamp)
¥:125.00








OB-G2-0016
多功能插座
Universal socket
¥:117.00










OB-G2-0024
德式插座+二位USB
2 USB with German socket
¥:267.00

OB-G2 超薄钢化玻璃金色/ Ultra-thin tempered glass gold

	OB-G2-0025 法式插座+二位USB 2 USB with French socket ¥:267.00		OB-G2-0033 法式透明防溅插座 French transparent splash-proof socket ¥:141.00		OB-G2-0041 卫星插座 Satellite socket ¥:142.00
	OB-G2-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:265.00		OB-G2-0034 德式插座+防水 German socket + Waterproof belt ¥:127.00		OB-G2-0042 二位卫星插座 Double Satellite socket ¥:162.00
	OB-G2-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal) ¥:335.00		OB-G2-0035 法式插座+防水 French socket + Waterproof belt ¥:127.00		OB-G2-0043 电视卫星插座 Satellite and TV socket ¥:147.00
	OB-G2-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:265.00		OB-G2-0036 电视插座 TV socket ¥:127.00		OB-G2-0044 电话卫星插座 ¥:147.00 Satellite and telephone socket 电脑卫星插座 ¥:152.00 Satellite and computer socket
	OB-G2-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥:335.00		OB-G2-0037 电话插座 ¥:127.00 telephone socket 电脑插座 ¥:137.00 computer socket		OB-G2-0045 二位USB插座 Double USB socket ¥:247.00
	OB-G2-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:265.00		OB-G2-0038 二位电视插座 Double TV socket ¥:137.00		OB-G2-0046 二位音响插座 Single audio socket ¥:147.00
	OB-G2-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:265.00		OB-G2-0039 二位电话插座 ¥:137.00 Double telephone socket 二位电脑插座 ¥:147.00 Double computer socket 电话电脑插座 ¥:142.00 telephone+computer socket		OB-G2-0047 四位音响插座 Double audio socket ¥:167.00
	OB-G2-0032 德式透明防溅插座 German type transparent splash-proof socket ¥:141.00		OB-G2-0040 电视电话插座 ¥:137.00 TV + telephone socket 电视电脑插座 ¥:142.00 TV + computer socket		OB-G2-0048 紧急呼叫开关 Emergency call switch ¥:217.00

OB-G2 超薄钢化玻璃金色/ Ultra-thin tempered glass gold

	OB-G2-0049 调光开关300W Dimming 300W ¥:190.00 调光开关500W Dimming 500W ¥:230.00 调光开关1000W Dimming 1000W ¥:260.00 调光LED开关200W ¥:230.00 Dimming LED 200W		OB-G2-0057 凹型人体感应地脚灯 The human body induction footlights ¥:302.00		OB-G2-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥:141.00
	OB-G2-0050 调速开关300W ¥:190.00 Speed 300W 调速开关500W ¥:230.00 Speed 500W		OB-G2-0058 剃须插座 Shaving socket ¥:492.00		OB-G2-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥:141.00
	OB-G2-0051 调音开关 Tuning switch (fire) ¥:240.00		OB-G2-0059 空白面板 Blank plate ¥:98.00		OB-G2-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:141.00
	OB-G2-0052 触摸延时开关 ¥:190.00 Touch delay switch 声光控延时开关 ¥:190.00 Sound-light controlled delay switch		OB-G2-0060 二位德式插座(单体) Double German socket(single) ¥:145.00		OB-G2-0066 一位连体边框 one face frame ¥:80.00
	OB-G2-0053 人体感应开关 Human body induction ¥:300.00		OB-G2-0061 二位法式插座(单体) Double French socket (single) ¥:145.00		OB-G2-0067 二位连体边框 Double face frame ¥:200.00
	OB-G2-0054 叮咚门铃 Ding dong doorbell ¥:230.00		OB-G2-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:410.00		OB-G2-0068 三位连体边框 Three face frame ¥:280.00
	OB-G2-0055 插卡取电(机械式) ¥:292.00 Mechanical card for electricity 插卡取电(低频) ¥:422.00 Low frequency induction card for electricity 插卡取电(高频) ¥:552.00 High frequency induction card for electricity		OB-G2-0069 四位连体边框 four face frame ¥:360.00		
	OB-G2-0056 凹型地脚灯 The footlights ¥:202.00		OB-G2-0070 五位连体边框 five face frame ¥:440.00		


OB-G3

超薄钢化玻璃黑色 SERIES

Ultra-thin

Tempered glass black

The high transparency and smooth texture of glass give switches and sockets a unique fashionable and modern feel. Whether it is a minimalist home decor or a luxurious European style, the glass-faced switch and socket can perfectly match it, adding a touch of refinement and elegance to the space.





OB-G3 超薄钢化玻璃黑色/ Ultra-thin tempered glass black

	OB-G3-0071 20A红绿开关 20A Red and green switch ¥:185.00		OB-G3-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:210.00		OB-G3-0087 1/2 USB/TYPE-C +HDMI ¥:375.00
	OB-G3-0072 空白出线孔 Blank outlet hole ¥:98.00		OB-G3-0080 1/2 白板+白板 blank panel+blank panel ¥:103.00		OB-G3-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:330.00
	OB-G3-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:132.00		OB-G3-0081 1/2 双HDMI 1/2 Dual HDMI ¥:420.00		OB-G3-0089 1/2 电视+ USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:252.00
	OB-G3-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:132.00		OB-G3-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:297.00		OB-G3-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:252.00
	OB-G3-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:142.00		OB-G3-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:297.00		OB-G3-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:262.00
	OB-G3-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:172.00		OB-G3-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:307.00		OB-G3-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:292.00
	OB-G3-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:147.00		OB-G3-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:337.00		OB-G3-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:267.00
	OB-G3-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:255.00		OB-G3-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:312.00		



OB-G3 超薄钢化玻璃黑色/ Ultra-thin tempered glass black

	OB-G3-0001 一开单控开关 ¥:117.00 1 gang 1 way switch 一开双控开关 ¥:120.00 1 gang 2 way switch 一开多控开关 ¥:138.00 1 gang 3 way switch		OB-G3-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:127.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:133.00		OB-G3-0017 13A方角插座 13A square corner socket ¥:117.00
	OB-G3-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:122.00 一开双控复位开关 1 gang 2 way Reset switch ¥:125.00		OB-G3-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:137.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:143.00		OB-G3-0018 德式插座 German socket ¥:117.00
	OB-G3-0003 二开单控开关 ¥:127.00 2 gang 1 way switch 二开双控开关 ¥:133.00 2 gang 2 way switch		OB-G3-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:137.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:146.00		OB-G3-0019 法式插座 French socket ¥:117.00
	OB-G3-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:137.00 二开双控复位开关 2 gang 2 way Reset switch ¥:143.00		OB-G3-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:152.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:161.00		OB-G3-0020 俄式插座 Russian socket ¥:117.00
	OB-G3-0005 三开单控开关 ¥:137.00 3 gang 1 way switch 三开双控开关 ¥:146.00 3 gang 2 way switch		OB-G3-0013 门铃开关(荧光) Doorbell switch(Fluorescent lamp) ¥:122.00		OB-G3-0021 德意式插座 German+Italian socket ¥:137.00
	OB-G3-0006 三开单复位开关 ¥:152.00 3 gang 1 way Reset switch 三开双复位开关 ¥:161.00 3 gang 2 way Reset switch		OB-G3-0014 门禁开关(荧光) Gating switch(Fluorescent lamp) ¥:122.00		OB-G3-0022 德式USB+Type-c German USB+Type-C ¥:277.00
	OB-G3-0007 一开单控开关(荧光) ¥:117.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:120.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:138.00 1 gang 3 way switch(Fluorescent lamp)		OB-G3-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:137.00		OB-G3-0023 法式USB+Type-c French USB+Type-C ¥:277.00
	OB-G3-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:122.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:125.00		OB-G3-0016 多功能插座 Universal socket ¥:117.00		OB-G3-0024 德式插座+二位USB 2 USB with German socket ¥:267.00

OB-G3 超薄钢化玻璃黑色/ Ultra-thin tempered glass black

	OB-G3-0025 法式插座+二位USB 2 USB with French socket ¥:267.00		OB-G3-0033 法式透明防溅插座 French transparent splash-proof socket ¥:141.00		OB-G3-0041 卫星插座 Satellite socket ¥:142.00
	OB-G3-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:265.00		OB-G3-0034 德式插座+防水 German socket + Waterproof belt ¥:127.00		OB-G3-0042 二位卫星插座 Double Satellite socket ¥:162.00
	OB-G3-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal) ¥:335.00		OB-G3-0035 法式插座+防水 French socket + Waterproof belt ¥:127.00		OB-G3-0043 电视卫星插座 Satellite and TV socket ¥:147.00
	OB-G3-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:265.00		OB-G3-0036 电视插座 TV socket ¥:127.00		OB-G3-0044 电话卫星插座 ¥:147.00 Satellite and telephone socket 电脑卫星插座 ¥:152.00 Satellite and computer socket
	OB-G3-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥:335.00		OB-G3-0037 电话插座 ¥:127.00 telephone socket 电脑插座 ¥:137.00 computer socket		OB-G3-0045 二位USB插座 Double USB socket ¥:247.00
	OB-G3-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:265.00		OB-G3-0038 二位电视插座 Double TV socket ¥:137.00		OB-G3-0046 二位音响插座 Single audio socket ¥:147.00
	OB-G3-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:265.00		OB-G3-0039 二位电话插座 ¥:137.00 Double telephone socket 二位电脑插座 ¥:147.00 Double computer socket 电话电脑插座 ¥:142.00 telephone+computer socket		OB-G3-0047 四位音响插座 Double audio socket ¥:167.00
	OB-G3-0032 德式透明防溅插座 German type transparent splash-proof socket ¥:141.00		OB-G3-0040 电视电话插座 ¥:137.00 TV + telephone socket 电视电脑插座 ¥:142.00 TV + computer socket		OB-G3-0048 紧急呼叫开关 Emergency call switch ¥:217.00

OB-G3 超薄钢化玻璃黑色/ Ultra-thin tempered glass black

	OB-G3-0049 调光开关300W ¥:190.00 Dimming 300W 调光开关500W ¥:230.00 Dimming 500W 调光开关1000W ¥:260.00 Dimming 1000W 调光LED开关200W ¥:230.00 Dimming LED 200W		OB-G3-0057 凹型人体感应地脚灯 The human body induction footlights ¥:302.00		OB-G3-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥:141.00
	OB-G3-0050 调速开关300W ¥:190.00 Speed 300W 调速开关500W ¥:230.00 Speed 500W		OB-G3-0058 剃须插座 Shaving socket ¥:492.00		OB-G3-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥:141.00
	OB-G3-0051 调音开关 Tuning switch (fire) ¥:240.00		OB-G3-0059 空白面板 Blank plate ¥:98.00		OB-G3-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:141.00
	OB-G3-0052 触摸延时开关 ¥:190.00 Touch delay switch 声光控延时开关 ¥:190.00 Sound-light controlled delay switch		OB-G3-0060 二位德式插座(单体) Double German socket(single) ¥:145.00		OB-G3-0066 一位连体边框 one face frame ¥:80.00
	OB-G3-0053 人体感应开关 Human body induction ¥:300.00		OB-G3-0061 二位法式插座(单体) Double French socket (single) ¥:145.00		OB-G3-0067 二位连体边框 Double face frame ¥:200.00
	OB-G3-0054 叮咚门铃 Ding dong doorbell ¥:230.00		OB-G3-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:410.00		OB-G3-0068 三位连体边框 Three face frame ¥:280.00
	OB-G3-0055 插卡取电(机械式) ¥:292.00 Mechanical card for electricity 插卡取电(低频) ¥:422.00 Low frequency induction card for electricity 插卡取电(高频) ¥:552.00 High frequency induction card for electricity		OB-G3-0069 四位连体边框 four face frame ¥:360.00		
	OB-G3-0056 凹型地脚灯 The footlights ¥:202.00		OB-G3-0070 五位连体边框 five face frame ¥:440.00		

OB-G4



超薄钢化玻璃灰色 SERIES

Ultra-thin














Tempered glass grey

The high transparency and smooth texture of glass give switches and sockets a unique fashionable and modern feel.
















Whether it is a minimalist home decor or a luxurious European style, the glass-faced switch and socket can perfectly match it, adding a touch of refinement and elegance to the space.













OB-G4 超薄钢化玻璃灰色/ Ultra-thin tempered glass grey

	OB-G4-0071 20A红绿开关 20A Red and green switch ¥:185.00		OB-G4-0079 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:210.00		OB-G4-0087 1/2 USB/TYPE-C +HDMI ¥:375.00
	OB-G4-0072 空白出线孔 Blank outlet hole ¥:98.00		OB-G4-0080 1/2 白板+白板 blank panel+blank panel ¥:103.00		OB-G4-0088 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:330.00
	OB-G4-0073 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:132.00		OB-G4-0081 1/2 双HDMI 1/2 Dual HDMI ¥:420.00		OB-G4-0089 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:252.00
	OB-G4-0074 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:132.00		OB-G4-0082 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:297.00		OB-G4-0090 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:252.00
	OB-G4-0075 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:142.00		OB-G4-0083 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:297.00		OB-G4-0091 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:262.00
	OB-G4-0076 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:172.00		OB-G4-0084 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:307.00		OB-G4-0092 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:292.00
	OB-G4-0077 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:147.00		OB-G4-0085 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:337.00		OB-G4-0093 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:267.00
	OB-G4-0078 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:255.00		OB-G4-0086 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:312.00		











OB-G4 超薄钢化玻璃灰色/ Ultra-thin tempered glass grey

	OB-G4-0001 一开单控开关 ¥:117.00 1 gang 1 way switch 一开双控开关 ¥:120.00 1 gang 2 way switch 一开多控开关 ¥:138.00 1 gang 3 way switch		OB-G4-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:127.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:133.00		OB-G4-0017 13A方角插座 13A square corner socket ¥:117.00
	OB-G4-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:122.00 一开双控复位开关 1 gang 2 way Reset switch ¥:125.00		OB-G4-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:137.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:143.00		OB-G4-0018 德式插座 German socket ¥:117.00
	OB-G4-0003 二开单控开关 ¥:127.00 2 gang 1 way switch 二开双控开关 ¥:133.00 2 gang 2 way switch		OB-G4-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:137.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:146.00		OB-G4-0019 法式插座 French socket ¥:117.00
	OB-G4-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:137.00 二开双控复位开关 2 gang 2 way Reset switch ¥:143.00		OB-G4-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:152.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:161.00		OB-G4-0020 俄式插座 Russian socket ¥:117.00
	OB-G4-0005 三开单控开关 ¥:137.00 3 gang 1 way switch 三开双控开关 ¥:146.00 3 gang 2 way switch		OB-G4-0013 门铃开关(荧光) Doorbell switch(Fluorescent lamp) ¥:122.00		OB-G4-0021 德意式插座 German+Italian socket ¥:137.00
	OB-G4-0006 三开单复位开关 ¥:152.00 3 gang 1 way Reset switch 三开双复位开关 ¥:161.00 3 gang 2 way Reset switch		OB-G4-0014 门禁开关(荧光) Gating switch(Fluorescent lamp) ¥:122.00		OB-G4-0022 德式USB+Type-c German USB+Type-C ¥:277.00
	OB-G4-0007 一开单控开关(荧光) ¥:117.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:120.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:138.00 1 gang 3 way switch(Fluorescent lamp)		OB-G4-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:137.00		OB-G4-0023 法式USB+Type-c French USB+Type-C ¥:277.00
	OB-G4-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:122.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:125.00		OB-G4-0016 多功能插座 Universal socket ¥:117.00		OB-G4-0024 德式插座+二位USB 2 USB with German socket ¥:267.00

SF-G4钢化玻璃灰色/Tempered glass grey

	OB-G4-0025 法式插座+二位USB 2 USB with French socket ¥:267.00		OB-G4-0033 法式透明防溅插座 French transparent splash-proof socket ¥:141.00		OB-G4-0041 卫星插座 Satellite socket ¥:142.00
	OB-G4-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:265.00		OB-G4-0034 德式插座+防水 German socket + Waterproof belt ¥:127.00		OB-G4-0042 二位卫星插座 Double Satellite socket ¥:162.00
	OB-G4-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C (horizontal) ¥:335.00		OB-G4-0035 法式插座+防水 French socket + Waterproof belt ¥:127.00		OB-G4-0043 电视卫星插座 Satellite and TV socket ¥:147.00
	OB-G4-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:265.00		OB-G4-0036 电视插座 TV socket ¥:127.00		OB-G4-0044 电话卫星插座 ¥:147.00 Satellite and telephone socket 电脑卫星插座 ¥:152.00 Satellite and computer socket
	OB-G4-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥:335.00		OB-G4-0037 电话插座 ¥:127.00 telephone socket 电脑插座 ¥:137.00 computer socket		OB-G4-0045 二位USB插座 Double USB socket ¥:247.00
	OB-G4-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:265.00		OB-G4-0038 二位电视插座 Double TV socket ¥:137.00		OB-G4-0046 二位音响插座 Single audio socket ¥:147.00
	OB-G4-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:265.00		OB-G4-0039 二位电话插座 ¥:137.00 Double telephone socket 二位电脑插座 ¥:147.00 Double computer socket 电话电脑插座 ¥:142.00 telephone+computer socket		OB-G4-0047 四位音响插座 Double audio socket ¥:167.00
	OB-G4-0032 德式透明防溅插座 German type transparent splash-proof socket ¥:141.00		OB-G4-0040 电视电话插座 ¥:137.00 TV + telephone socket 电视电脑插座 ¥:142.00 TV + computer socket		OB-G4-0048 紧急呼叫开关 Emergency call switch ¥:217.00


SF-G4钢化玻璃灰色/Tempered glass grey

	OB-G4-0049 调光开关300W ¥:190.00 Dimming 300W 调光开关500W ¥:230.00 Dimming 500W 调光开关1000W ¥:260.00 Dimming 1000W 调光LED开关200W ¥:230.00 Dimming LED 200W		OB-G4-0057 凹型人体感应地脚灯 The human body induction footlights ¥:302.00		OB-G4-0063 121型二位德式插座(短连体) 121 Double German socket(short) ¥:141.00
	OB-G4-0050 调速开关300W ¥:190.00 Speed 300W 调速开关500W ¥:230.00 Speed 500W		OB-G4-0058 剃须插座 Shaving socket ¥:492.00		OB-G4-0064 121型二位法式插座(短连体) 121 Double French socket(short) ¥:141.00
	OB-G4-0051 调音开关 Tuning switch (fire) ¥:240.00		OB-G4-0059 空白面板 Blank plate ¥:98.00		OB-G4-0065 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:141.00
	OB-G4-0052 触摸延时开关 ¥:190.00 Touch delay switch 声光控延时开关 ¥:190.00 Sound-light controlled delay switch		OB-G4-0060 二位德式插座(单体) Double German socket(single) ¥:145.00		OB-G4-0066 一位连体边框 one face frame ¥:80.00
	OB-G4-0053 人体感应开关 Human body induction ¥:300.00		OB-G4-0061 二位法式插座(单体) Double French socket (single) ¥:145.00		OB-G4-0067 二位连体边框 Double face frame ¥:200.00
	OB-G4-0054 叮咚门铃 Ding dong doorbell ¥:230.00		OB-G4-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:410.00		OB-G4-0068 三位连体边框 Three face frame ¥:280.00
	OB-G4-0055 插卡取电(机械式) ¥:292.00 Mechanical card for electricity 插卡取电(低频) ¥:422.00 Low frequency induction card for electricity 插卡取电(高频) ¥:552.00 High frequency induction card for electricity		OB-G4-0069 四位连体边框 four face frame ¥:360.00		
	OB-G4-0056 凹型地脚灯 The footlights ¥:202.00		OB-G4-0070 五位连体边框 five face frame ¥:440.00		

LL-82 PC白色功能键/White function key PC



LL-82-0001
一开单控开关 ¥:33.00
1 gang 1 way switch
一开双控开关 ¥:36.00
1 gang 2 way switch
一开多控开关 ¥:54.00
1 gang 3 way switch




LL-82-0009
二开单控开关(荧光)
2 gang 1 way switch
(Fluorescent lamp)
¥:43.00
二开双控开关(荧光)
2 gang 2 way switch
(Fluorescent lamp)
¥:49.00



LL-82-0017
13A方角插座
13A square corner socket
¥:33.00



LL-82-0002
一开单控复位开关
1 gang 1 way Reset switch
¥:38.00
一开双控复位开关
1 gang 2 way Reset switch
¥:41.00



LL-82-0010
二开单控复位开关(荧光)
2 gang 1 way Reset switch
(Fluorescent lamp)
¥:53.00
二开双控复位开关(荧光)
2 gang 2 way Reset switch
(Fluorescent lamp)
¥:59.00



LL-82-0018
德式插座
German socket
¥:33.00



LL-82-0003
二开单控开关 ¥:43.00
2 gang 1 way switch
二开双控开关 ¥:49.00
2 gang 2 way switch



LL-82-0011
三开单控开关(荧光)
3 gang 1 way switch
(Fluorescent lamp)
¥:53.00
三开双控开关(荧光)
3 gang 2 way switch
(Fluorescent lamp)
¥:62.00



LL-82-0019
法式插座
French socket
¥:33.00



LL-82-0004
二开单控复位开关
2 gang 1 way Reset switch
¥:53.00
二开双控复位开关
2 gang 2 way Reset switch
¥:59.00



LL-82-0012
三开单复位开关(荧光)
3 gang 1 way Reset switch
(Fluorescent lamp)
¥:68.00
三开双复位开关(荧光)
3 gang 2 way Reset switch
(Fluorescent lamp)
¥:77.00



LL-82-0020
俄式插座
Russian socket
¥:33.00



LL-82-0005
三开单控开关 ¥:53.00
3 gang 1 way switch
三开双控开关 ¥:62.00
3 gang 2 way switch



LL-82-0013
门铃开关(荧光)
Doorbell switch(Fluorescent lamp)
¥:38.00



LL-82-0021
德意式插座
German+Italian socket
¥:53.00



LL-82-0006
三开单复位开关 ¥:68.00
3 gang 1 way Reset switch
三开双复位开关 ¥:77.00
3 gang 2 way Reset switch




LL-82-0014
门禁开关(荧光)
Gating switch(Fluorescent lamp)
¥:38.00



LL-82-0022
德式USB+Type-c
German USB+Type-C
¥:193.00



LL-82-0007
一开单控开关(荧光) ¥:33.00
1 gang 1 way switch(Fluorescent lamp)
一开双控开关(荧光) ¥:36.00
1 gang 2 way switch(Fluorescent lamp)
一开多控开关(荧光) ¥:54.00
1 gang 3 way switch(Fluorescent lamp)



LL-82-0015
百叶窗升降开关(荧光)
louver window lifter switch
(Fluorescent lamp)
¥:53.00



LL-82-0023
法式USB+Type-c
French USB+Type-C
¥:193.00



LL-82-0008
一开单控复位开关(荧光)
1 gang 1 way Reset switch
(Fluorescent lamp)
¥:38.00
一开双控复位开关(荧光)
1 gang 2 way Reset switch
(Fluorescent lamp)
¥:41.00



LL-82-0016
多功能插座
Universal socket
¥:33.00



LL-82-0024
德式插座+二位USB
2 USB with German socket
¥:183.00

LL-82 PC白色功能键/White function key PC



LL-82-0025
法式插座+二位USB
2 USB with French socket
¥:183.00



LL-82-0033
法式透明防溅插座
French transparent
splash-proof socket
¥:56.00




LL-82-0041
卫星插座
Satellite socket
¥:58.00



LL-82-0026
德式插座USB+Type-C(横)(10W)
German socket USB+Type-C
(horizontal)(10W)
¥:180.00



LL-82-0034
德式插座+防水
German socket + Waterproof belt
¥:43.00



LL-82-0042
二位卫星插座
Double Satellite socket
¥:78.00



LL-82-0027
德式插座USB+Type-C(横)(20W)
German socket USB+Type-C(20W)
(horizontal)
¥:250.00



LL-82-0035
法式插座+防水
French socket + Waterproof belt
¥:43.00




LL-82-0043
电视卫星插座
Satellite and TV socket
¥:63.00



LL-82-0028
法式插座USB+Type-C(横)(10W)
French socket USB+Type-C
(horizontal)(10W)
¥:180.00




LL-82-0036
电视插座
TV socket
¥:43.00




LL-82-0044
电话卫星插座 ¥:63.00
Satellite and telephone socket
电脑卫星插座 ¥:68.00
Satellite and computer socket



LL-82-0029
法式插座USB+Type-C(横)(20W)
French socket USB+Type-C
(horizontal)(20W)
¥:250.00



LL-82-0037
电话插座 ¥:43.00
telephone socket
电脑插座 ¥:53.00
computer socket



LL-82-0045
二位USB插座
Double USB socket
¥:163.00



LL-82-0030
德式插座带二位USB(横)
German socket with 2 USB
(horizontal)
¥:180.00



LL-82-0038
二位电视插座
Double TV socket
¥:53.00



LL-82-0046
二位音响插座
Single audio socket
¥:63.00



LL-82-0031
法式插座带二位USB(横)
French socket with 2 USB(horizontal)
¥:180.00



LL-82-0039
二位电话插座 ¥:53.00
Double telephone socket
二位电脑插座 ¥:63.00
Double computer socket
电话电脑插座 ¥:58.00
telephone+computer socket



LL-82-0047
四位音响插座
Double audio socket
¥:83.00



LL-82-0032
德式透明防溅插座
German type transparent
splash-proof socket
¥:56.00











LL-82-0040
电视电话插座 ¥:53.00
TV + telephone socket
电视电脑插座 ¥:58.00
TV + computer socket






LL-82-0048
紧急呼叫开关
Emergency call switch
¥:133.00
















LL-82 PC白色功能键/White function key PC

	LL-82-0049 调光开关300W Dimming 300W 调光开关500W Dimming 500W 调光开关1000W Dimming 1000W 调光LED开关200W Dimming LED 200W ¥:106.00 ¥:146.00 ¥:176.00 ¥:146.00		LL-82-0057 凹型人体感应地脚灯 The human body induction footlights ¥:218.00		LL-82-0065 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:48.00
	LL-82-0050 调速开关300W Speed 300W 调速开关500W Speed 500W ¥:106.00 ¥:146.00		LL-82-0058 剃须插座 Shaving socket ¥:408.00		LL-82-0066 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:48.00
	LL-82-0051 调音开关 Tuning switch (fire) ¥:156.00		LL-82-0059 空白面板 Blank plate ¥:14.00		LL-82-0067 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:58.00
	LL-82-0052 触摸延时开关 Touch delay switch ¥:106.00 声光控延时开关 Sound-light controlled delay switch ¥:106.00		LL-82-0060 二位德式插座(单体) Double German socket(single) ¥:60.00		LL-82-0068 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:88.00
	LL-82-0053 人体感应开关 Human body induction ¥:216.00		LL-82-0061 二位法式插座(单体) Double French socket (single) ¥:60.00		LL-82-0069 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:63.00
	LL-82-0054 叮咚门铃 Ding dong doorbell ¥:146.00		LL-82-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:330.00		LL-82-0070 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:170.00
	LL-82-0055 插卡取电(机械式) Mechanical card for electricity ¥:208.00 插卡取电(低频) Low frequency induction card for electricity ¥:338.00 插卡取电(高频) High frequency induction card for electricity ¥:468.00		LL-82-0063 20A红绿开关 20A Red and green switch ¥:95.00		LL-82-0071 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:125.00
	LL-82-0056 凹型地脚灯 The footlights ¥:118.00		LL-82-0064 空白出线孔 Blank outlet hole ¥:14.00		LL-82-0072 1/2 白板+白板 blank panel+blank panel ¥:19.00










LL-82 PC白色功能键/White function key PC

	LL-82-0073 1/2 双HDMI 1/2 Dual HDMI ¥:330.00		LL-82-0081 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:163.00		LL-82-0086 121型二位德式插座(短连体) 121 Double German socket(short) ¥:56.00
	LL-82-0074 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:208.00		LL-82-0082 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:163.00		LL-82-0087 121型二位法式插座(短连体) 121 Double French socket(short) ¥:56.00
	LL-82-0075 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:208.00		LL-82-0083 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:172.00		LL-82-0088 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:56.00
	LL-82-0076 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:217.00		LL-82-0084 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:203.00		
	LL-82-0077 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:248.00		LL-82-0085 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:178.00		
	LL-82-0078 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:223.00				
	LL-82-0079 1/2 USB/TYPE-C+HDMI ¥:285.00				
	LL-82-0080 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:240.00				










LL-82 烤漆彩色功能键/Paint color function key

	LL-82-0001 一开单控开关 ¥:37.00 1 gang 1 way switch (Fluorescent lamp) 一开双控开关 ¥:40.00 1 gang 2 way switch 一开多控开关 ¥:58.00 1 gang 3 way switch		LL-82-0009 二开单控开关(荧光) 2 gang 1 way switch (Fluorescent lamp) ¥:47.00 二开双控开关(荧光) 2 gang 2 way switch (Fluorescent lamp) ¥:53.00		LL-82-0017 13A方角插座 13A square corner socket ¥:37.00
	LL-82-0002 一开单控复位开关 1 gang 1 way Reset switch ¥:42.00 一开双控复位开关 1 gang 2 way Reset switch ¥:45.00		LL-82-0010 二开单控复位开关(荧光) 2 gang 1 way Reset switch (Fluorescent lamp) ¥:57.00 二开双控复位开关(荧光) 2 gang 2 way Reset switch (Fluorescent lamp) ¥:63.00		LL-82-0018 德式插座 German socket ¥:37.00
	LL-82-0003 二开单控开关 ¥:47.00 2 gang 1 way switch 二开双控开关 ¥:53.00 2 gang 2 way switch		LL-82-0011 三开单控开关(荧光) 3 gang 1 way switch (Fluorescent lamp) ¥:57.00 三开双控开关(荧光) 3 gang 2 way switch (Fluorescent lamp) ¥:66.00		LL-82-0019 法式插座 French socket ¥:37.00
	LL-82-0004 二开单控复位开关 2 gang 1 way Reset switch ¥:57.00 二开双控复位开关 2 gang 2 way Reset switch ¥:63.00		LL-82-0012 三开单复位开关(荧光) 3 gang 1 way Reset switch (Fluorescent lamp) ¥:72.00 三开双复位开关(荧光) 3 gang 2 way Reset switch (Fluorescent lamp) ¥:81.00		LL-82-0020 俄式插座 Russian socket ¥:37.00
	LL-82-0005 三开单控开关 ¥:57.00 3 gang 1 way switch 三开双控开关 ¥:66.00 3 gang 2 way switch		LL-82-0013 门铃开关(荧光) Doorbell switch (Fluorescent lamp) ¥:42.00		LL-82-0021 德意式插座 German+Italian socket ¥:57.00
	LL-82-0006 三开单复位开关 ¥:72.00 3 gang 1 way Reset switch 三开双复位开关 ¥:81.00 3 gang 2 way Reset switch		LL-82-0014 门禁开关(荧光) Gating switch (Fluorescent lamp) ¥:42.00		LL-82-0022 德式USB+Type-c German USB+Type-C ¥:197.00
	LL-82-0007 一开单控开关(荧光) ¥:37.00 1 gang 1 way switch(Fluorescent lamp) 一开双控开关(荧光) ¥:40.00 1 gang 2 way switch(Fluorescent lamp) 一开多控开关(荧光) ¥:58.00 1 gang 3 way switch(Fluorescent lamp)		LL-82-0015 百叶窗升降开关(荧光) louver window lifter switch (Fluorescent lamp) ¥:57.00		LL-82-0023 法式USB+Type-c French USB+Type-C ¥:197.00
	LL-82-0008 一开单控复位开关(荧光) 1 gang 1 way Reset switch (Fluorescent lamp) ¥:42.00 一开双控复位开关(荧光) 1 gang 2 way Reset switch (Fluorescent lamp) ¥:45.00		LL-82-0016 多功能插座 Universal socket ¥:37.00		LL-82-0024 德式插座+二位USB 2 USB with German socket ¥:187.00







LL-82 烤漆彩色功能键/Paint color function key

	LL-82-0025 法式插座+二位USB 2 USB with French socket ¥:187.00		LL-82-0033 法式透明防溅插座 French transparent splash-proof socket ¥:61.00		LL-82-0041 卫星插座 Satellite socket ¥:62.00
	LL-82-0026 德式插座USB+Type-C(横)(10W) German socket USB+Type-C (horizontal)(10W) ¥:185.00		LL-82-0034 德式插座+防水 German socket + Waterproof belt ¥:47.00		LL-82-0042 二位卫星插座 Double Satellite socket ¥:82.00
	LL-82-0027 德式插座USB+Type-C(横)(20W) German socket USB+Type-C(20W) (horizontal) ¥:255.00		LL-82-0035 法式插座+防水 French socket + Waterproof belt ¥:47.00		LL-82-0043 电视卫星插座 Satellite and TV socket ¥:67.00
	LL-82-0028 法式插座USB+Type-C(横)(10W) French socket USB+Type-C (horizontal)(10W) ¥:185.00		LL-82-0036 电视插座 TV socket ¥:47.00		LL-82-0044 电话卫星插座 ¥:67.00 Satellite and telephone socket 电脑卫星插座 ¥:72.00 Satellite and computer socket
	LL-82-0029 法式插座USB+Type-C(横)(20W) French socket USB+Type-C (horizontal)(20W) ¥:255.00		LL-82-0037 电话插座 ¥:47.00 telephone socket 电脑插座 ¥:57.00 computer socket		LL-82-0045 二位USB插座 Double USB socket ¥:167.00
	LL-82-0030 德式插座带二位USB(横) German socket with 2 USB (horizontal) ¥:185.00		LL-82-0038 二位电视插座 Double TV socket ¥:57.00		LL-82-0046 二位音响插座 Single audio socket ¥:67.00
	LL-82-0031 法式插座带二位USB(横) French socket with 2 USB(horizontal) ¥:185.00		LL-82-0039 二位电话插座 ¥:57.00 Double telephone socket 二位电脑插座 ¥:67.00 Double computer socket 电话电脑插座 ¥:62.00 telephone+computer socket		LL-82-0047 四位音响插座 Double audio socket ¥:87.00
	LL-82-0032 德式透明防溅插座 German type transparent splash-proof socket ¥:61.00		LL-82-0040 电视电话插座 ¥:57.00 TV + telephone socket 电视电脑插座 ¥:62.00 TV + computer socket		LL-82-0048 紧急呼叫开关 Emergency call switch ¥:137.00

LL-82 烤漆彩色功能键/ Paint color function key


	LL-82-0049 调光开关300W Dimming 300W 调光开关500W Dimming 500W 调光开关1000W Dimming 1000W 调光LED开关200W Dimming LED 200W ¥:110.00 ¥:150.00 ¥:180.00 ¥:150.00		LL-82-0057 凹型人体感应地脚灯 The human body induction footlights ¥:222.00		LL-82-0065 1/2 电视插座+白板 1/2 TV socket+blank panel ¥:52.00
	LL-82-0050 调速开关300W Speed 300W 调速开关500W Speed 500W ¥:110.00 ¥:150.00		LL-82-0058 剃须插座 Shaving socket ¥:412.00		LL-82-0066 1/2 电话插座+白板 1/2 telephone socket+blank panel ¥:52.00
	LL-82-0051 调音开关 Tuning switch(fire) ¥:160.00		LL-82-0059 空白面板 Blank plate ¥:18.00		LL-82-0067 1/2 电脑插座+白板 1/2 computer socket+blank panel ¥:62.00
	LL-82-0052 触摸延时开关 Touch delay switch 声光控延时开关 Sound-light controlled delay switch ¥:110.00 ¥:110.00		LL-82-0060 二位德式插座(单体) Double German socket(single) ¥:65.00		LL-82-0068 1/2 电脑插座六类+白板 1/2 Computer socket(Cat6) +blank panel ¥:92.00
	LL-82-0053 人体感应开关 Human body induction ¥:220.00		LL-82-0061 二位法式插座(单体) Double French socket (single) ¥:65.00		LL-82-0069 1/2 卫星插座+白板 1/2 satellite socket+blank panel ¥:67.00
	LL-82-0054 叮咚门铃 Ding dong doorbell ¥:150.00		LL-82-0062 请勿打扰请即清理 门铃开关(触摸式NP款) Do not disturb please clean the doorbell switch (push-button) NP type (key in the lower middle) ¥:330.00		LL-82-0070 1/2 HDMI+白板 1/2 HDMI+blank panel ¥:175.00
	LL-82-0055 插卡取电(机械式) Mechanical card for electricity 插卡取电(低频) Low frequency induction card for electricity 插卡取电(高频) High frequency induction card for electricity ¥:212.00 ¥:342.00 ¥:472.00		LL-82-0063 20A红绿开关 20A Red and green switch ¥:105.00		LL-82-0071 1/2 USB+type-c10W+白板 1/2 USB+type-c10W+blank panel ¥:130.00
	LL-82-0056 凹型地脚灯 The footlights ¥:122.00		LL-82-0064 空白出线孔 Blank outlet hole ¥:18.00		LL-82-0072 1/2 白板+白板 blank panel+blank panel ¥:23.00

LL-82 烤漆彩色功能键/ Paint color function key

	LL-82-0073 1/2 双HDMI 1/2 Dual HDMI ¥:340.00		LL-82-0081 1/2 电视+USB/TYPE-C 1/2 TV socket+1/2USB/TYPE-C ¥:172.00		LL-82-0086 121型二位德式插座(短连体) 121 Double German socket(short) ¥:61.00
	LL-82-0074 1/2 电视+HDMI 1/2 TV socket+1/2 HDMI socket ¥:217.00		LL-82-0082 1/2 电话+USB/TYPE-C 1/2 telephone socket+ 1/2 USB/TYPE-C ¥:172.00		LL-82-0087 121型二位法式插座(短连体) 121 Double French socket(short) ¥:61.00
	LL-82-0075 1/2 电话+HDMI 1/2 telephone socket+1/2 HDMI socket ¥:217.00		LL-82-0083 1/2 电脑+USB/TYPE-C 1/2 Computer socket+ USB/TYPE-C ¥:182.00		LL-82-0088 121型二位俄式插座(短连体) 121 Double Russian socket(short) ¥:61.00
	LL-82-0076 1/2 电脑插座+HDMI 1/2 computer socket+HDMI ¥:227.00		LL-82-0084 1/2 电脑六类+USB/TYPE-C 1/2 Computer socket(Cat6) +USB/TYPE-C ¥:212.00		
	LL-82-0077 1/2 电脑插座六类+HDMI 1/2 Computer socket(Cat6)+HDMI ¥:257.00		LL-82-0085 1/2 卫星+USB/TYPE-C 1/2 satellite socket+USB/TYPE-C ¥:187.00		
	LL-82-0078 1/2 卫星+HDMI 1/2 satellite socket+HDMI ¥:232.00				
	LL-82-0079 1/2 USB/TYPE-C+HDMI ¥:295.00				
	LL-82-0080 二位1/2 USB/TYPE-C Double 1/2 USB/TYPE-C ¥:250.00				


颜色可选

Colors are selectable




金色功能键

Gold function key



黑色功能键

Black function key



灰色功能键

Grey function key



电卡定制 ELECTRIC CARD CUSTOMIZATION

图案/文字/LOGO 免费定制
Design/text /LOGO free customization



机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of



机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of



机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of



机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of



机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of



机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of





机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of




机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of




机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of



机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of



机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of



机械卡Mecha card
¥：10.00/张 | 10.00/a sheet of
低频卡Low-frequency card
¥：20.00/张 | 20.00/a sheet of
高频卡High-frequency card
¥：20.00/张 | 20.00/a sheet of




新款底盒

New bottom box



EU

认真对待每一个产品
Take every product seriously



产品外观尺寸

Product appearance dimensions

86产品尺寸 86 Type

一位面框 One face frame	二位面框 Two face frame	三位面框 Three face frame	四位面框 Four face frame	五位面框 Five face frame
86MMX86MM	86MMX157MM	86MMX228MM	86MMX299MM	86MMX370MM

80产品尺寸 80 Type

一位面框 One face frame	二位面框 Two face frame	三位面框 Three face frame	四位面框 Four face frame	五位面框 Five face frame
80MMX80MM	80MMX150MM	80MMX221MM	80MMX292MM	80MMX363MM

European bottom box details
欧式底盒详情

EU CONNECTION
BOX



可做连体底盒
Can be made a one-piece bottom box

一位底盒 One bottom box	¥:10.00
二位连体底盒 Two-piece bottom box	¥:20.00
三位连体底盒 Three-piece bottom box	¥:30.00
四位连体底盒 Four-piece bottom box	¥:40.00
五位连体底盒 Five-piece bottom box	¥:50.00



可做连体底盒
Can be made a one-piece bottom box

一位底盒 One bottom box	¥:10.00
二位连体底盒 Two-piece bottom box	¥:20.00
三位连体底盒 Three-piece bottom box	¥:30.00
四位连体底盒 Four-piece bottom box	¥:40.00
五位连体底盒 Five-piece bottom box	¥:50.00



可做连体底盒
Can be made a one-piece bottom box

一位底盒 One bottom box	¥:10.00
二位连体底盒 Two-piece bottom box	¥:20.00
三位连体底盒 Three-piece bottom box	¥:30.00
四位连体底盒 Four-piece bottom box	¥:40.00
五位连体底盒 Five-piece bottom box	¥:50.00



可做连体底盒
Can be made a one-piece bottom box

一位底盒 One bottom box	¥:10.00
二位连体底盒 Two-piece bottom box	¥:20.00
三位连体底盒 Three-piece bottom box	¥:30.00
四位连体底盒 Four-piece bottom box	¥:40.00
五位连体底盒 Five-piece bottom box	¥:50.00



颜色可选
Color optional

White

Yellow

Green

Red

二位连体底盒
Two-piece bottom box
¥:20.00



颜色可选
Color optional

White

Yellow

Green

Red

三位连体底盒
Three-piece bottom box
¥:30.00



可做连体底盒
Can be made a one-piece bottom box

一位底盒 One bottom box	¥:10.00
二位连体底盒 Two-piece bottom box	¥:20.00
三位连体底盒 Three-piece bottom box	¥:30.00
四位连体底盒 Four-piece bottom box	¥:40.00
五位连体底盒 Five-piece bottom box	¥:50.00



可做连体底盒
Can be made a one-piece bottom box

一位底盒 One bottom box	¥:10.00
二位连体底盒 Two-piece bottom box	¥:20.00
三位连体底盒 Three-piece bottom box	¥:30.00
四位连体底盒 Four-piece bottom box	¥:40.00
五位连体底盒 Five-piece bottom box	¥:50.00



颜色可选
Color optional

White

Yellow

Green

Red

四位连体底盒
Four-piece bottom box
¥:40.00



颜色可选
Color optional

White

Yellow

Green

Red

五位连体底盒
Five-piece bottom box
¥:50.00